

DVP-S525D/S725D

RMT-D108P/D111P

SERVICE MANUAL

*South African Model
Middle and Near East Model*

Self Diagnosis
Supported model



Photo: DVP-S725D

SPECIFICATIONS

CD/DVD player

Laser Semiconductor laser
Signal format system PAL/(NTSC)

Audio characteristics

Frequency response DVD (PCM 96 kHz): 2 Hz to 44 kHz (± 1 dB)* (S525D)
DVD (PCM 96 kHz): 2 Hz to 44 kHz (± 0.5 dB)* (S725D)
DVD (PCM 48 kHz): 2 Hz to 22 kHz (± 0.5 dB)
CD: 2 Hz to 20 kHz (± 0.5 dB)

Signal-to-noise ratio More than 110 dB (LINE OUT (AUDIO) connectors only) (S525D)
More than 110 dB (AUDIO OUT connector only) (S725D)

Harmonic distortion Less than 0.0025%
Dynamic range More than 100 dB (DVD)
More than 98 dB (CD)

Wow and flutter Less than detected value ($\pm 0.001\%$ W PEAK)

Outputs and inputs

	Jack type	Output level	Load impedance
LINE OUT (AUDIO) (S525D)	Phono jacks	2 Vrms (at 50 kilohms)	Over 10 kilohms
AUDIO OUT (S725D)	Phono jacks	2 Vrms (at 50 kilohms)	Over 10 kilohms
DIGITAL OUT (OPTICAL)	Optical output connector	-18 dBm	Wave length: 660 nm
DIGITAL OUT (COAXIAL)	Phono jack	0.5 Vp-p	75 ohms terminated
LINE OUT (VIDEO) (S525D)	Phono jacks	1.0 Vp-p	75 ohms, sync negative

VIDEO OUT (1, 2) (S725D)	Phono jacks	1.0 Vp-p	75 ohms, sync negative
S VIDEO OUT (S525D)	4-pin mini DIN	Y: 1.0 Vp-p	75 ohms, sync negative
S VIDEO OUT (1, 2) (S725D)		C: 0.3 Vp-p (PAL) C: 0.286 Vp-p (NTSC)	75 ohms terminated
COMPONENT VIDEO OUT (Y, Cb/B-Y, Cr/R-Y) (S725D)	phono jacks	Y: 1.0 Vp-p Cb/B-Y, Cr/R-Y: 0.7 Vp-p	75 ohms, sync negative
PHONES	Phone jack	12 mW	32 ohms
5.1CH OUTPUT	Phono jacks	2 Vrms (at 50 kilohms)	Over 10 kilohms

General

Power requirements 220 - 240 V AC, 50/60 Hz
Power consumption 17 W (S525D)
22 W (S725D)

Dimensions (approx.) 430 × 95 × 305 mm (w/h/d) incl. projecting parts

Mass (approx.) 3.4 kg (S525D)
4.0 kg (S725D)

Operating temperature 5°C to 35°C
Operating humidity 5% to 90%

- Continued on next page -



CD/DVD PLAYER

SONY

Supplied accessories

- Audio/Video connecting cord (1)
- S video cable (1)
- Remote commander (remote) RMT-D108P (1) (S525D)
- Remote commander (remote) RMT-D111P (1) (S725D)
- Size AA (R6) batteries (2)




DVP-S525D:

- * The signals from LINE OUT (AUDIO) connectors and 5.1 ch L, R connectors are measured. When you play the PCM sound tracks with 96 kHz sampling frequency, the output signals from the DIGITAL OUT (OPTICAL, COAXIAL) are converted to 48 kHz (sampling frequency).

DVP-S725D:

- * The signals from AUDIO OUT connectors and 5.1 ch L, R connectors are measured. When you play the PCM sound tracks with 96 kHz sampling frequency, the output signals from the DIGITAL OUT (OPTICAL, COAXIAL) are converted to 48 kHz (sampling frequency).

Design and specifications are subject to change without notice.



WARNING!!

WHEN SERVICING, DO NOT APPROACH THE LASER EXIT WITH THE EYE TOO CLOSELY. IN CASE IT IS NECESSARY TO CONFIRM LASER BEAM EMISSION, BE SURE TO OBSERVE FROM A DISTANCE OF MORE THAN 25 cm FROM THE SURFACE OF THE OBJECTIVE LENS ON THE OPTICAL PICK-UP BLOCK.

CAUTION:

The use of optical instrument with this product will increase eye hazard.

CAUTION

Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

SAFETY CHECK-OUT

After correcting the original service problem, perform the following safety checks before releasing the set to the customer:

1. Check the area of your repair for unsoldered or poorly-soldered connections. Check the entire board surface for solder splashes and bridges.
2. Check the interboard wiring to ensure that no wires are "pinched" or contact high-wattage resistors.
3. Look for unauthorized replacement parts, particularly transistors, that were installed during a previous repair. Point them out to the customer and recommend their replacement.
4. Look for parts which, though functioning, show obvious signs of deterioration. Point them out to the customer and recommend their replacement.
5. Check the B+ voltage to see it is at the values specified.

SAFETY-RELATED COMPONENT WARNING!!

COMPONENTS IDENTIFIED BY MARK \triangle OR DOTTED LINE WITH MARK \triangle ON THE SCHEMATIC DIAGRAMS AND IN THE PARTS LIST ARE CRITICAL TO SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY.


TABLE OF CONTENTS

<i>Section</i>	<i>Title</i>	<i>Page</i>	<i>Section</i>	<i>Title</i>	<i>Page</i>
Service Note		4	ER-4 Printed Wiring Board		4-55
1. GENERAL			ER-4 (EURO AV1) Schematic Diagram		4-57
Getting Started		1-1	ER-4 (EURO AV2) Schematic Diagram		4-59
Playing Discs		1-4	ER-5 Printed Wiring Board		4-61
Using Various Functions with the Control Menu		1-6	ER-5 (EURO AV1) Schematic Diagram		4-65
Settings and Adjustments		1-12	ER-5 (EURO AV2) Schematic Diagram		4-67
2. DISASSEMBLY			FL-100 Printed Wiring Board		4-69
2-1. Case Removal		2-1	FL-98 Printed Wiring Board		4-73
2-2. MB-85 Board Removal		2-1	FL-98/100 (FUNCTION SWITCH) Schematic Diagram		4-75
2-3. Power Block Removal		2-1	FL-98/100 (IF CON) Schematic Diagram		4-77
2-4. ER-4/5 Board Removal		2-1	SW-314/316 Printed Wiring Boards		4-79
2-5. AU-209 Board Removal (S525D)		2-2	FR-147/149 Printed Wiring Boards		4-80
2-6. AU-211 Board Removal (S725D)		2-2	SW-314/316, FR-147/149 Schematic Diagram		4-81
2-7. Tray Cover Removal		2-2	HP-108/110 Printed Wiring Boards and Schematic Diagram		4-83
2-8. Front Panel Removal		2-2	RY-12 Printed Wiring Board and Schematic Diagram		4-85
2-9. Mechanism Deck Removal		2-3	HS-030SH Printed Wiring Board		4-87
2-10. Tray Removal		2-3	HS-030SH Schematic Diagram		4-89
2-11. Optical Pick-up Removal		2-3	5. IC PIN FUNCTION DESCRIPTION		
2-12. Belt, Loading Motor (M001), MS-29/TK-54 Board Removal		2-3	5-1. System Control Pin Function (MB-85 Board IC202)		5-1
2-13. Internal View		2-4	6. TEST MODE		
2-14. Circuit Boards Location		2-5	6-1. General Description		6-1
3. BLOCK DIAGRAMS			6-2. Starting Test Mode		6-1
3-1. Overall Block Diagram		3-1	6-3. Syscon Diagnosis		6-1
3-2. RF/Servo Block Diagram		3-3	6-4. Drive Auto Adjustment		6-5
3-3. Signal Process Block Diagram		3-5	6-5. Drive Manual Operation		6-7
3-4. Video Block Diagram		3-7	6-6. Mecha Aging		6-9
3-5. System Control Block Diagram		3-9	6-7. Emergency History		6-9
3-6. Audio (1) Block Diagram		3-11	6-8. Version Information		6-10
3-7. Audio (2) Block Diagram		3-13	6-9. Video Level Adjustment		6-10
3-8. Audio (3) Block Diagram		3-15	6-10. If Con Self Diagnostic Function		6-11
3-9. Interface Control Block Diagram		3-17	7. ELECTRICAL ADJUSTMENT		
3-10. Power Block Diagram		3-19	7-1. Power Supply Adjustment		7-1
4. PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAMS			1. HS030SH Board		7-1
4-1. Frame Schematic Diagrams		4-3	7-2. Adjustment of Video System		7-2
FRAME (1) Schematic Diagram		4-3	1. Video Level Adjustment		7-2
FRAME (2) Schematic Diagram		4-5	2. S-terminal Output Check		7-2
FRAME (3) Schematic Diagram		4-7	3. Checking Component Video Output B-Y		7-2
4-2. Printed Wiring Boards and Schematic Diagrams		4-9	4. Checking Component Video Output R-Y		7-2
TK-54 Printed Wiring Board		4-9	5. Checking Component Video Output Y		7-3
TK-54 Schematic Diagram		4-13	6. Checking RGB Output R		7-3
MS-29 Printed Wiring Board and Schematic Diagram		4-15	7. Checking RGB Output G		7-3
MB-85 Printed Wiring Board		4-17	8. Checking RGB Output B		7-3
MB-85 (AV DECODER) Schematic Diagram		4-21	9. Checking S Video output S-C		7-4
MB-85 (SDRAM) Schematic Diagram		4-23	7-3. Adjustment Related Parts Arrangement		7-6
MB-85 (SERVO DSP) Schematic Diagram		4-25	8. REPAIR PARTS LIST		
MB-85 (DRIVE) Schematic Diagram		4-27	8-1. Exploded Views		8-1
MB-85 (ARP) Schematic Diagram		4-29	8-1-1. Case Assembly (S525D)		8-1
MB-85 (SYSTEM CONTROL) Schematic Diagram		4-31	8-1-2. Case Assembly (S725D)		8-2
MB-85 (HGA) Schematic Diagram		4-33	8-1-3. Front Panel Assembly		8-3
MB-85 (CLOCK GENERATOR, AUDIO DSP, V EQ/NR) Schematic Diagram		4-35	8-1-4. Chassis Assembly		8-4
MB-85 (DAC) Schematic Diagram		4-37	8-1-5. Mechanism Deck Assembly		8-6
MB-85 (BIAS) Schematic Diagram		4-39	8-2. Electrical Parts List		8-7
AU-211 Printed Wiring Board		4-41			
AU-211 (AUDIO) Schematic Diagram		4-45			
AU-211 (VIDEO BUFFER) Schematic Diagram		4-47			
AU-209 Printed Wiring Board		4-49			
AU-209 (AUDIO) Schematic Diagram		4-51			
AU-209 (VIDEO BUFFER) Schematic Diagram		4-53			

SERVICE NOTE

1. DISASSEMBLY

- This set can be disassembled in the order shown below.



2. NOTE ON REMOVE THE CASE

- 1) Remove seven screws. (See Fig. 1)
- 2) Open the side of case. (See Fig. 1)
- 3) Remove the case as lift straight. (See Fig. 1)




Fig. 1

3. DISC REMOVAL PROCEDURE (at POWER OFF)

- 1) Insert a tapering driver into the aperture of the unit bottom, and move the lever of chuck cam in the direction of the arrow (A). (See Fig. 2)
- 2) Draw out the tray in the direction of the arrow (B), and remove a disc. (See Fig. 2)




Fig. 2

4. HOW TO SERVICE MB-85 BOARD

- 1) Remove the case from the set. (Refer to 2-1)
- 2) Remove the MB-85 board. (Refer to 2-2)
- 3) Set the MB-85 board as shown in Fig. 3.

Note: Do not disconnect wiring, except FMA-7/8/9.




Fig. 3

SECTION 1 GENERAL

This section is extracted from DVP-S725D instruction manual (3-866-153-21).

About This Manual

Conventions

- Instructions in this manual describe the controls on the player. You can also use the controls on the remote if they have the same or similar names as those on the player.
- The icons on the right are used in this manual:

Icon	Meaning
	Indicates that you can use only the remote to do the task.
	Indicates tips and hints for making the task easier.
	Indicates the functions for DVD VIDEOS.
	Indicates the functions for VIDEO CDs.
	Indicates the functions for Audio CDs.

This Player Can Play the Following Discs

	DVD VIDEOS		VIDEO CDs		Audio CDs	
Disc logo						
Contents	Audio + Video		Audio + Video		Audio	
Disc size	12 cm	8 cm	12 cm	8 cm	12 cm	8 cm (CD single)
Play time	About 4 h (for single-sided DVD) / about 8 h (for double-sided DVD)	About 40 min (for single-sided DVD) / about 160 min (for double-sided DVD)	74 min.	20 min.	74 min.	20 min

*DVD VIDEO® logo is a trademark.

When you play an NTSC disc, this player outputs the video signal in the NTSC system only. In this case, if your TV is a PAL system mode, the picture becomes noisy.

Region code of DVDs you can play on this unit

Your DVD player has a region code printed on the back of the unit and will only play DVDs that are labeled with identical region codes.

DVDs labeled (R1) will be also played on this unit.

If you try to play any other DVD, the message "Playing this disc prohibited by area limits." will appear on the TV screen.

Depending on the DVD, no region code indication may be labeled even though playing the DVD is prohibited by the area limits.




Note on playback operations of DVDs and VIDEO CDs

Some playback operations of DVDs and VIDEO CDs may be intentionally fixed by software producers. Since this player plays DVDs and VIDEO CDs according to the disc contents the software producers designed, some playback features may not be available. Also refer to the instructions supplied with the DVDs or VIDEO CDs.

4

Terms for discs

- Title**
The longest sections of a picture or a music piece on a DVD: a movie, etc., for a picture piece on a video software; or an album, etc., for a music piece on an audio software. Each title is assigned a title number enabling you to locate the title you want.
- Chapter**
Sections of a picture or a music piece that are smaller than titles. A title is composed of several chapters. Each chapter is assigned a chapter number enabling you to locate the chapter you want. Depending on the disc, no chapters may be recorded.
- Track**
Sections of a picture or a music piece on a VIDEO CD or a CD. Each track is assigned a track number enabling you to locate the track you want.



Index (CD) / Video Index (VIDEO CD)

A number that divides a track into sections to easily locate the point you want on a VIDEO CD or a CD. Depending on the disc, no indexes may be recorded.

Scene

On a VIDEO CD with PBC functions, the menu screens, moving pictures and still pictures are divided into sections called "scenes." Each scene is assigned a scene number enabling you to locate the scene you want.

Note on PBC (Playback Control) (VIDEO CDs)

This player conforms to Ver. 1.1 and Ver. 2.0 of VIDEO CD standards. You can enjoy two kinds of playback according to the disc type.

Disc type	You can
VIDEO CDs without PBC functions (Ver. 1.1 discs)	Enjoy video playback (moving pictures) as well as music.
VIDEO CDs with PBC functions (Ver. 2.0 discs)	Play interactive software using menu screens displayed on the TV screen (PBC Playback), in addition to the video playback functions of Ver. 1.1 discs. Moreover, you can play high-resolution still pictures, if they are included on the disc.

Discs that the player cannot play

The player cannot play discs other than the ones listed in the table on page 4. CD-Rs, CD-RWs including PHOTO CDs, data discs, CD-EXTRAS, DVD-ROMs etc., cannot be played.

When playing DTS®-encoded CDs, excessive noise will be heard from the analog stereo outputs. To avoid possible damage to the audio system, the consumer should take proper precautions when the analog stereo outputs of the DVD player are connected to an amplification system. To enjoy DTS Digital Surround™ playback, an external 5.1-channel DTS Digital Surround™ decoder system must be connected to the digital output of the DVD player.

This product incorporates copyright protection technology that is protected by method claims of certain U.S. patents and other intellectual property rights owned by Macrovision Corporation and other rights owners. Use of this copyright protection technology must be authorized by Macrovision Corporation, and is intended for home and other limited viewing uses only unless otherwise authorized by Macrovision Corporation. Reverse engineering or disassembly is prohibited.

* "DTS" is a trademark of Digital Theater Systems, Inc.

5

Precautions

On safety

- Caution** - The use of optical instruments with this product will increase eye hazard.
- Should any solid object or liquid fall into the cabinet, unplug the player and have it checked by qualified personnel before operating it any further.

On power sources

- The player is not disconnected from the AC power source (mains) as long as it is connected to the wall outlet, even if the player itself has been turned off.
- If you are not going to use the player for a long time, be sure to disconnect the player from the wall outlet. To disconnect the AC power cord (mains lead), grasp the plug itself; never pull the cord.
- Should the AC power cord (mains lead) need to be changed, have it done at a qualified service shop only.

On placement

- Place the player in a location with adequate ventilation to prevent heat build-up in the player.
- Do not place the player on a soft surface such as a rug that might block the ventilation holes on the bottom.
- Do not place the player in a location near heat sources, or in a place subject to direct sunlight, excessive dust or mechanical shock.

On operation

- If the player is brought directly from a cold to a warm location, or is placed in a very damp room, moisture may condense on the lenses inside the player. Should this occur, the player may not operate properly. In this case, remove the disc and leave the player turned on for about half an hour until the moisture evaporates.

On adjusting volume

- Do not turn up the volume while listening to a portion with very low level inputs or no audio signals. If you do, the speakers may be damaged when a peak level portion is played.

On cleaning

- Clean the cabinet, panel and controls with a soft cloth slightly moistened with a mild detergent solution. Do not use any type of abrasive pad, scouring powder or solvent such as alcohol or benzene.

If you have any questions or problems concerning your player, please consult your nearest Sony dealer.

IMPORTANT NOTICE

Caution: The enclosed DVD player is capable of holding a still video image or On screen display image on your television screen indefinitely. If you leave the still video image or On screen display image displayed on your TV for an extended period of time you risk permanent damage to your television screen. Projection televisions are very susceptible.

Notes on Discs

On handling discs

- To keep the disc clean, handle the disc by its edge. Do not touch the surface.
- Do not stick paper or tape on the disc.
- If there is glue (or a similar substance) on the disc, remove the glue completely before using the disc.



- Do not expose the disc to direct sunlight or heat sources such as hot air ducts, or leave it in a car parked in direct sunlight as there can be considerable rise in temperature inside the car.
- After playing, store the disc in its case.

On cleaning

- Before playing, clean the disc with a cleaning cloth. Wipe the disc from the center out.



- Do not use solvents such as benzene, thinner, commercially available cleaners or anti-static spray intended for vinyl LPs.

Getting Started

This section describes how to hook up the CD/DVD player to a TV (with audio/video input jacks) and/or an AV receiver (amplifier). You cannot connect this player to a TV which does not have a video input connection. Be sure to turn off the power of each component before making the connections.


Unpacking

Check that you have the following items:

- Audio/video connecting cord (1)
- S video cord (1)
- Remote commander (remote) RMT-D111F (1)
- R6 (size AA) batteries (2)

Inserting batteries into the remote

You can control the player using the supplied remote. Insert two R6 (size AA) batteries by matching the + and - on the batteries. When using the remote, point it at the remote sensor (2) on the player.



You can control TVs and AV receivers using the supplied remote. See page 63.

Notes

- Do not leave the remote in an extremely hot or humid place.
- Do not drop any foreign object into the remote casing, particularly when replacing the batteries.
- Do not expose the remote sensor to direct sunlight or lighting appliances. Doing so may cause a malfunction.
- If you will not use the remote for an extended period of time, remove the batteries to avoid possible damage from battery leakage and corrosion.

6

7

Receiver (Amplifier) Hookups



Getting Started

This connection is for listening to the sound through speakers connected to a receiver (amplifier) such as an integrated stereo amplifier, a receiver having a built-in Dolby Pro Logic decoder, etc.). Refer to the instructions supplied with the component to be connected. You can enjoy 5.1 channel surround sound by connecting a receiver (amplifier) with 5.1 channel inputs. See page 36.

You can enjoy surround when connecting front speakers only. You can use 3D sound imaging to create virtual rear speakers from the sound of the front speakers (L, R) without using actual rear speakers (Virtual Enhanced Surround). For details, see page 36.

Required cords

Audio connecting cord (not supplied) (1)
5 video cord (supplied) (1)
When connecting the cords, be sure to match the color-coded cord to the appropriate jacks on the components. Red (right) to Red and White (left) to White. Be sure to make connections firmly to avoid hum and noise.




Note
You cannot enjoy the picture with 5 video signal if your TV is not conformed to the 5 video signal. When your TV does not have 5 VIDEO input, connect the component via the VIDEO INPUT connector using the video connecting cord (not supplied) instead of the 5 video cord. For details, see page 9.
Refer to the instructions supplied with your TV.

12


If you have a digital component such as a receiver (amplifier) with a digital connector, DAT or MD

Connect the component via the DIGITAL OUT OPTICAL or COAXIAL connector using an optical or coaxial digital connecting cord (not supplied).
When you play a DVD, set "DIGITAL OUT" in "AUDIO SETUP" to "ON" and then set "DOLBY DIGITAL" to "D-PCM", "MPEG" to "PCM" and "DTS" to "OFF" in the setup display. (page 59)

■ When using an optical digital connecting cord



Take off the cap and plug in the optical digital connecting cord.



■ When using a coaxial digital connecting cord



Notes

- Refer to the instructions supplied with the component to be connected.
- You cannot make digital audio recordings of discs recorded in multi-channel surround format directly using an MD deck or DAT deck.

When you make the connections above, do not set "DOLBY DIGITAL" to "DOLBY DIGITAL", "MPEG" to "MPEG" and "DTS" to "ON". If you do, a loud noise will suddenly come out from the speakers, affecting your ears or causing the speakers to be damaged.


If you have an audio component with a built-in DTS decoder, Dolby Digital decoder or MPEG decoder

Connect the component via the DIGITAL OUT OPTICAL or COAXIAL connector using an optical or coaxial digital connecting cord (not supplied).

■ When you play a DVD or CD that are recorded in DTS format
Set "DIGITAL OUT" in "AUDIO SETUP" to "ON" and then set "DTS" to "ON" in the setup display. (page 59)

■ When you play a DVD that is recorded in Dolby Digital format
Set "DIGITAL OUT" in "AUDIO SETUP" to "ON" and then set "DOLBY DIGITAL" to "DOLBY DIGITAL" in the setup display. (page 59)

■ When you play a DVD that is recorded in MPEG format
Set "DIGITAL OUT" in "AUDIO SETUP" to "ON" and then set "MPEG" to "MPEG" in the setup display. (page 59)



Notes

- Refer to the instructions supplied with the component to be connected.
- When you do not connect an audio component with a built-in DTS decoder, do not set "DTS" to "ON".
- When you do not connect an audio component with a built-in DOLBY DIGITAL decoder, do not set "DOLBY DIGITAL" to "DOLBY DIGITAL".
- When you do not connect an audio component with a built-in MPEG decoder, do not set "MPEG" to "MPEG."

Setups for the player

Some setups are necessary for the player depending on the components to be connected.

Use the setup display to change the various settings. For details on using the setup display, see page 49.

- To listen to the sound through speakers connected to a receiver (amplifier) having a digital connector or to output the sound to a digital component such as a DAT or MD deck
When you play a DVD, set "DIGITAL OUT" in "AUDIO SETUP" to "ON" and then set "DOLBY DIGITAL" to "D-PCM", "MPEG" to "PCM" and "DTS" to "OFF" in the setup display (page 59). These are the default settings.

Getting Started

13

5.1 Channel Surround Hookups

Getting Started

Some DVDs have a sound track with up to 5.1 channels recorded in Dolby® Digital (AC-3) or MPEG AUDIO format. Using a receiver (amplifier) having 5.1 channel inputs and the 5 (+1) speakers, you can enjoy more real audio presence in the comfort of your own home. "5 channel" stands for the 2 front speakers (Left and Right), 2 rear speakers (Left and Right) and 1 center speaker. The "0.1 channel" (+1) stands for the subwoofer which outputs the bass.

Even if you have fewer than 5 (+1) speakers, the player distributes the output signal to the speakers appropriately. This player has VIRTUAL 3D SURROUND mode. You can use the 3D sound imaging to shift the sound of the rear speakers away from the actual speaker position (VIRTUAL REAR SHIFT) or to create 3 sets of virtual rear speakers from 1 set of actual rear speakers (VIRTUAL MULTI REAR). For details on the VIRTUAL 3D SURROUND mode, see page 36.

Note

When a DVD has a sound track with 7.1 channels recorded in MPEG AUDIO format, the output audio signals are mixed down to 5.1 channels.

Speaker placement

For the best possible surround sound, we recommend the following conditions.


- Use higher performance speakers.
- Use rear and center speakers that match your front speakers in size and performance.
- All speakers should be the same distance from the listening position.
- Place the subwoofer between the front (L, R) speakers if possible.

Note


Do not place the center or rear speakers further away from the listening position than the front speakers.

Required cords


Audio cords (not supplied)
Two for the 5.1CH OUTPUT FRONT and REAR jacks



Monoserial audio cords (not supplied)
Two for the 5.1CH OUTPUT CENTER and SUBWOOFER jacks



5 video cord (supplied)
One for the 5 VIDEO OUT jacks



Notes

- Do not connect the power cord to an AC outlet or press the POWER switch before completing all connections.
- The cord connectors should be fully inserted into the jacks. Loose connection may cause hum and noise.
- Jacks and plugs of the connecting cords are color-coded as follows:
Red jacks and plugs: Right audio channel
White jacks and plugs: Left audio channel
You can use either red or white cables to connect the center speaker and subwoofer.
- When you connect the component via the DIGITAL OUT OPTICAL or COAXIAL connector using an optical or coaxial digital connecting cord (not supplied), see page 13.


Setups for the player

Some setups are necessary for the player depending on the components to be connected. Use the setup display or the Control Menu display to change the various settings.

For details on using the setup display, see page 49. For details on enjoying Digital Cinema Sound, see page 36.

- To enjoy Dolby Digital or MPEG AUDIO surround sound by connecting the player to a receiver (amplifier) with 5.1 ch inputs
Set each speaker position or distance, etc. See page 61.

* Manufactured under license from Dolby Laboratories. "Dolby", "AC-3", "Pro Logic" and the double-D symbol are trademarks of Dolby Laboratories. Confidential Unpublished Works. ©1995-1997 Dolby Laboratories, Inc. All rights reserved.




Getting Started

14


15

Selecting the Language for On-Screen Display

You can select the language for the setup display, the Control Menu display or the messages displayed on the screen. Default setting is "ENGLISH."



- 1 Press SET UP and select "LANGUAGE SETUP" using \uparrow/\downarrow , then press ENTER.



- 2 Select "OSD" using \uparrow/\downarrow , then press \rightarrow or ENTER.



- 3 Select "FRANÇAIS" using \uparrow/\downarrow , then press ENTER.



To cancel using the setup display on the way Press SET UP.

Note
The languages you can select are the ones displayed in step 2. For details, see page 52.


Playing Discs

This chapter describes how to play a DVD/CD/VIDEO CD.

This player conforms to the PAL color system. When you play a disc recorded in the NTSC color system, the player outputs the video signal or the setup display etc. in the NTSC color system and the picture may not appear on the TV screen. In this case, open the disc tray and remove the disc.

Playing Discs DVD VIDEO CD

Depending on the DVD or VIDEO CD, some operations may be different or restricted. Refer to the instructions supplied with your disc.




- 1 Make settings on your TV.
Turn on the TV and select the video input so that you can view the pictures from this player.

When using a receiver (amplifier)
Turn on the receiver (amplifier) and select the appropriate position so that you can listen to the sound from this player.

- 2 Press I/O (POWER) to turn on the player.
The indicator (red) above the I/O (POWER) button changes to green and the front panel display lights up.

- 3 Press Δ , and place the disc on the disc tray.



- 4 Press \triangleright .
The disc tray closes, and the player starts playback (Continuous Play). Adjust the volume on the TV or the receiver (amplifier).

After following Step 4
■ When playing a DVD
A DVD menu or title menu may appear on the TV screen (see page 21).
■ When playing a VIDEO CD
The menu screen may appear on the TV screen depending on the VIDEO CD. You can play the disc interactively, following the instructions on the menu screen. (PBC Playback, see page 22.)



16

17

Playing Discs

You can turn on the player using the remote.
Press I/O (POWER) when the indicator above the I/O (POWER) button on the front panel is lit in red.

- Notes
- If you leave the player or the remote in pause or stop mode for 15 minutes, the screen saver image appears automatically. To make the screen saver image go away, press \triangleright . (If you want to set the screen saver function to off, see page 53.)
 - The indicator above the I/O (POWER) button lights up in red when the power is turned off.
 - If you don't operate the player or the remote for more than 30 minutes when a disc is not being played, the power is automatically turned off. (Auto Power Off function)




To	Operation
Stop	Press \blacksquare .
Pause	Press M.
Resume play after pause	Press M or \triangleright .
Go to the next chapter, track or scene in continuous play mode	On the player: Turn $\blacktriangleleft/\blacktriangleright$ clockwise to select the chapter and then press $\blacktriangleleft/\blacktriangleright$. On the remote: Press $\blacktriangleleft/\blacktriangleright$.
Go back to the preceding chapter, track or scene in continuous play mode	On the player: Turn $\blacktriangleleft/\blacktriangleright$ counterclockwise to select the chapter and then press $\blacktriangleleft/\blacktriangleright$. On the remote: Press $\blacktriangleleft/\blacktriangleright$.
Stop play and remove the disc	Press Δ .

You can play discs in various modes such as Program Play using the on-screen menu (Control Menu). For operations of Control Menu, see page 25.

Playing at Various Speeds/Frame by Frame DVD VIDEO CD

Using the click shuttle and the JOG button/indicator, you can play back a DVD/CD/VIDEO CD at various speeds or frame by frame. Each time you press JOG, it changes between shuttle mode and jog mode.



When you play back a CD/VIDEO CD

- 2 \blacktriangleright Fast forward (Faster than "1 \blacktriangleright ")
- 1 \blacktriangleright Fast forward
- 1 \blacktriangleright (Normal speed)
- 1 \blacktriangleright Slow (playback direction)*
- 2 \blacktriangleright Slow (playback direction) - slower than "1 \blacktriangleright "
- 1 \blacksquare Pause
- 1 \blacktriangleleft Fast rewind
- 2 \blacktriangleleft Fast rewind (Faster than "1 \blacktriangleleft ")

* VIDEO CD Only

If you turn the click shuttle quickly, the playback speed goes to 2 \blacktriangleright /2 \blacktriangleleft at once.

To return to continuous play
Press \triangleright .

To search for the picture using the button on the remote
Keep pressing \blacktriangleleft or \blacktriangleright . The playback speed is same as 1 \blacktriangleleft or 1 \blacktriangleright when using the click shuttle.

Note
Depending on the DVD/VIDEO CD, you may not be able to do some of the operations described.

To change the playback speed (Shuttle mode)

Turn the click shuttle. The playback speed changes depending on the turning direction and angle as follows:

When you play back a DVD

- 2 \blacktriangleright Fast forward (about 10 times the normal speed)
- 1 \blacktriangleright Fast forward (about 10 times the normal speed)
- 2 \blacktriangleright (about twice the normal speed)
- 1 \blacktriangleright (Normal speed)
- 1 \blacktriangleright Slow (playback direction)
- 2 \blacktriangleright Slow (playback direction) - slower than "1 \blacktriangleright "
- 1 \blacksquare Pause
- 2 \blacktriangleleft Slow (opposite direction) - slower than "1 \blacktriangleleft "
- 1 \blacktriangleleft Slow (opposite direction)
- 2 \blacktriangleleft (about twice the normal speed)
- 1 \blacktriangleleft Fast rewind (about 10 times the normal speed)
- 2 \blacktriangleleft Fast rewind (about 10 times the normal speed)

If you turn the click shuttle quickly, the playback speed goes to 2 \blacktriangleright /2 \blacktriangleleft at once.

18

19

Playing at Various Speeds/Frame by Frame

To play the disc frame by frame changing the playback speed (Jog mode)

- 1 Press JOG.
JOG lights up during jog mode. When you press JOG on the player, it pauses.
- 2 Turn the click shuttle.
Depending on the turning speed, the playback goes to frame-by-frame in the direction that the click shuttle is turned. If you turn the click shuttle with constant speed for a while, the playback speed goes to slow or normal.

To return to Continuous Play



Press ▷.

Notes

- The JOG indicator shows the mode of the corresponding click shuttle. For example, when the JOG indicator on the remote is not lit, the remote click shuttle will remain in the shuttle mode even if the indicator on the player is lit.
- If you don't operate the click shuttle for about 20 seconds after pressing JOG, it returns to shuttle mode on the remote. On the player, it stays in jog mode.

Resuming Playback from the Point Where You Stopped the Disc (Resume Play)

The player stores the point where you stopped the disc and if "RESUME" appears on the front panel display. You can resume playback from that point. As long as you do not open the disc tray, Resume Play is available even if you turn the power off.



- 1 While playing a disc, press ■ to stop playback. "RESUME" appears in the front panel display and "When playing next time, disc restarts from point you stopped." appears on the TV screen. If "RESUME" does not appear, Resume Play is not available.

- 2 Press ▷.
The player starts playback from the point where you stopped the disc in Step 1.

To play from the beginning of the disc
When the playing time appears on the front panel display before you start playing, press ■ to reset the playing time, then press ▷.



Notes

- Resume Play may not be available depending on the DVD.
- Resume Play is not available in Shuffle or Program Play mode.
- Depending on where you stopped the disc, the player may resume playback from a different point.
- The point where you stopped playing is cleared when:
 - you open or close the disc tray
 - you disconnect the AC power cord
 - you change the play mode
 - you start playback after selecting a title, chapter or track
 - you change the settings of "OSD," "DVD MENU," "AUDIO" or "SUBTITLE" in "LANGUAGE SETUP" in the setup display and "AUDIO" or "SUBTITLE" in the Control Menu display
 - you change the settings of "TV TYPE" in "SCREEN SETUP" in the setup display
 - you change the settings of "PARENTAL CONTROL" in "CUSTOM SETUP" in the setup display

Using the Menu for Each DVD

Using the title menu

A DVD is divided into long sections of a picture or a music piece called "titles." When you play a DVD which contains several titles, you can select the title you want using the title menu.



- 1 Press TITLE.
The title menu appears on the TV screen. The contents of the menu vary from disc to disc.
- 2 Press ◀/▶/◂/▸ to select the title you want to play.
Depending on the disc, you can use the number buttons to select the title.
- 3 Press ENTER.
The player starts playing the selected title.

Notes

- Depending on the DVD, you may not be able to select the title.
- Depending on the DVD, a "title menu" may simply be called a "menu" or "title" in the instructions supplied with the disc. "Press ENTER" may also be expressed as "Press SELECT."

20

21

Using the Menu for Each DVD

Using the DVD menu

Some DVDs allow you to select the disc contents using the menu. When you play these DVDs, you can select the language for the subtitles, the language for the sound, etc., using the DVD menu.

- 1 Press DVD MENU.
The DVD menu appears on the TV screen. The contents of the menu vary from disc to disc.
- 2 Press ◀/▶/◂/▸ to select the item you want to change.
Depending on the disc, you can use the number buttons to select the item.
- 3 To change other items, repeat Step 2.
- 4 Press ENTER.



To select the language for the DVD menu
Change the setting using "LANGUAGE SETUP" in the setup display. For details, see page 52.

Note

Depending on the DVD, a "DVD menu" may simply be called a "menu" in the instructions supplied with the disc.

Playing VIDEO CDs with PBC Functions (PBC Playback)

When playing VIDEO CDs with PBC functions (Ver. 2.0 discs), you can enjoy simple interactive operations, operations with search functions, etc. PBC Playback allows you to play VIDEO CDs interactively, following the menu screen on the TV screen. On this player, you can use the number buttons, ENTER, ◀, ▶, ◂, ▸ and RETURN during PBC Playback.



- 1 Start playing a VIDEO CD with PBC functions, following Steps 1 to 4 in "Playing Discs" on page 17.
- 2 Select the item number you want.
On the player
Press ◀/▶ to select the item number.
On the remote
Press the number button of the item you want.
- 3 Press ENTER.
- 4 Follow the instructions on the menu screen for interactive operations.
Refer to the instructions supplied with the disc, as the operating procedure may differ according to the VIDEO CD.

Going back to the menu screen

Press ◀, ▶, ◂, or ▸.

When playing VIDEO CDs with PBC functions
PBC playback starts automatically.

- To cancel PBC playback of a VIDEO CD with PBC functions and play the disc in Continuous Play mode there are two ways.
 - Before you start playing, select the track you want using ◀/▶, then press ENTER or ▷.
 - Before you start playing, select the track number using the number buttons on the remote, then press ENTER or ▷.
- "Play without PBC" appears on the TV screen and the player starts Continuous Play. You cannot play still pictures such as a menu screen.

To return to PBC playback, press ■ twice then press ▷.


Note

Depending on the VIDEO CD, "Press ENTER" in Step 3 may be expressed as "Press SELECT" in the instructions supplied with the disc.

Using the Front Panel Display


Display information while playing the disc

You can check information about the disc, such as the total number of the titles or the tracks or remaining time, using the front panel display.



When playing back a DVD

Display information while playing the disc



Checking the remaining time

Press TIME/TEXT.
Each time you press TIME/TEXT while playing the disc, the display changes as shown in the following chart.

22

23

Control Menu Item List

PAUSE (DVD/VIDEO CD only) (page 47)

You can display 9 consecutive sections of the disc on the screen. In this case, the sections show still images.

TITLE (DVD only) (page 48)

CHAPTER (DVD only) (page 48)

TRACK (VIDEO CD only) (page 48)

You can check the titles, chapters and tracks of the disc on the screen divided in 9 sections, and start playback from the chosen title, chapter or track.

PROGRAM (DVD/VIDEO CD only) (page 48)


You can have the player store specific portions of the disc in memory and play them immediately whenever you want without the need to search.

Using Various Functions with the Control Menu

Searching for the Title/Chapter/Track/Index/Scene


DVD **VIDEO** **CD**

You can search by selecting the title/chapter/track/index/scene.
Select "TITLE," "CHAPTER," "TRACK," "INDEX" or "SCENE" after pressing DISPLAY.
When you play back a DVD, "TITLE" and "CHAPTER" are displayed.
When you play back a VIDEO CD/CD, "TRACK" and "INDEX" are displayed. When you play back a VIDEO CD with PBC functions, "SCENE" is displayed.




1 Select "TITLE," "CHAPTER," "TRACK," "INDEX" or "SCENE" using \uparrow/\downarrow .

"***" is highlighted. (** means optional number in this manual.) Number in parentheses indicate the total number of titles, chapters, tracks, indexes or scenes.



2 Press \rightarrow or ENTER.

"***" is changed to "----" (**).



3 Select the number of the title, chapter, track, index or scene you want to search for using the number buttons, then press ENTER.

The player starts searching. To cancel the number, press CLEAR before pressing ENTER.

To cancel selecting
Press \rightarrow RETURN.

Notes

- The number of titles, chapters or tracks displayed is that of the titles, chapters or tracks recorded on a disc.
- The index numbers are not displayed during PBC playback of VIDEO CDs.


Checking the Playing Time and Remaining Time

DVD **VIDEO** **CD**

You can check the playing time and remaining time of the current title /chapter/track and the total remaining time of the disc.

Select "TIME/TEXT" or "TIME/MEMO" after pressing DISPLAY.

You can also check the DVD TEXT, CD TEXT and Disc Memo, and label the Disc Memo. See page 31.



When playing a DVD

TIME/TEXT or TIME/MEMO

- C ***:***: Playing time of the current chapter
- C -*:***: Remaining time of the current chapter
- T ***:***: Playing time of the current title
- T -*:***: Remaining time of the current title

When playing a VIDEO CD (during PBC playback)

TIME/MEMO

- *:***: Playing time of the current scene

When playing a VIDEO CD (in continuous play) or CD

TIME/TEXT or TIME/MEMO

- T ***:***: Playing time of the current track
- T -*:***: Remaining time of the current track
- D ***:***: Playing time of the current disc
- D -*:***: Remaining time of the current disc

You can display "TIME/TEXT" or "TIME/MEMO" display using the remote.

Press TIME/TEXT on the remote. Each time you press the button, the time information changes.

Using Various Functions with the Control Menu


Selecting a Start Point Using the Time Code

DVD


You can search by inputting the time code.

Select "TIME/TEXT" or "TIME/MEMO" after pressing DISPLAY.

The time code corresponds to the approximate actual playing time. For example, to search for a scene one hour past the beginning, input 1:00:00.




1 Select "C ***:***:" (playing time of the current chapter) when playing a DVD.



2 Press \rightarrow or ENTER.

Time code changes to "----" (**).



3 Input the time code using the number buttons, then press ENTER.

The player starts searching. To cancel the number, press CLEAR before pressing ENTER.

To cancel inputting

Press \rightarrow RETURN.

You can display "TIME/TEXT" or "TIME/MEMO" display using the remote.
Press TIME/TEXT on the remote.


Using Various Functions with the Control Menu

Checking the Information of the Disc

DVD **VIDEO** **CD**

You can check the DVD TEXT or CD TEXT of the disc on the TV screen and the front panel display. When the disc is a VIDEO CD or the DVD TEXT or CD TEXT is not recorded on the disc, you can label the disc as a Disc Memo and then check it.

DVD TEXT and CD TEXT are information recorded on the disc which you cannot change.
Select "TIME/TEXT" or "TIME/MEMO" after pressing DISPLAY. Then press TIME/TEXT on the remote until DVD/CD TEXT or Disc Memo is displayed.
The information is displayed at the bottom of the display.



You can display "TIME/TEXT" or "TIME/MEMO" display using the remote.

Press TIME/TEXT on the remote. To display DVD/CD TEXT or Disc Memo, press TIME/TEXT until DVD/CD TEXT or Disc Memo is displayed.

Note

The DVD TEXT only in English is displayed.


Labeling discs (Disc Memo)

When the disc is a VIDEO CD or the DVD TEXT or CD TEXT is not recorded on the disc, you can change the name of the disc by labeling it on the on-screen display and put a personal title on the disc. You can input up to 20 characters per disc each.

You can also have the player display the Disc Memo each time you select the disc. The Disc Memo can be anything you like, such as a title, musician's name, category or date of purchase.


1 Select "DISC MEMO INPUT" in "TIME/TEXT" or "TIME/MEMO"

The DISC MEMO INPUT display appears.



2 Select the character by pressing $\leftarrow/\rightarrow/\uparrow/\downarrow$ or by turning the disc shuttle.


The selected character changes color.




Using Various Functions with the Control Menu

Checking the Information of the Disc

- Press ENTER.
- If you selected a wrong character, press CLEAR.



- Repeat steps 2 and 3 to input other characters.
- When you have entered all the characters for the disc label, press INPUT on the remote. The disc label is stored.




To correct the characters

- You can erase the last character one by one by pressing CLEAR.
- To insert or overwrite the characters:
 - Move the cursor to the character you want to correct by pressing \leftarrow or \rightarrow .
 - Select the correct character by pressing \leftarrow or \rightarrow or by turning the click shuttle.
 - To insert the character, press ENTER. To overwrite, don't press ENTER but move the cursor by pressing \leftarrow or \rightarrow .

You can display the Disc Memo input display using the remote. Press INPUT on the remote.

Changing the Sounds

With DVDs recorded with multilingual sounds, you can select the language you want while playing the DVD. With multiples CDs or VIDEO CDs, you can select the sound from the right or left channel and listen to the sound of the selected channel through both the right and left speakers. In this case, the sound loses the stereo effect. For example, with a disc containing a song, the right channel may output the vocals and the left channel may output the instrumental. If you only want to hear the instrumental, you can select the left channel and hear it from both speakers.



■ AUDIO
When playing a DVD
Select the language. The languages you can select are different depending on the DVD. When 4 digits are displayed, they represent the language code. Select the language code from the list on page 72.


When playing a VIDEO CD or a CD
• STEREO (L/R): The standard stereo sound
• 1/L: The sound of the left channel (monaural)
• 2/R: The sound of the right channel (monaural)

You can display "AUDIO" display using the remote. Press AUDIO on the remote.

- Notes**
- Depending on the DVD, you may not be able to change the languages even if multilingual sounds are recorded on the DVD.
 - While playing the CD/VIDEO CD, the standard stereo playback will be resumed when:
 - you open or close the disc tray
 - you turn the power off
 - While playing the DVD, the sound may be changed when:
 - you open or close the disc tray
 - you change the title
 - If the language is displayed as a 4 digit number, refer to the language code list on page 72.


Displaying the audio information of the disc

When you select "AUDIO," the playing channels are displayed on the screen. In Dolby Digital (AC-3) format, the signals from monaural to 5.1 channels can be recorded on a DVD. Depending on the DVD the number of the recorded channels may be different.



* "PCM," "DTS," "DOLBY DIGITAL" or "MPEG" is displayed. In "DOLBY DIGITAL" case, the channels in the playing track are displayed by number as follows:

The case of Dolby Digital (AC-3) 5.1 ch:




The letters in the program format display mean the following:
L: Front (L)
R: Front (R)
C: Center (monaural)
LS: Rear (L)
RS: Rear (R)
S: Rear (monaural) - the rear component of the Dolby Surround processed stereo signal and the Dolby Digital signal.
LFE: LFE (Low Frequency Effects)

Changing the Sounds

The display examples are as follows:


• PCM (stereo)




• Dolby Surround



• Dolby Digital (AC-3) 5.1ch



• DTS



• MPEG




You can find Dolby Surround-encoded software by looking at the packaging. Use disc with the DOLBY SURROUND logo. In order to enjoy Dolby Digital (AC-3) playback, you must use disc bearing this logo.

Displaying the Subtitles

■ DVD

With DVDs on which subtitles are recorded, you can turn the subtitles on and off whenever you want while playing the DVD. With DVDs on which multilingual subtitles are recorded, you can change the subtitle language whenever you want while playing the DVD, and turn it on or off whenever you want. For example, you can select the language you want to master and turn the subtitles on for better understanding.

Select "SUBTITLE" after pressing DISPLAY.



■ SUBTITLE
Select the language. The languages you can select are different depending on the DVD. When 4 digits are displayed, they indicate the language code. Select the language code from the list on page 72.


You can display the "SUBTITLE" display by using the remote. Press SUBTITLE on the remote. Each time you press the button, the item changes.

- Notes**
- When playing a DVD on which no subtitles are recorded, no subtitles appear.
 - Depending on the DVD, you may not be able to turn the subtitles on even if they are recorded on it.
 - Depending on the DVD, you may not be able to turn the subtitles off.
 - If the language is displayed as a 4-digit number, refer to the language code list on page 72.
 - The type and number of languages for subtitles vary from disc to disc.
 - Depending on the DVD, you may not be able to change the subtitles even if multilingual subtitles are recorded on it.
 - While playing the DVD, the subtitle may change when:
 - you open or close the disc tray
 - you change the title


Changing the Angles

■ DVD


With DVDs on which various angles (multi-angles) for a scene are recorded, you can change the angles. For example, while playing a scene of a train in motion, you can display the view from either the front of the train, the left window of the train or from the right window without having the train's movement interrupted. Select "ANGLE" after pressing DISPLAY. When the angles can be changed, the indicator of the "ANGLE" lights in green.




1 Select "ANGLE."



2 Press \rightarrow



- Select the number of the angles using the number buttons or \leftarrow or \rightarrow , then press ENTER. The angle is changed to the selected angle.



Notes

- The number of angles varies from disc to disc or from scene to scene. The number of angles that can be changed on a scene is that of angles recorded for that scene.
- Depending on the DVD, you may not be able to change the angles even if multi-angles are recorded on the DVD.

You can specify the angle beforehand. Specify the angle when "ANGLE" is not displayed on the front panel display. When a scene on which multi-angles are recorded comes, the angle is automatically selected.

You can select the angle using the remote. Press ANGLE on the remote. Each time you press the button, the angle changes.

You can display different angles simultaneously (ANGLE VIEWER). You can display all the angles recorded on the disc on the same screen, and start playback in continuous mode from the chosen angle directly. The angles are displayed on a screen divided in 9 sections. For details, see page 47.

Setting for Digital Cinema Sound

Select the mode to enjoy multi channel surround sound such as Dolby Digital and MPEG.

Even if you connect only front speakers, Virtual Enhanced Surround lets you enjoy 3D sound by using 3D sound imaging to create virtual rear speakers from the sound of the front speakers (L, R) without using actual rear speakers.


When you connect 2 front speakers and 2 rear speakers, use 3D sound imaging to shift the sound of the rear speakers away from the actual speaker position (VIRTUAL REAR SHIFT) or to create 3 sets of virtual rear speakers from 1 set of actual rear speakers (VIRTUAL MULTI REAR).

You can feel the more effective 3D sound when you connect a receiver (amplifier) with 5.1 channel inputs, 2 front speakers, 2 rear speakers, 1 center speaker and 1 subwoofer.

Select "VIRTUAL 3D SURROUND" after pressing DISPLAY. When you select the item except "OFF," the indicator of the "VIRTUAL 3D SURROUND" lights in green.

Note

To enjoy the original Dolby Digital (AC-3) sound through the 5.1CH OUTPUT connectors, set each speaker position or distance, etc. For details on setting each speaker, see page 61.



VIRTUAL 3D SURROUND

Select the desired item. For details on each item, see "Effects of each item."

- OFF
- VES A*
- VES B*
- NORMAL SURROUND
- ENHANCED SURROUND
- VIRTUAL REAR SHIFT
- VIRTUAL MULTI REAR

* These settings also affect the output from the AUDIO OUT connector.

Note

The items displayed are different depending on the settings of "SPEAKER SETUP" (page 61).

- You can select only "OFF," "VES A" or "VES B" when you play back a DVD and set "NONE" in "REAR" in "SIZE" under "SPEAKER SETUP" in the set up display.
- "VIRTUAL 3D SURROUND" is not displayed when you play back a VIDEO CD or CD and set "NONE" in "REAR" in "SIZE" under "SPEAKER SETUP" in the set up display.

Effects of each item

OFF

Outputs all channel signals recorded on the disc. For example, outputs 2-channel signals for stereo sound of the CD or 5-channel signals for Dolby Digital sound of the DVD. When you connect fewer than 5 (+1) speakers, the player distributes the output signal for the missing speaker to other speakers appropriately.

VES (Virtual Enhanced Surround) A

Uses 3D sound imaging to create virtual rear speakers from the sound of the front speakers (L, R) without using actual rear speakers. The virtual speakers are reproduced as shown in the illustration below.



VES (Virtual Enhanced Surround) B

Uses 3D sound imaging to create virtual rear speakers from the sound of the front speakers (L, R) without using actual rear speakers. The virtual speakers are reproduced as shown in the illustration below.



NORMAL SURROUND


Software with 2 channel audio signals, is decoded with Dolby Pro Logic to create surround effects.

ENHANCED SURROUND

Provides a greater sense of presence from Pro Logic source with monaural rear channel sound. Produces a stereo like effect in the rear channels.


VIRTUAL REAR SHIFT

Uses 3D sound imaging to shift the sound of the rear speakers away from the actual speaker position. The virtual speakers are reproduced as shown in the illustration below. The shift position differs according to the setting of the rear speaker position.



VIRTUAL MULTI REAR

Uses 3D sound imaging to create an array of virtual rear speakers from a single pair of actual rear speakers. The virtual speakers are reproduced as shown in the illustration below. The position of the virtual rear speakers differs according to the setting of the rear speaker position.



* See page 61 for details on how to set the rear speaker position.

- L: Front speaker (left)
- R: Front speaker (right)
- SL: Rear speaker (left)
- SR: Rear speaker (right)
- : Virtual speaker

Notes


- Each item of "VIRTUAL 3D SURROUND" (except "NORMAL SURROUND" and "ENHANCED SURROUND") is effective on only discs on which a multi-channel sound track is recorded. Some discs do not have rear sound. In this case, you cannot get the 3D surround effect.
- When you select an item, the sound cuts off for a moment.
- When the playing signal does not contain the surround component, the effects may be difficult to hear even if you select "VES A" or "VES B."
- If you connect the front speakers only, "NORMAL SURROUND," "ENHANCED SURROUND," "VIRTUAL REAR SHIFT" and "VIRTUAL MULTI REAR" cannot be selected.
- The sound does not come from the rear speakers when you set "VIRTUAL 3D SURROUND" to "VES A" or "VES B" in the Control Menu display even if you have connected rear speakers.
- Set the front speakers to form an equilateral triangle including the listening position, or the effects may be difficult to hear even if you select "VES A" or "VES B."
- When you select "VES A" or "VES B," the player outputs the audio signal from AUDIO OUT, DIGITAL OUT (OPTICAL, COAXIAL) or 5.1CH OUTPUT FRONT connectors. In case of the signal from DIGITAL OUT (OPTICAL, COAXIAL), however, the surround effect will be heard only when you play DVD or VIDEO CD with "DOLBY DIGITAL" set to "D-PCM," and "MPEG" to "PCM" in "AUDIO SETUP."
- When you play sound tracks with 96 kHz sampling frequency, be sure to select "OFF," or the output signals will be converted to 48 kHz (sampling frequency).
- When you connect a center speaker and a subwoofer, you can also hear the sound from the center speaker and the subwoofer. When you select "VES A" or "VES B," the player does not output the sound from the center speaker.

You can select the item of "VIRTUAL 3D SURROUND" using this button. Press VIRTUAL 3D SURROUND on the player. Each time you press the button, the item changes.

Creating Your Own Program (Program Play)

You can play the contents of the disc in the order you want by arranging the order of the titles, chapters or tracks on the disc and create your own program. One program can be created in the player and contain up to 99 titles, chapters and tracks.

Select "PROGRAM" after pressing DISPLAY. When you select "ON," the indicator of the "PROGRAM" lights in green.



PROGRAM


- OFF plays normal.
- SET- allows you to create your own program.
- ON: plays Program Play.

Creating the program

1 Select "SET" in "PROGRAM".


The programming display appears.

"TRACK" is displayed when you play a VIDEO CD or a CD.



2 Press SET.



"01" is highlighted. It is ready to set the first title or track for program.




3 Select the title, chapter or track you want to program using 1/4, then press ENTER.

For example, select title or track 2. (You can also use the number buttons and ENTER button to select. In this case, the selected number is displayed on the screen.)

When both titles and chapters are recorded on the disc, select the title, then the chapter.



When playing a VIDEO CD or CD, Select the track you want to program.



To cancel the programmed order, select "ALL CLEAR" in Step 2. To cancel the selected program, select the program using 1/4 in Step 2 then press CLEAR, or select "-" in Step 3 then press ENTER.

The program remains even after the Program Play ends. When you press ON, you can play the same program again.

You can do Repeat Play or Shuffle Play of the programmed titles, chapters or tracks. During Program Play, press REPEAT or SHUFFLE. Or set "REPEAT" or "SHUFFLE" to "ON" in the Control Menu display.

You can display "PROGRAM" display using the remote Press PROGRAM.

To cancel the programmed order

To cancel all the titles, chapters or tracks in the programmed order, select "ALL CLEAR" in Step 2. To cancel the selected program, select the program using 1/4 in Step 2 then press CLEAR, or select "-" in Step 3 then press ENTER.

The program remains even after the Program Play ends. When you press ON, you can play the same program again.

You can do Repeat Play or Shuffle Play of the programmed titles, chapters or tracks. During Program Play, press REPEAT or SHUFFLE. Or set "REPEAT" or "SHUFFLE" to "ON" in the Control Menu display.

You can display "PROGRAM" display using the remote Press PROGRAM.

Notes

- The number of titles, chapters or tracks displayed are that of the titles, chapters or tracks recorded on a disc.
- The program is controlled when:
 - you open or close the disc tray
 - you turn the power off
- You may not be able to do Program Play depending on the DVD.
- While you are doing PBC playback, you cannot set a program unless you stop playback once.

4 To program other titles, chapters or tracks, repeat Step 3.

The programmed titles, chapters or tracks are displayed from 2 in order.

5 Press ON to start Program Play.

To cancel Program Play

Press CLEAR.

To cancel programming

Press PROGRAM.


To change programming

- 1 In Step 2, select the program number of the title, chapter or track you want to change using 1/4.
- 2 Follow Step 3 for new programming.

Playing in Random Order (Shuffle Play)

You can have the player "shuffle" titles or tracks and play them in a random order. The playing order may differ from the previous "shuffling."

Select "SHUFFLE" after pressing DISPLAY. When you select "ON", the indicator of the "SHUFFLE" lights in green.



SHUFFLE
Selects the setting of Shuffle Play.

When playing a DVD and when Program Play is set to OFF

- OFF: does not play a disc in random order.
- TITLE: has the player "shuffle" titles and play in a random order.
- CHAPTER: has the player "shuffle" chapters and play in a random order.

When playing a VIDEO CD, CD or DVD (when Program Play is set to ON)

- OFF: does not play a disc in random order.
- ON: has the player "shuffle" titles or tracks and play in a random order.

When playing a VIDEO CD or CD (when Program Play is set to OFF)

- OFF: does not play a disc in random order.
- TRACK: has the player "shuffle" tracks and play in a random order.

After selecting the item of "SHUFFLE", press **ENTER**.
The player starts Shuffle Play.

To cancel Shuffle Play
Press CLEAR.

You can display the "SHUFFLE" display by pressing the button
Press SHUFFLE.

Notes

- Shuffle Play is canceled when:
 - you open or close the disc tray
 - you turn the power off
- You may not be able to do Shuffle Play depending on the DVD.
- Up to 200 chapters in a disc can be played in a random order when "CHAPTER" is selected.

Playing Repeatedly (Repeat Play)


You can play all the titles/tracks on a disc or a single title/chapter/track.

In Shuffle or Program Play mode, the player repeats the titles or tracks in the shuffled or programmed order.

You cannot do Repeat Play during PBC playback of VIDEO CDs (page 22).

You may not be able to do Repeat Play depending on the DVD.

Select "REPEAT" after pressing DISPLAY. When you do not select "OFF" the indicator of the "REPEAT" lights in green.



REPEAT

Selects the setting of Repeat Play.

When playing a DVD and when Program Play and Shuffle Play are set to OFF

- OFF: does not play repeatedly.
- DISC: repeats all the titles.
- TITLE: repeats the current title on a disc.
- CHAPTER: repeats the current chapter.

When playing a VIDEO CD/CD and when Program Play and Shuffle Play are set to OFF

- OFF: does not play repeatedly.
- DISC: repeats all the tracks on a disc.
- TRACK: repeats the current track.

When Program Play or Shuffle Play is set to ON

- OFF: does not play repeatedly.
- ON: repeats Program Play or Shuffle Play.

To cancel Repeat Play
Press CLEAR.

You can display the "REPEAT" display by pressing the button
Press REPEAT.

Note


Repeat play is canceled when you turn the power off.

Repeating a Specific Portion (A→B Repeat)

You can play a specific portion of a title, chapter, track repeatedly. This is useful when you want to memorize lyrics.

During PBC Playback of VIDEO CDs (page 22), this function is available only while playing moving pictures. You may not be able to do A→B Repeat Play depending on the DVD.

Select "A-B REPEAT" after pressing DISPLAY. During A→B Repeat Play, the indicator of the "A-B REPEAT" lights in green.





A-B REPEAT

- SET: sets the A and B points.
- OFF: does not play a specific portion of a title/chapter/track repeatedly.


Repeating a Specific Portion (A→B Repeat)

Setting a portion for A→B Repeat

- Select "SET" in "A-B REPEAT."
The A→B REPEAT setting display appears.




- During playback, when you find the starting point (point A) of the portion to be played repeatedly, press ENTER.
The starting point (point A) is set.



- When you reach the ending point (point B), press ENTER again.
The setting points are displayed and the player starts repeating this specific portion.

"A-B" appears on the front panel display during A→B repeat play.



To cancel A→B Repeat Play
Press CLEAR.

Notes

- You can set A→B Repeat on only one specific portion.
- A→B Repeat is canceled when:
 - you open or close the disc tray
 - you turn the power off
- When you set A→B Repeat, the settings for Shuffle Play and Program Play are canceled.
- You may not be able to set A→B Repeat, depending on the scene of the DVD or the VIDEO CD.

Checking the Play Information

You can check the play information on the bit rate, bit rate history or the portion where the disc is played (layer).

While playing a disc, the approximate bit rate of the playback picture is always displayed by Mbps (Mega bit per second) and the audio by Kbps (Kilo bit per second). Select "ADVANCED" after pressing DISPLAY.




ADVANCED

When playing a DVD


- BIT RATE: displays bit rate.
- BIT RATE HISTORY: displays bit rate and bit rate history.
- LAYER: displays layer and the point picked up.
- OFF: turns off ADVANCED display.

Displays of each item

BIT RATE




When you play MPEG AUDIO sound tracks



Bit rate refers to the amount of video/audio data per second in a disc. The higher the bit rate is, the larger the amount of data. When the bit rate level is high, there is a large amount of data. However, this does not always mean that you can get higher quality pictures or sounds.

BIT RATE HISTORY



Indicates the transition of bit rate of the playback picture for a period up to the present.

Checking the Play Information

LAYER




Indicates where the disc is played. When the DVD has dual-layer, the player indicates which layer is being read. For details on layer, see page 70.

Using Various Functions with the Control Menu

44

Reducing the Picture Noise (DNR: Digital Video Noise Reduction)

You can make the picture clearer by reducing the picture noise of the background. Select "DNR" after pressing DISPLAY. When you select "DNR1," "DNR2," or "DNR3," the indicator of the "DNR" lights in green.



DNR
As the value increases, the picture noise will be reduced. However, afterimages may increase.

- OFF: turns off the DNR function
- DNR1
- DNR2
- DNR3


Notes

- Depending on the disc, the effect may be difficult to tell.
- If the afterimages appear on the TV screen, set the noise reduction function to off on your TV. Then set "DNR" to "OFF" on the Control Menu display.

Adjustments for Playback Picture (VIDEO EQ: Video Equalizer)

You can adjust the video output of the DVD or VIDEO CD from the player, not from the TV, to obtain the picture quality you want. Choose one of the video modes whichever best suits the program you are watching. When you select "MEMORY" in a menu item, adjust the value.

Select "VIDEO EQ" after pressing DISPLAY.



VIDEO EQ

Selects the setting of video control.

- STANDARD: displays a standard picture
- DYNAMIC: emphasizes the black level and to produces a bolder dynamic picture
- CINEMA: displays a finely detailed picture
- MEMORY: adjusts the picture items

To adjust the picture items

You can adjust the following picture items individually.

- PICTURE
- BRIGHTNESS
- COLOR
- SHARPNESS



Using Various Functions with the Control Menu

45


Adjustments for Playback Picture (VIDEO EQ: Video Equalizer)

- 1 Select "MEMORY" in "VIDEO EQ."

The video control display appears.



- 2 Select the picture item you want to adjust using \uparrow/\downarrow , then press ENTER. The adjustment bar of the selected item appears. To cancel adjusting the picture halfway, press \rightarrow RETURN.



- 3 Adjust the selected picture item using \leftarrow/\rightarrow , then press ENTER.




Using Various Functions with the Control Menu

46

Displaying Different Angles Simultaneously

With DVDs on which various angles (multi-angles) for a scene are recorded, you can display all the angles recorded on the disc on the same screen, and start playback in continuous mode at the chosen angle directly. The angles are displayed on a screen divided in 9 sections. Select "ANGLE VIEWER" after pressing DISPLAY. When you can select "ANGLE VIEWER," the indicator of the "ANGLE VIEWER" lights in green.



To select the one angle
Select the angle using \leftarrow/\rightarrow , then press ENTER. The selected angle only is displayed.

To cancel displaying multi-angles
Press \rightarrow RETURN.


You can check the number on the front panel display. The number of the angle you select is displayed on the front panel display.

Notes

- Depending on the DVD, you may not be able to change the angles even if multi-angles are recorded on the DVD.
- When a scene for which various angles (multi-angles) are not recorded comes while displaying different angles simultaneously, the player returns to the normal play.

Dividing a Track into 9 Sections (Strobe Play)

You can display 9 consecutive sections of the disc on the screen. In this case, the sections show still images. Select "STROBE PLAYBACK" after pressing DISPLAY.



To cancel watching the strobe play
Press \rightarrow RETURN.

During pause mode, 9 still images around the pause position are displayed. It is convenient to see the still images around the specific portion.

Notes

Depending on the disc, there are some scenes you may not be able to watch with the strobe play.


Using Various Functions with the Control Menu

47

Scanning the Title, Chapter and Track


You can check the top picture of titles, chapters and tracks of the disc on a screen divided in 9 sections, and start playback from the chosen title, chapter or track.

Select "TITLE VIEWER" (DVD only), "CHAPTER VIEWER" (DVD only) or "TRACK VIEWER" (VIDEO CD only) after pressing DISPLAY.



To start playback from the selected picture
Select the picture using \leftarrow/\rightarrow , then press ENTER. The playback starts from the selected picture.

When there are over 9 titles or chapters, ∇ appears at the right bottom of the screen. Use ∇ to scroll and display next titles or chapters.



You can check the number on the front panel display. The number of the title, chapter and track you select is displayed on the front panel display.

To cancel scanning the title, chapter and track
Press ∇ RETURN.


Notes

- Depending on the disc, you may not be able to scan the title, chapter and track.
- You cannot scan the title, chapter and track on a VIDEO CD during PIC playback.

Setting and Selecting Favorite Scene (Bookmark)

You can have the player store specific portions of the disc in memory and play them immediately whenever you want without the need to search (Bookmark). Up to 9 bookmarks per disc for up to 200 discs can be stored in memory.

Select "BOOKMARK" after pressing DISPLAY. When you play the disc which has bookmarks, the indicator of the "BOOKMARK" lights in green.



To start playback from the selected picture
Select the picture using \leftarrow/\rightarrow , then press ENTER. The playback starts from the selected picture.

To cancel scanning the bookmark pictures
Press ∇ RETURN.

To reset the bookmark
Select the point on which you want to reset the bookmark using \leftarrow/\rightarrow , then press CLEAR.

To reset the all bookmarks of the player
Select "BOOKMARK RESET" under the "CUSTOM SETUP" in the setup display. For details on resetting all the bookmark of the player, see page 55.

Setting the bookmark

During playback, when you find the scene to be bookmarked, press BOOK MARK on the remote.



Settings and Adjustments

This chapter describes how to set and how to adjust using the on-screen SET UP menu. Most settings and adjustments are required to be set when you first use the player.


This chapter also describes how to set the remote for controlling the TV or the AV receiver (amplifier).

Using the Setup Display

Using the setup display, you can do the initial setup, adjusting the picture and sound quality, setting the various outputs, etc. You can also set a language for the subtitles and the setup display, limit playback by children, etc.

For details on each setup display item, see pages 52 to 64.

Note
You can display the setup display only when the player is in stop mode.





1 Press SET UP to display the setup display on the TV screen.





Using the Setup Display


2 Select the main item you want using \leftarrow/\rightarrow , and then press ENTER.
The selected main item is highlighted.



3 Select the item you want using \leftarrow/\rightarrow , then press \rightarrow or ENTER.



4 Select the setting you want using \leftarrow/\rightarrow , then press ENTER.



To cancel using the setup display on the way
Press SET UP on the remote.

Note
Some setup display items require operations other than selecting the setting. For details on these items, see the relevant pages.

Setup Display Item List

Default settings are underlined.

LANGUAGE SETUP (page 52)	<ul style="list-style-type: none"> OSD — <u>ENGLISH</u> — FRANÇAIS — DEUTSCH — ITALIANO — ESPAÑOL — NEDERLANDS — DANSK — SVENSKA — SUOMI — NORSK — PORTUGUÊS
DVD MENU	<ul style="list-style-type: none"> — <u>ENGLISH</u> — FRANÇAIS — DEUTSCH — ITALIANO — ESPAÑOL — NEDERLANDS — DANSK — SVENSKA — SUOMI — NORSK — PORTUGUÊS — PYCCOPIE — CHINESE — JAPANESE — OTHERS
AUDIO	— <u>ORIGINAL</u> (same as DVD MENU)
SUBTITLE	— <u>AUDIO FOLLOW</u> (same as DVD MENU)

SCREEN SETUP (page 53)	<ul style="list-style-type: none"> TV TYPE — <u>16:9</u> — 4:3 LETTER BOX — 4:3 PAN SCAN
SCREEN SAVER	— <u>ON</u> — OFF
BACKGROUND	— <u>WIDE PICTURE</u> — PICTURE MEMORY — GRAPHICS — BLUE — BLACK
STARTUP SCREEN	— <u>STANDARD</u> — PICTURE MEMORY

CUSTOM SETUP (page 54)	<ul style="list-style-type: none"> COMPONENT OUT — <u>OFF</u> — ON
EURO AV OUT	— <u>VIDEO</u> — S VIDEO — RGB
AUTO PLAY	— <u>OFF</u> — ON
TIMER	— <u>DEMO1</u> — DEMO2
DIMMER	— <u>BRIGHT</u> — DARK
PAUSE MODE	— <u>OFF</u> — FRAME
BOOKMARK RESET	— <u>ON</u> — OFF
PARENTAL CONTROL	— <u>ON</u> — OFF
PLAYBACK MEMORY	— <u>ON</u> — OFF


AUDIO SETUP (page 58)	<ul style="list-style-type: none"> AUDIO ATT — <u>OFF</u> — ON
AUDIO FILTER	— <u>SHARP</u> — SLOW
AUDIO DRC	— <u>STANDARD</u> — TV MODE — WIDE RANGE
TRACK SELECTION	— <u>OFF</u> — AUTO
DOWN MIX	— <u>DOLBY SURROUND</u> — NORMAL
DIGITAL OUT	— <u>ON</u> — OFF
DOLBY DIGITAL	— <u>ON</u> — OFF
MPEG	— <u>ON</u> — OFF

SPEAKER SETUP (page 51)	<ul style="list-style-type: none"> SIZE — <u>FRONT</u> — CENTER — REAR — SUBWOOFER
DISTANCE	— <u>FRONT</u> — CENTER — REAR
BALANCE	— <u>FRONT</u> — REAR
LEVEL	— <u>CENTER</u> — REAR — SUBWOOFER
TEST TONE	— <u>ON</u> — OFF

Setting the Language for Display and Sound (LANGUAGE SETUP)

Select "LANGUAGE SETUP" after pressing SET UP.
"LANGUAGE SETUP" allows you to set various languages for on-screen display or sound.
Default settings are underlined.

Note
When you select a language that is not recorded on the DVD, one of the recorded languages is automatically selected except for the "OSD".



■OSD (On-Screen Display)

Switches the language for the on-screen display.

- ENGLISH (ENGLISH)
- FRANÇAIS (FRENCH)
- DEUTSCH (GERMAN)
- ITALIANO (ITALIAN)
- ESPAÑOL (SPANISH)
- NEDERLANDS (DUTCH)
- DANSK (DANISH)
- SVENSKA (SWEDISH)
- SUOMI (FINNISH)
- NORSK (NORWEGIAN)
- PORTUGUÊS (PORTUGUESE)

■DVD MENU

Switches the language for the DVD menu.

- ENGLISH (ENGLISH)
- FRANÇAIS (FRENCH)
- DEUTSCH (GERMAN)
- ITALIANO (ITALIAN)
- ESPAÑOL (SPANISH)
- NEDERLANDS (DUTCH)
- DANSK (DANISH)
- SVENSKA (SWEDISH)
- SUOMI (FINNISH)
- NORSK (NORWEGIAN)
- PORTUGUÊS (PORTUGUESE)
- РУССКИЙ (RUSSIAN)
- ЧИНСКИЙ (CHINESE)
- JAPANESE (JAPANESE)

When you select "OTHERS" select and enter the language code from the list using the number buttons (page 72). After you have once selected, the language code (4 digits) is displayed.

■AUDIO

Switches the language for the sounds.

- ORIGINAL (the language given priority in the disc)
- ENGLISH (ENGLISH)
- FRANÇAIS (FRENCH)
- DEUTSCH (GERMAN)
- ITALIANO (ITALIAN)
- ESPAÑOL (SPANISH)
- NEDERLANDS (DUTCH)
- DANSK (DANISH)
- SVENSKA (SWEDISH)
- SUOMI (FINNISH)
- NORSK (NORWEGIAN)
- PORTUGUÊS (PORTUGUESE)
- РУССКИЙ (RUSSIAN)
- ЧИНСКИЙ (CHINESE)
- JAPANESE (JAPANESE)

■OTHERS

When you select "OTHERS" select and enter the language code from the list using the number buttons (page 72). After you have once selected, the language code (4 digits) is displayed.

■SUBTITLE

Switches the language for the subtitles.

- AUDIO FOLLOW
- ENGLISH (ENGLISH)
- FRANÇAIS (FRENCH)
- DEUTSCH (GERMAN)
- ITALIANO (ITALIAN)
- ESPAÑOL (SPANISH)
- NEDERLANDS (DUTCH)
- DANSK (DANISH)
- SVENSKA (SWEDISH)
- SUOMI (FINNISH)
- NORSK (NORWEGIAN)
- PORTUGUÊS (PORTUGUESE)
- РУССКИЙ (RUSSIAN)
- ЧИНСКИЙ (CHINESE)
- JAPANESE (JAPANESE)

■OTHERS

When you select "OTHERS" select and enter the language code from the list using the number buttons (page 72). After you have once selected, the language code (4 digits) is displayed.

When you select "AUDIO FOLLOW," the language for the subtitles changes according to the language for the setting you selected in "AUDIO."


Note

The player gives priority to the settings of "SUBTITLE" and "AUDIO" in the Control Menu display when "PLAYBACK MEMORY" is set to "ON." The settings of "SUBTITLE" and "AUDIO" selected in the setup display may not appear in this case. For details on the Playback Memory function, see page 55.

Settings for Display (SCREEN SETUP)

Select "SCREEN SETUP" after pressing SET UP.

"SCREEN SETUP" allows you to set the display according to the playback conditions.
Default settings are underlined.



■TV TYPE

Selects the aspect ratio of the TV to be connected.

- 16:9 when you connect a wide-screen TV to the player.
- 4:3 LETTER BOX: when you connect a normal TV to the player. Displays a wide picture with bands displayed on the upper and lower portions of the screen.
- 4:3 PAN SCAN: when you connect a normal TV to the player. Displays the wide picture on the whole screen with a portion automatically cut off.

16:9



4:3 LETTER BOX



4:3 PAN SCAN



Note

Depending on the DVD, "4:3 LETTER BOX" may be selected automatically instead of "4:3 PAN SCAN" and vice versa.

■SCREEN SAVER

Turns on and off the screen saver. If you turn on the screen saver, the screen saver image appears when you leave the player or the remote in pause or stop mode for 15 minutes or when you play back a CD for more than 15 minutes. The screen saver is useful to prevent your display from becoming damaged.

- ON: turns on the screen saver.
- OFF: turns off the screen saver.

■BACKGROUND

Selects the background color or picture of the TV screen in stop mode or while playing a CD.

- JACKET PICTURE: The jacket picture appears in the background, but only when the jacket picture is already recorded on the disc.
- PICTURE MEMORY: Your favorite picture appears in the background when you have the player store in memory your favorite scene recorded on the disc for the background picture. For the way of storing in memory, see "Storing the picture in memory."
- GRAPHICS: The graphic picture stored in memory in the player beforehand appears in the background.
- BLUE: The background color is blue.
- BLACK: The background color is black.

■STARTUP SCREEN

Selects the startup screen. The startup screen image you selected appears when you turn on the player.

- STANDARD: The standard startup screen memorized in the player beforehand appears.
- PICTURE MEMORY: Your favorite picture appears in the startup screen when you have the player store in memory your favorite scene recorded on the disc for the startup screen. For the way of storing in memory, see "Storing the picture in memory" (page 54).

Settings for Display (SCREEN SETUP)

Storing the picture in memory

During playback, when you find the scene to be stored in memory, press PICTURE MEMORY on the remote.
The picture is stored in memory.




Notes

- The player can store in memory only one scene. The stored picture appears in both the background and the startup screen.
- When the picture is stored in memory by pressing PICTURE MEMORY, the picture stored before is not retained in memory.
- When you operate this player during storing picture in memory, the picture does not be stored in memory.

Custom Settings (CUSTOM SETUP)

Select "CUSTOM SETUP" after pressing SET UP.
"CUSTOM SETUP" allows you to set the playback conditions.
Default settings are underlined.



■COMPONENT OUT

Selects the method of outputting video signals from the COMPONENT VIDEO OUT (Y, Cb/Y, Cr/Y) connectors on the rear panel of the player.

- When you select "ON," you need to connect the monitor or projector via EURO AV, VIDEO OUT or S VIDEO OUT beforehand.
- OFF: outputs no signals.
- ON: outputs the component video signals.

Notes

- When you set "EURO AV OUT" to "RGB," you cannot set "COMPONENT OUT" to "ON."
- When you connect the player to a monitor or projector via only the COMPONENT VIDEO OUT connectors, do not select "OFF." If you select "OFF" in this case, the picture may not appear.

■EURO AV OUT

Selects the methods of outputting video signals from the EURO AV 1 (RGB)-TV connectors on the rear panel of the player.

- VIDEO: outputs the video signals.
- S VIDEO: outputs the S video signals.
- RGB: outputs the RGB signals.

Notes

- When you set "COMPONENT OUT" to "ON," you cannot set "EURO AV OUT" to "RGB."
- If your TV is not conforming to the S video or the RGB signals, no picture appears on the TV screen even if you select "S VIDEO" or "RGB." Refer to the instructions supplied with your TV.
- If your TV has only one EURO AV IN connector, do not select "S VIDEO."

■AUTO PLAY

Selects the setting of Auto Play when you connect the AC power cord to the AC outlet.

- OFF: does not use "TIMER," "DEMO1" or "DEMO2" to start playing.

- TIMER: starts playing a disc automatically when you connect the AC power cord to the AC outlet. By connecting a timer (not supplied), you can start playing at any time you want.
- DEMO1: starts playing the demonstration 1 automatically.
- DEMO2: starts playing the demonstration 2 automatically.

■DIMMER

Adjusts the lighting of the front panel display.

- BRIGHT: makes the front panel display bright.
- DARK: makes the front panel display dark.
- OFF: turns off the lighting of the front panel display.

■PAUSE MODE

Selects the picture in pause mode.

- AUDIO: A picture including subjects that move dynamically is output with no jitter. Normally select this position.
- FRAME: A picture including subjects that do not move dynamically is output with high resolution.

■BOOKMARK RESET

Select "BOOKMARK RESET" The BOOKMARK reset display appears. And then press ENTER to reset all bookmarks.

■PARENTAL CONTROL

Sets a password and playback limitation level when you play DVDs with playback limitation for children. For details, see "Limiting Playback by Children (Parental Control)."

■PLAYBACK MEMORY

You can have the player store the settings of SUBTITLE and VIDEO EQ, etc. of each disc up to 200 discs (Playback Memory).

- Set the Playback Memory function on or off.
- ON: stores the settings in memory when you eject the disc.
- OFF: does not store the settings in memory.

Following settings are stored in memory with the Playback Memory function.

- AUDIO (page 33)
- SUBTITLE (page 34)
- ANGLE (page 35)
- VIRTUAL 3D SURROUND (page 36)
- VIDEO EQ (page 45)
- DNR (page 45)


Note

The player can store in memory the settings of up to 200 discs. When you have the player store over 200 discs in memory, each new setting erases the setting from those first stored.


Limiting Playback by Children (Parental Control)

Select "CUSTOM SETUP" after pressing SET UP.


Playing some DVDs can be limited depending on the age of users. The "Parental Control" function allows you to set a playback limitation level.




1 Select "PARENTAL CONTROL" using \uparrow/\downarrow , then press ENTER.



■When you have not entered a password yet.
The display for entering a password appears.




■When you have already entered a password
The display for confirming the password appears. Skip Step 2.




Custom Settings (CUSTOM SETUP)


- Enter a password in 4 digits using the number buttons, then press ENTER. The digits change to asterisks (*), and the display for confirming the password appears.



- To confirm your password, enter it using the number buttons, then press ENTER. The display for setting the playback limitation level and changing the password appears.



- Select "STANDARD" using \uparrow/\downarrow , then press \rightarrow .



- Select an area as the standard for playback limitation level using \uparrow/\downarrow , then press \rightarrow . When you select "OTHERS", select and enter the standard code in the table below using number buttons.



- Select "LEVEL" using \uparrow/\downarrow , then press \rightarrow .



- Select the level you want using \uparrow/\downarrow , then press ENTER.



The lower the value is, the more strict the limitation.

To return to the normal screen
Press SET UP.

To turn off the Parental Control function and play the DVD after entering your password
Set "LEVEL" to "OFF" in Step 7, then press \rightarrow .

To change the password

- After Step 3, select "CHANGE PASSWORD" using \uparrow/\downarrow , then press \rightarrow or ENTER. The display for changing the password appears.
- Follow Steps 2 and 3 to enter a new password.

You can turn off the Parental Control function just after inserting the DVD (Parental Control temporarily Canceled). When you set a playback limitation level and insert the DVD, the PARENTAL CONTROL display appears. Enter the password to turn off the Parental Control function. When you stop playing the DVD, the level returns to the original level.

If you have forgot your password
Enter the 6-digit number "199703" in Step 2 to clear the current password. To enter a new password, follow the procedure from Step 2 again.

Notes

- When you play DVDs which do not have the Parental Control function, playback cannot be limited on this player.
- When you do not set a password, you cannot change the settings for playback limitation.
- Depending on the DVD, you may be asked to change the parental control level while playing the disc. In this case, enter the password, then change the level. When you stop playing the DVD, the level returns to the original level.


Standard	Code number
Austria	2046
Belgium	2087
Catala	2079
China	2092
Denmark	2115
Finland	2165
France	2174
Germany	2109
Hong Kong	2219
Indonesia	2238
Italy	2254
Japan	2276
Malaysia	2363
Netherlands	2375
Norway	2379
Philippines	2424
Russian	2489
Singapore	2501
Spain	2149
Sweden	2499
Switzerland	2086
Taiwan	2543
Thailand	2528
United Kingdom	2184

56

57

Settings for Sound (AUDIO SETUP)

Select "AUDIO SETUP" after pressing SET UP.
"AUDIO SETUP" allows you to set the sound according to the playback conditions.
Default settings are underlined.



AUDIO ATT (attenuation)

- Selects the setting of the output from the AUDIO OUT, EURO AV (1,2) and 5.1 OUTPUT connectors according to the audio equipment to be connected.
- OFF**: turns off the audio attenuation.
- ON**: reduces the audio output level so that no sound distortion occurs.

Note

The setting does not affect the output from the DIGITAL OUT OPTICAL and COAXIAL connectors.

AUDIO FILTER

- Selects the type of digital filter to reduce the noise of a frequency higher than 22.05kHz (fs 44.1kHz), 24kHz (fs 48kHz) or 48kHz (fs 96kHz).
- SHARP**: makes the sound clear and provides smooth sound reproduction. Normally set this position.
- SLOW**: makes the sound warm and deep.

Note

Depending on the disc, the effect on the sound may be difficult to hear.

AUDIO DRC (Dynamic Range Control)

- Makes the sound clear with the volume turned down at night, etc., when you play a DVD. This affects the output from the DIGITAL OUT connectors only when "PCM" in "DIGITAL OUT" is set to "ON," and it affects the output from the AUDIO OUT, EURO AV (1,2) and 5.1CH OUTPUT connectors.
- STANDARD**: Normally select this position.
- TV MODE**: makes the low sound clear even if you turned the volume down, so it is good for playing at night. It is especially recommended when you listen to the sound using the speakers of the TV.
- WIDE RANGE**: It gives you the feeling of being at a live performance. When you use high quality speakers, it is more effective.

Notes

- When you play DVDs without the AUDIO DRC function, the effect on the sound may be difficult to hear.
- When this item is set to "WIDE RANGE," the sound volume from other than the 5.1CH OUTPUT connectors may be less than usual.
- "WIDE RANGE" cannot be selected when you have selected "NONE" in "SIZE" under "SPEAKER SETUP."

TRACK SELECTION

- Gives the sound track which contains the highest number of the channels priority when you play a DVD on which multiple audio formats are recorded. If multiple audio channels are recorded in PCM, DTS, MPEG AUDIO or Dolby Digital (AC-3) format, the higher-numbered channel audio recorded in PCM, DTS, MPEG AUDIO or Dolby Digital (AC-3) format is played.
- OFF**: No priority given.
- AUTO**: Priority given.

Notes

- When the player stores the settings in memory with the "Playback Memory" function, the player may not give priority even if you select "AUTO."
- When you set this item to "AUTO," the language may change depending on the "AUDIO" settings in "LANGUAGE SETUP." The "TRACK SELECTION" setting has higher priority than that of "AUDIO" settings in "LANGUAGE SETUP" (page 52).
- If you set "DTS" in "AUDIO SETUP" to "OFF," the DTS sound track is not played even if you set this item to "AUTO" and the highest-numbered channel audio is recorded in DTS format.
- If PCM, DTS, MPEG AUDIO and Dolby Digital (AC-3) sound tracks have the same number of the highest channels, the player selects PCM, DTS, Dolby Digital (AC-3) and MPEG AUDIO sound tracks, in this order.
- Depending on the DVD, the audio with priority may be predetermined. In this case, you cannot give priority to the DTS, MPEG AUDIO or Dolby Digital (AC-3) format by selecting "AUTO."

DOWN MIX*

Switches the mixing down methods when you play a DVD on which the sound in Dolby Digital (AC-3) format is recorded.

- DOLBY SURROUND**: when the player is connected to an audio component that conforms to Dolby surround (Pro Logic).
- NORMAL**: when the player is connected to a normal audio component.

- The setting affects the following connectors:
- AUDIO OUT connector
- DIGITAL OUT (OPTICAL, COAXIAL) connectors.

DIGITAL OUT

Selects output signals via the DIGITAL OUT OPTICAL and COAXIAL connectors.


- ON**: Normally select this position. When you select "ON," set "DOLBY DIGITAL," "MPEG" and "DTS."
- For details on setting them, see "Setting for the Signal to the Digital Output."
- OFF**: when the player does not output the sound signals via DIGITAL OUT OPTICAL and COAXIAL connectors, if you select this position, the influence of the digital circuit upon the analog one is minimum.

Notes

- When you play the sound tracks with 96 kHz sampling frequency, the output signals from the DIGITAL OUT (OPTICAL, COAXIAL) are converted to 48 kHz (sampling frequency). Sampling Frequency stays at 48kHz only when the signals are output from AUDIO OUT connector.
- When you select "OFF," you cannot set "DOLBY DIGITAL," "MPEG" and "DTS."

Setting for the Signal to the Digital Output

When you select "ON," set "DOLBY DIGITAL," "MPEG" and "DTS."
Switches the methods of outputting audio signals when you connect a digital component such as a receiver (amplifier) having a digital connector, an audio component having a built-in DTS decoder, a DAT or MD via the DIGITAL OUT OPTICAL or COAXIAL connector using an optical or coaxial digital connecting cord. For details on the connection, see page 13.



DOLBY DIGITAL

Selects output Dolby Digital (AC-3) signals via the DIGITAL OUT OPTICAL and COAXIAL connectors. You must select this item when you set "DIGITAL OUT" to "OFF."

- D-PCM (Downmix PCM)**: when you play the Dolby Digital (AC-3) sound tracks, the output audio signals are mixed down to 2 channels. With the settings of the item "DOWN MIX" in "AUDIO SETUP," you can select whether the signals conform to Dolby surround (Pro Logic) or not.
- DOLBY DIGITAL**: when the player is connected to an audio component with a built-in Dolby Digital (AC-3) decoder.

Note

If the player is connected to an audio component lacking a built-in Dolby Digital (AC-3) decoder, do not set "DOLBY DIGITAL" in "AUDIO SETUP" to "DOLBY DIGITAL." Otherwise, when you play the Dolby Digital (AC-3) sound track, a loud noise or no sound will come out from the speakers, affecting your ears or causing the speakers to be damaged.

58

59

Settings for Sound (AUDIO SETUP)

■MPEG

Selects output MPEG AUDIO signals via the DIGITAL OUT OPTICAL and COAXIAL connectors. You cannot select this item when you set "DIGITAL OUT" to "OFF."

- **EQ:** when the player is connected to an audio component lacking a built-in MPEG decoder. If you play MPEG AUDIO sound tracks, the player outputs stereo signals taken from MPEG AUDIO signals via the DIGITAL OUT OPTICAL and COAXIAL connectors.
- **MPEG:** when the player is connected to an audio component having a built-in MPEG decoder.

Note

If the player is connected to an audio component lacking a built-in MPEG decoder, do not set "MPEG" in "AUDIO SETUP" to "MPEG". Otherwise, when you play the MPEG AUDIO sound track, a loud noise will come out from the speakers, affecting your ears or causing the speakers to be damaged.

Note

The player outputs the MPEG analog audio sound only from the front speakers when you set "DIGITAL OUT" in "AUDIO SETUP" to "ON" and then set "MPEG" to "MPEG."

■DTS

Selects output DTS signals via the DIGITAL OUT OPTICAL and COAXIAL connectors. You cannot select this item when you set "DIGITAL OUT" to "OFF."

- **EQ:** when the player is connected to an audio component lacking a built-in DTS decoder.
- **ON:** when the player is connected to an audio component having a built-in DTS decoder.

Note

Set the setting correctly. Otherwise, no sound or strange sound will come out from the speakers, affecting your ears or causing the speakers to be damaged.

- Do not play the DTS sound tracks without connecting the player to an audio component having a built-in DTS decoder. You cannot hear the DTS sound unless you connect the player to an audio component having a built-in DTS decoder.
- When you play the DTS sound track on a CD, a loud noise will come out from the AUDIO OUT, 5.1CH OUTPUT (FRONT L/R) and PHONES connectors, affecting your ears or causing the speakers or headphones to be damaged.
- When you play the DTS sound track on a DVD, no sounds will come out from the AUDIO OUT, 5.1CH OUTPUT (FRONT L/R) and PHONES connectors.

Notes on playing the DTS sound tracks on a CD

- Do not play the DTS sound tracks without connecting the player to an audio component having a built-in DTS decoder. The player outputs the DTS signal via the DIGITAL OUT OPTICAL and COAXIAL connectors even if "DTS" in "AUDIO SETUP" is set to "OFF" in the setup display affecting your ears or causing the speakers to be damaged.
- The DTS indicator on the front panel does not light up even if the player outputs DTS signal via the DIGITAL OUT OPTICAL and COAXIAL connectors.
- Set the sounds to "STEREO" when you play the DTS sound tracks on a CD. (See "Changing the Sounds" on page 35.) If you set the sounds to "L/R" or "2/18", no sounds will come out from the DIGITAL OUT OPTICAL and COAXIAL connectors.

Notes on playing the DTS sound tracks on a DVD


- No sounds will come out from the AUDIO OUT and PHONES connectors.
- If the player is connected to an audio component lacking a built-in DTS decoder, do not set "DTS" in "DIGITAL OUT" to "ON". When you play the DTS sound track, a loud noise will come out from the speakers, affecting your ears or causing the speakers to be damaged.
- When you set "DTS" in "AUDIO SETUP" to "OFF", no sound will come out from the DIGITAL OUT OPTICAL and COAXIAL connectors even if you play DTS sound tracks on DVDs.

Speaker Set Up

Select "SPEAKER SETUP" after pressing SET UP.

To obtain the best possible surround sound, first specify the size of speakers you have connected and their distance from your listening position and set the balance and level. Then use the test tone to adjust the speaker volumes to the same level.

For the speaker hook ups, see pages 14 to 15.



■SIZE

Selects the size of the speakers to be connected.


- **FRONT**
 - **LARGE:** Normally select this.
 - **SMALL:** When the sound cracks or the effects of the surround is difficult to hear, select this. This activates the Dolby Digital (AC-3) bass redirection circuitry and outputs the bass frequencies of the speaker from subwoofers.
- **CENTER**
 - **NONE:** If you will not connect a center speaker, select this.
 - **LARGE:** Normally select this.
 - **SMALL:** When the sound cracks, select this. This activates the Dolby Digital (AC-3) bass redirection circuitry and outputs the bass frequencies of the speaker from some other speakers.
- **REAR**
 - **NONE:** If you will not connect a rear speaker, select this.
 - **LARGE (REAR/SIDE):** Normally select this.
 - **SMALL (REAR/SIDE):** When the sound cracks or the effects of the surround is difficult to hear, select this. This activates the Dolby Digital (AC-3) bass redirection circuitry and outputs the bass frequencies of the speaker from some other speakers.
- **SUBWOOFER**
 - **NONE:** If you do not connect a subwoofer, select this. This activates the Dolby Digital (AC-3) bass redirection circuitry and outputs the LFE signals from the front speakers.
 - **YES:** If you connect a subwoofer, select this to output the LFE (low frequency effects) channel from the subwoofer.

• Rear speaker position (REAR/SIDE)

These items let you specify the location of your rear speakers for proper implementation of "VIRTUAL REAR SHIFT" and "VIRTUAL MULTI REAR" in the Control Menu display. Refer to the illustration below.

- Set to "SIDE" if the location of your rear speakers corresponds to section B.
- Set to "REAR" if the location of your rear speakers corresponds to section A.

This setting affects only the "VIRTUAL REAR SHIFT" and "VIRTUAL MULTI REAR" mode.



Notes

- When you select an item, the sound cuts off for a moment.
- The cut off frequency for the subwoofer is fixed at 100Hz.
- Set the subwoofer's cut off frequency as high as possible.
- Depending on the settings of other speakers, the subwoofer may output excessive sound.
- If your speakers are too small to reproduce low bass frequencies, please set all speaker settings to "SMALL" and utilize a subwoofer for low frequency sound.

■DISTANCE

You can vary the distance of each speaker as follows. Default adjustments are in the parentheses.

- **FRONT (3.6m)**
Front speaker distance can be set in 0.2 meter steps from 1 to 15 meters.
- **CENTER (3.6m)**
Center speaker distance can be set in 0.2 meter steps from a distance 0.6 meter farther to the front speaker to a distance 1.5 meters closer to your listening position.
- **REAR (3.0m)**
Rear speaker distance can be set in 0.2 meter steps from a distance equal to the front speaker distance to a distance 5 meters closer to your listening position.

Notes

- When you set the distance, the sound cuts off for a moment.
- If each of the front or rear speakers are not placed an equal distance from your listening position, set the distance of the closest speaker.
- Do not place the rear speaker farther away from your listening position than the front speakers.

Speaker Set Up

■BALANCE

You can vary the balance of each speaker as follows. Default adjustments are in the parentheses.

- **FRONT (0dB)**
Adjust the balance between the front left and right speakers (-6dB [L] to +6dB [R], 0.5dB steps).
- **REAR (0dB)**
Adjust the balance between the rear left and right speakers (-6dB [L] to +6dB [R], 0.5dB steps).

Note

When you select "YES A" or "YES B" in "VIRTUAL 3D SURROUND" in the Control Menu display, you cannot adjust the level or the balance of the speakers except for the front speakers.

■LEVEL

You can vary the level of each speaker as follows. Default adjustments are in the parentheses.

- **CENTER (0dB)**
Adjust the level of the center speaker (-6dB to +6dB, 0.5dB steps).
- **REAR (0dB)**
Adjust the level of the rear speakers (-6dB to +6dB, 0.5dB steps).
- **SUBWOOFER (0dB)**
Adjust the level of the subwoofer (-10dB to +6dB, 0.5dB steps).

■TEST TONE

You can hear the test tone from each speaker in sequence.

- **OFF:** The test tone is not emitted from speakers.
- **ON:** During adjustment of "BALANCE" or "LEVEL," the test tone is emitted from both speakers simultaneously.

Note

While you are playing a disc, you cannot hear the test tone. Execute the test tone after you stop playback.

To adjust the volume of all the speakers at one time

Use the receiver's (amplifier's) volume control.

To return to the default setting

Select the item, then press CLEAR.


Adjusting the speaker volume

- 1 While you stop playback, select "SPEAKER SETUP" after pressing SET UP.
- 2 Select "TEST TONE" and set "TEST TONE" to "ON." You will hear the test tone from each speaker in sequence.
- 3 From your listening position, select "BALANCE" or "LEVEL" and adjust the value of "BALANCE" and "LEVEL" using \uparrow/\downarrow . During this adjustment, the test tone is emitted from both speakers simultaneously.
- 4 Select "TEST TONE" and set "TEST TONE" to "OFF" to turn off the test tone.

Controlling the TV or the AV Receiver (Amplifier) with the Supplied Remote

If you adjust the remote signal, you can control your TV with the supplied remote. Default setting is to control Sony TVs with the \square mark.

When you connect the player to a Sony AV receiver (amplifier), you can also set the input of the receiver (amplifier) to this player with the supplied remote.



Controlling TVs with the remote

- 1 Slide TV/DVD switch to TV.
- 2 Hold down M/POWER, and enter your TV's manufacturer's code (see the table) using the number buttons. Then release M/POWER.

Code numbers of controllable TVs

If more than one code number is listed, try entering them one at a time until you find the one that works with your TV.


Notes

- If you enter a new code number, the code number previously entered will be erased.
- When you replace the batteries of the remote commander, the code number automatically resets to 0 (Sony). Reset the appropriate code number.

Manufacturer	Code number
Sony (default)	01
Grundig	11
Hitachi	24
Loewe	45
Nokia	15,16,69
Panasonic	17,49
Philips	06,07,08
Saba	12,13
Samsung	22,23
Sanyo	25
Sharp	29
Telefunken	36
Thomson	43
Toshiba	38

Controlling the TV or the AV Receiver (Amplifier) with the Supplied Remote

When you set the TV/DVD switch to TV, you can control your TV using the keys below.



By pressing	You can
I/O (POWER)	Turn the TV on or off
TV/VIDEO	Select the input source for the TV between the TV and VCR
TV/DVD*	Select the input source for the TV between the TV and CD/DVD player
VOL**	Adjust the volume of the TV
PROG	Select the program position of the TV
WIDE MODE	Switch the wide picture on or off
Number buttons and ENTER	Select the program position of the TV

* If you connect the player to the TV via the EURO AV OUT connectors, the input source for the TV is set to the player automatically when you start playback or press any button. In this case, press TV/DVD to return the input to the TV.
** You can control the TV regardless of the position of the TV/DVD switch.

Notes

- Depending on the TV, you may not be able to control your TV or to use some of the buttons above.
- If you use number buttons to select program position of the TV, press <-- followed by the number buttons for two-digit numbers.

Controlling an AV receiver (amplifier) with the remote

1 Slide TV/DVD switch to DVD.

2 Hold down I/O (POWER), and enter your AV receiver's manufacturer's code (see the table below) using the number buttons. Then release I/O (POWER).

Manufacturer	Code number
Sony	9 (default), 85, 89
Denon	86, 85, 86
Kentwood	92, 93
Onkyo	81, 82, 83
Pioneer	99
Sansui	87
Technics	97, 98
Yamaha	94, 95, 96

Code numbers of controllable receivers (amplifiers)

If more than one code number is listed, try entering them one at a time until you find the one that works with your receiver.

You can also change the sound volume of the AV receiver using AV VOL.



Notes

- Depending on the AV receiver (amplifier), you may not be able to control your AV receiver (amplifier).
- You can control the AV receiver (amplifier) regardless of the position of the TV/DVD switch.

Self-diagnosis function

When the self-diagnosis function works to prevent the player from malfunctioning, a five-character service number (combination of a letter and digits) flashes on the screen. In this case, check the following table.



First three characters	Cause and/or Corrective Action
C13	<ul style="list-style-type: none"> The disc is dirty. <ul style="list-style-type: none"> Clean the disc with a cleaning cloth. (page 6)
C31	<ul style="list-style-type: none"> The disc is not inserted correctly. <ul style="list-style-type: none"> Open the disc tray and insert the disc correctly.
Err (xx is any number)	<ul style="list-style-type: none"> To prevent the player from malfunctioning, the self-diagnosis function has worked. <ul style="list-style-type: none"> When you contact your Sony dealer or local authorized Sony service facility, give the 5-character service number (example: E6110).

Language Code List

For details, see page 34, 52.


The language spellings conform to the ISO 639: 1988 (E/F) standard.

Code	Language	Code	Language	Code	Language	Code	Language
1027	After	1186	Scott Gaelic	1250	Malayalam	1513	Stewart
1028	Afrikaans	1194	Galician	1252	Mangolian	1514	Sesotho
1032	Afrikaans	1196	Guarani	1253	Moldavian	1515	Sundanese
1039	American	1200	Gujarati	1256	Marathi	1516	Swedish
1044	Arabic	1209	Hausa	1257	Malay	1517	Swahili
1045	Assamese	1217	Hindi	1258	Maltese	1521	Tamil
1051	Aymara	1226	Croatian	1263	Burmese	1525	Telugu
1052	Azerbaijani	1229	Hungarian	1265	Nauru	1527	Tajik
1053	Bashkir	1233	Armenian	1269	Nepali	1528	Thai
1057	Byelorussian	1225	Interlingua	1276	Dutch	1529	Tigrinya
1059	Bulgarian	1229	Interlingua	1279	Norwegian	1531	Turkmen
1060	Bihari	1245	Inupiat	1293	Orcadian	1532	Tagalog
1061	Bislama	1248	Indonesian	1403	(Afari) Oromo	1534	Sesawana
1066	Bengali/Bangla	1253	Icelandic	1408	Oriya	1535	Tonga
1067	Tibetan	1254	Italian	1417	Punjabi	1538	Turkish
1070	Breton	1257	Hebrew	1428	Polish	1539	Tsonga
1079	Catalan	1261	Japanese	1435	Pashto/Pushto	1540	Tatar
1093	Corsican	1269	Yiddish	1436	Portuguese	1543	Twi
1097	Czech	1283	Japanese	1463	Qechua	1557	Ukrainian
1103	Welsh	1287	Georgian	1481	Rheto-Romanic	1564	Urdu
1105	Danish	1297	Kazakh	1482	Kirundi	1572	Uzbek
1109	German	1298	Greenlandic	1483	Romanian	1581	Vietnamese
1130	Bhutani	1299	Cambodian	1489	Russian	1587	Volapuk
1142	Greek	1300	Kannada	1491	Kinyarwanda	1613	Wolof
1144	English	1301	Korean	1495	Sanskrit	1632	Xhosa
1145	Esperanto	1305	Kashmiri	1498	Sindhi	1665	Yoruba
1149	Spanish	1307	Kurdish	1501	Singha	1684	Chinese
1150	Estonian	1311	Alghia	1502	Serbo-Croatian	1697	Zulu
1151	Beque	1313	Latin	1503	Singhalese	1703	Not specified
1157	Persian	1326	Lingala	1505	Slovak		
1165	Finnish	1327	Lochian	1506	Slovenian		
1166	Fiji	1332	Lithuanian	1507	Somalian		
1171	Faroese	1334	Latvian/Lettish	1508	Shona		
1174	French	1345	Malagasy	1509	Somali		
1181	Frisian	1347	Maori	1511	Albanian		
1183	Irish	1349	Macedonian	1512	Serbian		

Index to Parts and Controls


Refer to the pages indicated in parentheses for details.

Front Panel



- 1 (remote sensor) (7)
- 2 Accepts the remote control signals.
- 3 I/O (POWER) button and Indicator (17)
- 4 Turns on and off the power of the player.
- 5 VIRTUAL 3D SURROUND button/indicator (37)
- 6 Selects the item of "VIRTUAL 3D SURROUND." Each time you press the button, the item changes. When you do not set "VIRTUAL 3D SURROUND" to "OFF," the indicator lights up.
- 7 SHUFFLE button (40)
- 8 Displays the "SHUFFLE" display on the TV screen.
- 9 MULTICHANNEL Indicator (36)
- 10 Lights up as follows:
 - playing back multichannel surround sound such as Dolby Digital (AC-3) soundtrack and MPEG soundtrack
 - the disc is not inserted
- 11 Disc tray (17)
- 12 Place a disc on the tray.
- 13 OPEN/CLOSE button (17)
- 14 Opens or closes the disc tray.
- 15 SEARCH buttons (19)
- 16 Press to locate a scene.
- 17 PREV/NEXT (DIRECT SEARCH dial) button (18)
- 18 Turn to select a chapter or track, and then press to go back to the selected chapter or track.
- 19 Click shuttle (19)
- 20 Changes the playback speed.
- 21 ENTER button
- 22 Selects and executes the items or settings.
- 23 I/O (POWER) button / Indicator (19)
- 24 Press to play a disc frame by frame.
- 25 PHONE connector (17)
- 26 Connect the headphones to this connector.
- 27 PHONE LEVEL control (17)
- 28 Adjusts the headphone volume.
- 29 PROGRAM button (38)
- 30 Displays the "PROGRAM" display on the TV screen.
- 31 Front Panel Display (23)
- 32 Indicates the playing time, etc.
- 33 REPEAT button (41)
- 34 Displays the "REPEAT" display on the TV screen.
- 35 CLEAR button (39, 40, 41)
- 36 Press to return to the continuous play, etc.
- 37 PLAY button (17)
- 38 Plays a disc.
- 39 PAUSE button (18)
- 40 Pauses playing a disc.
- 41 STOP button (18, 20)
- 42 Stops playing a disc.
- 43 TITLE button (21)
- 44 Displays the title menu on the TV screen.
- 45 DVD MENU button (21)
- 46 Displays the DVD menu on the TV screen.
- 47 RETURN button (22, 26)
- 48 Press to return to the previously selected screen, etc.

Rear Panel




Additional Information

- 1 **EURO AV 1 (RGB)-TV connector (8, 54)**
Connects to the TV with EURO AV connector to output the signal from the player. You can select the video signals, the S VIDEO signals or the RGB signals as output signal format. Choose the appropriate one. (page 54)
- 2 **EURO AV 2 connector (8)**
Connects to the video equipment with EURO AV connector to input the signal from the equipment.
- 3 **AUDIO OUT connectors (9, 12)**
Connects to the audio input connector on the TV or receiver (amplifier).
- 4 **5.1CH OUTPUT connectors (15)**
Connects to a receiver (amplifier) having 5.1 channel input connectors.
- 5 **DIGITAL OUT (OPTICAL) connector (13)**
Connects to an audio component using the optical digital connecting cord.
- 6 **DIGITAL OUT (COAXIAL) connector (13)**
Connects to an audio component using the coaxial digital connecting cord.
- 7 **VIDEO OUT connectors (8)**
Connects to the video input connector on the TV or monitor.
- 8 **S VIDEO OUT (1, 2) connectors (8, 12)**
Connects to the S video input connector on the TV or VCR.
- 9 **COMPONENT VIDEO OUT connectors (9)**
Connects to a monitor or projector having component video input connectors (Y, CB/B-Y, CR/R-Y) that conform to output signals from the player.

74

Remote



- 1 **TV/DVD switch (63)**
Selects to control the player or the TV with the remote.
- 2 **OPEN/CLOSE button (17)**
Opens or closes the disc tray.
- 3 **Number buttons**
Selects the items or settings.
- 4 **CLEAR / -/- (ten's digit) button (39, 40, 41)**
Press to return to the continuous play etc.
- 5 **REPEAT button (41)**
Displays the "REPEAT" display on the TV screen.
- 6 **PROGRAM button (38)**
Displays the "PROGRAM" display on the TV screen.
- 7 **SHUFFLE button (40)**
Displays the "SHUFFLE" display on the TV screen.
- 8 **ANGLE button (35)**
Changes the angles when playing a DVD.
- 9 **AUDIO button (33)**
Changes the sound while playing a DVD or VIDEO CD.
- 10 **SUBTITLE button (34)**
Displays the SUBTITLE menu in the Control Menu display.
- 11 **PREV/NEXT buttons (18)**
Press to go to the next chapter or track or to go back to the previous chapter or track.
- 12 **PLAY button (17)**
Plays a disc.
- 13 **SEARCH (FIND) buttons (19)**
Press to locate a scene.
- 14 **DISPLAY button (25)**
Displays the Control Menu display on the TV screen to set or adjust the items.
- 15 **TITLE button (21)**
Displays the title menu on the TV screen.
- 16 **DVD MENU button (21)**
Displays the DVD menu on the TV screen.
- 17 **Click shuttle (19)**
Changes the playback speed.
- 18 **ENTER button**
Selects and executes the items or settings.
- 19 **SET UP button (49)**
Displays the setup display on the TV screen to set or adjust the items.
- 20 **POWER button (17)**
Turns on and off the power of the player and TV.
- 21 **TV operation buttons (63, 64)**
Controls TVs.
- 22 **TIME/TEXT button (23)**
Displays the playing time of the disc, etc., on the front panel display.
- 23 **INPUT button (32)**
Press when labeling a disc.
- 24 **ENTER button**
Executes the items or settings.
- 25 **PICTURE MEMORY button (54)**
Press to store a picture in memory.
- 26 **TV/DVD button (64)**
Press to select the input source for the TV between the TV and CD/DVD player.
- 27 **BOOK MARK button (48)**
Press to set a bookmark.
- 28 **AV VOL button (64)**
Change the sound volume of the AV receivers (amplifiers).
- 29 **STOP button (18, 20)**
Stops playing a disc.
- 30 **PAUSE button (18)**
Pauses playing a disc.
- 31 **JOG button / indicator (19)**
Press to play a disc frame by frame.
- 32 **RETURN button (22, 26)**
Press to return to the previously selected screen, etc.


Additional Information

75


SECTION 2 DISASSEMBLY

Note: Follow the disassembly procedure in the numerical order given.


2-1. CASE REMOVAL




2-3. POWER BLOCK REMOVAL




2-2. MB-85 BOARD REMOVAL




2-4. ER-4/5 BOARD REMOVAL



2-5. AU-209 BOARD REMOVAL (S525D)




2-7. TRAY COVER REMOVAL




- ① Insert a tapering driver into the aperture of the unit bottom, and move the lever of chuck cam in the direction of the arrow ①.


2-6. AU-211 BOARD REMOVAL (S725D)




2-8. FRONT PANEL REMOVAL




2-9. MECHANISM DECK REMOVAL




2-11. OPTICAL PICK-UP REMOVAL



2-10. TRAY REMOVAL




2-12. BELT, LOADING MOTOR (M001), MS-29/TK-54 BOARD REMOVAL




2-13. INTERNAL VIEW

DC motor (loading)
1-541-632-11

Optical pick-up (KHM-220AAA/J1RP)
8-820-081-03




2-14. CIRCUIT BOARDS LOCATION




SECTION 3
BLOCK DIAGRAMS

3-1. OVERALL BLOCK DIAGRAM




05


3-2. RF/SERVO BLOCK DIAGRAM




3-3. SIGNAL PROCESS BLOCK DIAGRAM




3-4. VIDEO BLOCK DIAGRAM



3-5. SYSTEM CONTROL BLOCK DIAGRAM




3-6. AUDIO (1) BLOCK DIAGRAM




05


3-7. AUDIO (2) BLOCK DIAGRAM
- DVP-S525D -




05




3-8. AUDIO (3) BLOCK DIAGRAM
- DVP-S725D -



05




3-9. INTERFACE CONTROL BLOCK DIAGRAM



05

3-10. POWER BLOCK DIAGRAM







SECTION 4

PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAMS

THIS NOTE IS COMMON FOR PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAMS.

(In addition to this, the necessary note is printed in each block)

For printed wiring boards:








-  : indicates a lead wire mounted on the component side.
-  : indicates a lead wire mounted on the printed side.
-  : Through hole.
-  : Pattern from the side which enables seeing.



(The other layers' patterns are not indicated)

Caution:

Pattern face side: (Side B)	Parts on the pattern face side seen from the pattern face are indicated.
Parts face side: (Side A)	Parts on the parts face side seen from the parts face are indicated.


For schematic Diagram:

- Caution when replacing chip parts.
New parts must be attached after removal of chip.
Be careful not to heat the minus side of tantalum capacitor, because it is damaged by the heat.
- All resistors are in ohms, $\frac{1}{4}$ W (Chip resistors : $\frac{1}{10}$ W) unless otherwise specified.
k Ω : 1000 Ω , M Ω : 1000 k Ω .
- All capacitors are in μ F unless otherwise noted. pF : μ F
50V or less are not indicated except for electrolytics and tantalums.
- All variable and adjustable resistors have characteristic curve B, unless otherwise noted.
-  : nonflammable resistor.
-  : fusible resistor.
-  : panel designation.
-  : internal component.
-  : adjustment for repair.
-  : B+ Line.
-  : B- Line.
- Circled numbers refer to waveforms.
- Voltages are dc between measurement point.
- Readings are taken with a color-bar signals on DVD reference disc and when playing CD reference disc.
- Readings are taken with a digital multimeter (DC 10M Ω).
- Voltage variations may be noted due to normal production tolerances.

Note: The components identified by mark  or dotted line with mark  are critical for safety.
Replace only with part number specified.

When indicating parts by reference number, please include the board name.


4-1. FRAME SCHEMATIC DIAGRAMS
FRAME (1) SCHEMATIC DIAGRAM



4-5




FRAME (3) SCHEMATIC DIAGRAM
- DVP-S725D -



4-2. PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAMS

TK-54 (RF/SERVO) PRINTED WIRING BOARD

– Ref. No.: TK-54 board; 2,000 series –




TK-54 BOARD (SIDE A)


CN001	B-2
CN002	C-2
CN003	D-2
CN004	D-3
D003	B-2
IC001	C-1
Q001	A-2
Q002	D-1

There are few cases that the part isn't mounted in this model is printed on this diagram.

TK-54 BOARD(SIDE A)




TK-54 BOARD(SIDE B)




• Waveforms

① IC001 ① (DVD play)
200 mV/DIV 100 ns/DIV




536 mVp-p

② IC001 ① (CD play)
500 mV/DIV 500 ns/DIV




880 mVp-p

③ IC001 ② (DVD play)
200 mV/DIV 500 ms/DIV




592 mVp-p

④ IC001 ② (CD play)
200 mV/DIV 20 ms/DIV




448 mVp-p

⑤ IC001 ③ (DVD play)
500 mV/DIV 50 ms/DIV




1.3 Vp-p

⑥ IC001 ③ (CD play)
500 mV/DIV 200 ms/DIV




1.7 Vp-p

⑦ IC001 ④ (DVD play)
100 mV/DIV 50 ms/DIV




180 mVp-p

⑧ IC001 ④ (CD play)
500 mV/DIV 50 ms/DIV




860 mVp-p

⑨ IC001 ⑤ (DVD play)
500 mV/DIV 100 ns/DIV



1.5 Vp-p

⑩ IC001 ⑤ (CD play)
500 mV/DIV 500 ns/DIV



1.5 Vp-p

RF/SERVO TK-54

RF/SERVO TK-54




RF/SERVO TK-54



MS-29 (LOADING) PRINTED WIRING BOARD AND SCHEMATIC DIAGRAM
– Ref. No.: MS-29 board; 3,000 series –

There are few cases that the part isn't mounted in this model is printed on this diagram.

MS-29 BOARD





MS-29 BOARD




There are few cases that the part isn't mounted in this model is printed on this diagram.

MB-85 BOARD(SIDE A)

CN001	D-2
CN002	D-4
CN003	D-5
CN004	C-1
CN005	B-1
CN006	C-7
CN007	C-8
CN010	B-6
CN011	D-6
CN012	D-6
D801	C-6
D802	C-6
D803	C-6
D804	C-6
D805	C-5
D807	C-5
IC001	A-2
IC003	A-3
IC004	B-3
IC202	A-5
IC206	A-6
IC302	D-3
IC303	C-4
IC401	C-2
IC501	A-2
IC601	A-4
IC701	C-5
IC904	A-1
Q801	C-5
Q802	C-6
Q803	C-6



MB-85 BOARD(SIDE B)




MB-85 BOARD (SIDE B)


D701	C-2
D806	C-2
IC005	A-6
IC201	A-3
IC203	A-3
IC204	B-2
IC207	A-2
IC304	C-3
IC402	C-5
IC403	C-5
IC404	D-5
IC502	C-6
IC602	A-4
IC702	B-1
IC801	C-2
IC802	C-1
IC803	C-1
IC902	A-6
IC905	B-6
IC906	B-6
IC907	C-6

MB-85 (AV DECODER) SCHEMATIC DIAGRAM • See page 4-17 for printed wiring board.

– Ref. No.: MB-85 board; 1,000 series –



– Ref. No.: MB-85 board; 1,000 series –



① IC401 ⑤④

A square wave signal is shown within a rectangular frame. The signal has a period of 10 units and a duty cycle of 40%. It consists of a series of pulses, each 4 units wide and 1 unit high, separated by 6 units of low signal. The signal starts at a low level, rises to a high level for 4 units, and then returns to low for 6 units. This pattern repeats three times across the frame.

The graph shows the number of people in the workforce (in millions) from 1970 to 2000. The x-axis represents years from 1970 to 2000 in 5-year increments. The y-axis represents the number of people in millions, ranging from 0 to 120 in increments of 20. The line starts at approximately 65 million in 1970, rises to about 70 million by 1975, dips slightly to 68 million in 1980, and then continues a steady upward trend, reaching approximately 105 million by 2000.

4-24

SDRAM

– Ref. No.: MB-85 board; 1,000 series –


① IC701 ⑥9 (DVD play)
500 mV/DIV 50 ms/DIV



1.7 Vp-p


180 mVp-p

860 mVp-p




MB-85 (DRIVE) SCHEMATIC DIAGRAM • See page 4-17 for printed wiring board.

– Ref. No.: MB-85 board; 1,000 series –




MB-85 (SYSTEM CONTROL) SCHEMATIC DIAGRAM • See page 4-17 for printed wiring board.

– Ref. No.: MB-85 board; 1,000 series –




• Waveforms

① IC202 ②



2.4 Vp-p (12.5 MHz)

② IC202 ⑤




4 Vp-p (25.3 MHz)

NO MARK+DVD PLAY
CD+CD PLAY
*IMPOSSIBLE TO MEASURE THE
VOLTAGE AT THE MARKED POINTS.

DVP-S525D/S725D


MB-85 (HGA) SCHEMATIC DIAGRAM • See page 4-17 for printed wiring board.

– Ref. No.: MB-85 board; 1,000 series –




MB-85 (CLOCK GENERATOR, AUDIO DSP, V EQ/NR) SCHEMATIC DIAGRAM • See page 4-17 for printed wiring board and page 4-40 for waveforms.

– Ref. No.: MB-85 board; 1,000 series –




MB-85 (DAC) SCHEMATIC DIAGRAM • See page 4-17 for printed wiring board.

– Ref. No.: MB-85 board; 1,000 series –




MB-85 (BIAS) SCHEMATIC DIAGRAM • See page 4-17 for printed wiring board.
– Ref. No.: MB-85 board; 1,000 series –




• Waveforms

❶ IC004 ②, ⑤, ⑦




4.2 Vp-p (26.9 MHz)

❷ IC003 ⑤, ⑦




DVD: 6.2 Vp-p (37.0 MHz)
CD : 5 Vp-p (33.6 MHz)

❸ IC001 ⑥




4.2 Vp-p (27.0 MHz)

❹ IC001 ⑫




4.6 Vp-p (33.8 MHz)

❺ IC001 ⑰




DVD: 5.8 Vp-p (36.5 MHz)
CD : 5.1 Vp-p (33.8 MHz)

❻ IC001 ⑱ (DVD play)



4.2 Vp-p (25.3 MHz)

❼ IC001 ⑱ (CD play)





4.7 Vp-p (22.5 MHz)

AU-211 (AUDIO, VIDEO BUFFER) PRINTED WIRING BOARD

– Ref. No.: AU-211 board; 3,000 series –
– DVP-S725D –

There are few cases that the part isn't mounted in this model is printed on this diagram.




CN301	C-5
CN302	B-4
CN401	C-11
CN402	C-2
CN403	C-3
CN404	C-4
CN405	C-3
CN406	B-3
CN407	C-5

0301	A-4
0303	A-4
0401	C-11
0402	C-11
0403	C-11
0404	C-11
0405	C-4
0406	B-4
0407	B-4
0408	B-4
0409	B-4
0410	A-11
0411	A-11
0421	B-5
0422	B-5
0423	B-5
0424	B-5
0425	C-4
0426	B-2
0427	B-2

C301	B-1
C302	B-3
C303	A-1
C401	C-7
C403	B-7
C404	C-8
C405	C-9
C406	C-10
C407	B-7
C408	B-8
C409	B-9
C410	B-10
C411	B-5
C412	B-11
C415	C-5


Q301	B-2
Q302	B-2
Q303	A-1
Q401	B-4
Q402	B-4
Q403	B-4
Q404	B-4
Q405	B-4
Q410	A-7
Q411	A-6
Q412	A-8
Q413	A-8
Q414	A-9
Q415	A-9
Q416	A-10
Q417	A-10
Q418	B-5
Q419	B-5
Q420	B-12
Q421	B-11
Q422	A-11
Q423	A-11
Q424	A-11
Q425	B-3
Q426	B-3
Q427	B-3
Q431	B-4
Q432	B-5
Q433	B-5
Q434	B-5
Q435	C-5
Q437	C-7
Q438	C-8
Q439	B-3
Q440	B-3

– DVP-S725D –




AU-211 (VIDEO BUFFER) SCHEMATIC DIAGRAM • See page 4-41 for printed wiring board.

– Ref. No.: AU-211 board; 3,000 series –
– DVP-S725D –



• Waveforms



AU-209 (AUDIO, VIDEO BUFFER) PRINTED WIRING BOARD



– Ref. No.: AU-209 board; 2,000 series –
– DVP-S525D –

There are few cases that the part isn't mounted in this model is printed on this diagram.


AU-209 BOARD

- | | |
|-------|------|
| CN301 | B-2 |
| CN302 | B-3 |
| CN305 | B-6 |
| CN401 | C-7 |
| | |
| D301 | A-11 |
| D304 | A-5 |
| D306 | A-5 |
| D308 | B-6 |
| D431 | A-8 |
| D432 | A-8 |
| D525 | A-9 |
| D526 | A-8 |
| D551 | A-10 |
| D552 | A-9 |
| D591 | A-11 |
| D592 | A-11 |
| | |
| IC301 | C-11 |
| IC302 | A-11 |
| IC321 | B-3 |
| IC401 | A-6 |
| IC431 | B-7 |
| IC502 | B-8 |
| IC505 | A-1 |
| IC541 | B-9 |
| IC571 | B-10 |
| | |
| Q301 | B-5 |
| Q303 | A-11 |
| Q304 | B-6 |
| Q305 | C-3 |
| Q306 | C-9 |
| Q307 | C-7 |
| Q308 | C-10 |
| Q309 | C-10 |
| Q310 | C-11 |
| Q311 | C-10 |
| Q314 | B-2 |
| Q315 | B-3 |
| Q321 | B-4 |
| Q322 | B-4 |
| Q341 | A-1 |
| Q361 | A-3 |
| Q362 | A-4 |
| Q401 | A-6 |
| Q402 | A-6 |
| Q431 | B-7 |
| Q432 | B-7 |
| Q435 | C-6 |
| Q436 | A-8 |
| Q503 | B-9 |
| Q504 | A-8 |
| Q543 | B-10 |
| Q544 | A-9 |
| Q573 | B-11 |
| Q574 | A-10 |

AU-209 BOARD



AU-209 (AUDIO) SCHEMATIC DIAGRAM
- Ref. No.: AU-209 board; 2,000 series -
- DVP-S525D -




DVP-S525D/S725D

AU-209 (VIDEO BUFFER) SCHEMATIC DIAGRAM • See page 4-49 for printed wiring board.


– Ref. No.: AU-209 board; 2,000 series –

– DVP-S525D –




- **Waveforms**

① IC321 ②




1.1 Vp-p (H)

6 IC321 15




2.0 V_{p-p} (H)

② IC321 ④




1.2 V_{p-p} (H)

③ IC321 ⑦




860 mVp-p (H)

④ IC321 ⑩



1.8 Vp-p (H)

5 IC321 13



2.4 Vp-p (H)


NO MARK: DVD/CD PLAY
• SIGNAL PATH

SIGNAL PATH				
	VIDEO SIGNAL			AUDIO SIGNAL
	CHROMA	Y	Y/CHROMA	
PB	➡	➡➡	➡➡➡	➡

ER-4 (EURO AV) PRINTED WIRING BOARD

– Ref. No.: ER-4 board; 2,000 series –
– DVP-S525D –

There are few cases that the part isn't mounted in this model is printed on this diagram.




ER-4 BOARD

CN901 C-3
CN902 B-6
CN903 A-5
CN904 A-2


D901 B-5
D902 A-1
D903 B-2
D904 B-3
D905 B-4
D906 B-5
D908 A-4
D915 A-5
D917 A-1
D918 A-2
D919 A-2
D920 A-2
D921 A-2
D922 A-2
D923 A-3
D924 A-3
D926 A-4
D927 A-3
D929 A-1
D930 A-1

IC901 C-2
IC902 B-2
IC903 B-4

Q901 C-4
Q902 C-4
Q903 B-5
Q904 C-5
Q905 B-5
Q906 C-5
Q907 C-5
Q908 B-5
Q909 B-5
Q910 B-4
Q912 A-1
Q913 B-2
Q914 B-3
Q915 A-4
Q916 B-5



ER-4 BOARD(1/2)




①
ER-4 BOARD(2/2)
(SEE PAGE 4-59)

NO MARK: DVD/CD PLAY
• SIGNAL PATH

	VIDEO SIGNAL			AUDIO SIGNAL
	CHROMA	Y	Y/CHROMA	
PB	⇨	⇨⇨	⇨⇨⇨	⇨

ER-4 (EURO AV2) SCHEMATIC DIAGRAM • See page 4-55 for printed wiring board.
– Ref. No.: ER-4 board; 2,000 series –
– DVP-S525D –





ER-5 (EURO AV) PRINTED WIRING BOARD

– Ref. No.: ER-5 board; 2,000 series –
– DVP-S725D –

There are few cases that the part isn't mounted in this model is printed on this diagram.


ER-5 BOARD(SIDE A)



ER-5 BOARD(SIDE B)

EURO AV1 (RGB) - TV

EURO AV2




ER-5 BOARD (SIDE B)


CN901	C-3
CN902	B-6
CN903	A-5
CN904	A-2
D901	B-4
D902	A-1
D903	B-2
D904	B-3
D905	B-4
D906	B-5
D907	B-4
D908	A-4
D910	B-3
D915	A-5
D917	A-1
D918	A-2
D919	A-2
D920	A-2
D921	A-2
D922	A-2
D923	A-3
D924	A-3
D926	A-4
D927	A-3
D929	A-1
D930	A-1
IC901	C-2
IC902	B-2
IC903	B-4
Q901	C-4
Q902	C-4
Q903	C-4
Q904	C-5
Q905	B-5
Q906	C-5
Q907	C-5
Q908	B-5
Q909	B-5
Q910	B-4
Q912	A-1
Q913	B-2
Q914	B-3
Q915	A-4
Q916	B-5
Q917	B-3
Q918	B-3

– Ref. No.: ER-5 board; 2,000 series –

– DVP-S725D –



ER-5 (EURO AV2) SCHEMATIC DIAGRAM • See page 4-61 for printed wiring board.
– Ref. No.: ER-5 board; 2,000 series –
– DVP-S725D –





FL-100 (FUNCTION SWITCH, IF CON) PRINTED WIRING BOARD


– Ref. No.: FL-100 board; 2,000 series –
– DVP-S725D –

There are few cases that the part isn't mounted in this model is printed on this diagram.

FL-100 BOARD(SIDE A)



FL-100 BOARD (SIDE B)



FL-98 (FUNCTION SWITCH, IF CON) PRINTED WIRING BOARD



– Ref. No.: FL-98 board; 2,000 series –
– DVP-S525D –

There are few cases that the part isn't mounted in this model is printed on this diagram.

FL-98 BOARD


- CN201 C-1
- CN202 C-10
- CN203 C-12
- D202 A-10
- D203 C-1
- D204 C-13
- D206 B-1
- D207 B-1
- IC201 B-9
- IC202 A-10
- Q201 B-1

FL-98 BOARD




FL-98/100 (FUNCTION SWITCH) SCHEMATIC DIAGRAM • See page 4-69 for printed wiring board.


– Ref. No.: FL-98/100 board; 2,000 series –



FL-98/100 (IF CON) SCHEMATIC DIAGRAM • See pages 4-69 and 4-73 for printed wiring board.
– Ref. No.: FL-98/100 board; 2,000 series –



• Waveform




3.9 Vp-p (4 MHz)

SW-314/316 (SURROUND SWITCH) PRINTED WIRING BOARDS




– Ref. No.: SW-314/316 board; 4,000 series –

There are few cases that the part isn't mounted in this model is printed on this diagram.

– DVP-S525D –

SW-314 BOARD

– DVP-S725D –

**SW-316 BOARD
(SIDE A)****SW-316 BOARD
(SIDE B)**

FL-147/149 (IR/POWER SWITCH) PRINTED WIRING BOARDS

– Ref. No.: FL-147/149 board; 4,000 series –


There are few cases that the part isn't mounted in this model is printed on this diagram.

– DVP-S525D –

FR-147 BOARD


FR-147 BOARD

- CN001 B-3
- CN002 A-5
- CN003 A-2
- D001 A-4
- D002 A-4
- D003 B-4
- D004 A-4
- D071 A-1
- IC051 A-1
- Q001 A-3
- Q002 A-3



– DVP-S725D –


FR-149 BOARD(SIDE A)



FR-149 BOARD(SIDE B)



FR-149 BOARD (SIDE B)

- CN001 B-3
- CN002 A-5
- CN003 A-2
- D001 A-4
- D002 A-4
- D003 B-4
- D004 A-4
- D071 A-1
- IC051 A-1
- Q001 A-3
- Q002 A-3



SW-314/316 (SURROUND SWITCH), FR-147/149 (IR/POWER SWITCH) SCHEMATIC DIAGRAM • See pages 4-79 for printed wiring board.

– Ref. No.: SW-314/316 board and FR-147/149 board; 4,000 series –




HP-108/110 (HEADPHONE) PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAM

– Ref. No.: HP-108/110 board; 2,000 series –

There are few cases that the part isn't mounted in this model is printed on this diagram.


– DVP-S525D –

HP-108 BOARD




– DVP-S725D –



HP-110 BOARD(SIDE A)



HP-110 BOARD(SIDE B)



HP-108/110 BOARD





RY-12 (RELAY) PRINTED WIRING BOARD AND SCHEMATIC DIAGRAM


– Ref. No.: RY-12 board; 2,000 series –

There are few cases that the part isn't mounted in this model is printed on this diagram.

– DVP-S725D – RY-12 BOARD



– DVP-S725D –



Note: The components identified by mark \triangle or dotted line with mark \triangle are critical for safety. Replace only with part number specified.

HS-030SH (SWITCHING REGULATOR) PRINTED WIRING BOARD

– Ref. No.: HS-030SH board; 6,000 series –


HS-030SH BOARD

CN101	A-3
CN102	C-4
CN201	A-1
CN202	B-1
CN203	B-1

D101	C-4
D102	A-3
D104	A-3
D105	A-2
D131	A-2
D132	A-2
D133	A-3
D135	A-3
D182	C-2
D183	C-2
D184	C-2
D185	C-3
D211	B-1
D212	B-2
D311	A-2
D401	C-1
D402	C-1
D511	B-2
D611	B-2


IC301	A-2
IC401	C-1


Q101	B-3
Q102	A-3
Q103	B-3
Q131	A-2
Q181	C-2
Q182	C-3
Q183	C-2



There are few cases that the part isn't mounted in this model is printed on this diagram.

HS-030SH BOARD





5-1. SYSTEM CONTROL PIN FUNCTION (MB-85 BOARD IC202)

Pin No.	Pin name	I/O	Function
1	PB5	O	Analog filter gain control
2	PB6	O	VES gain control “H”: VES
3	PB7	O	Rear CH boost control “H”: rear boost
4	VCC3	-	Power supply
5	CLK	O	CPU clock out (25 MHz)
6	CS5	O	Not used
7	CS4	O	Chip select signal for ARP, SERVO DSP and HGA
8	CS3	O	Chip select signal for SDRAM and AV DEC
9	CS2	O	Chip select signal for REG and AV DEC
10	CS1	O	Chip select signal for external SRAM
11	CS0	O	Chip select signal for external FLASH ROM
12	NMI	I	Not used (fixed at “H”)
13	HST	I	Not used (fixed at “H”)
14	RST	I	Reset signal input from IF CON
15	GND	-	Ground
16	MD0	I	Input of mode select 0 (fixed at “1”)
17	MD1	I	Input of mode select 1 (fixed at “0”)
18	MD2	I	Input of mode select 2 (fixed at “0”)
19	RDY	I	Wait signal input
20	P81	I	Test terminal (fixed at “H”)
21	P82	I	Test terminal (fixed at “L”)
22	RD	O	Read enable signal output
23	WR0	O	High byte write enable signal output (16 bit and 8 bit)
24	WR1	O	Low byte write enable signal output (16 bit only)
25-32	D16-D23	I/O	Data bus D0-D7 (16 bit)
33-39	D24-D30	I/O	Data bus D8-D14 (16 bit), D0-D6 (8 bit)
40	GND	-	Ground
41	D31	I/O	Data bus D15 (16 bit), D7 (8 bit)
42	A00	O	Address bus A0
43	VCC5	-	Power supply
44-64	A01-A21	O	Address bus A1-A21
65	GND	-	Ground
66	P66	O	PLL IC control output “H”: DOUBLE
67	P67	I	DIAG mode signal input “L”: DIAG

Pin No.	Pin name	I/O	Function
68	EOP0	I	Not used
69	AVCC	-	Power supply
70	AVRH	-	Reference power supply (+3.3V)
71	AGND	-	Ground
72	AN0	I	Set of mode 0
73	AN1	I	Set of mode 1
74	AN2	I	Set of mode 2
75	AN3	I	Set of mode 3 (fixed at “H”)
76	SI0	I	Serial data input from IF CON and EEPROM
77	SO0	O	Serial data output to IF CON and EEPROM
78	SC0	O	Serial clock output to IF CON and EEPROM
79	SI1	I	Serial bus 1 (for data input)
80	SO1	O	Serial bus 1 (for data output)
81	SI2	I	Serial bus 2 (for data input)
82	SO2	O	Serial bus 2 (for data output)
83	PF7	O	Reset signal output
84	DACK1	O	Output of DMA-ACK 0 to AV DEC
85	DACK0	O	Output of DMA-ACK 1 to AV DEC
86	DREQ1	I	Input of DMA-REQ 0 from AV DEC
87	DREQ0	I	Input of DMA-REQ 1 from AV DEC
88	INT3	I	Input of interrupt from HGA
89	SC1	O	Serial clock output
90	GND	-	Ground
91	X1	O	Clock output (12.5MHz)
92	X0	I	Clock input (12.5MHz)
93	VCC5	-	Power supply
94	INT1	I	Input of interrupt ARP and SERVO DSP
95	INT0	I	Input of interrupt from AV DEC
96	PB0	I	Rear panel lime input select (“H”: DISC “L”: EXT)
97	PB1	O	Chip select signal to IF CON
98	PB2	O	Chip select signal to DAC (Lt and Rt)
99	PB3	O	Chip select signal to DAC (L and R)
100	PB4	O	DVD/CD select (“H”: 44.1kHz “L”: 48kHz)

SECTION 6 TEST MODE

6-1. GENERAL DESCRIPTION

The Test Mode allows you to make diagnosis and adjustment easily using the remote commander and monitor TV. The instructions, diagnostic results, etc. are given on the on-screen display (OSD).

6-2. STARTING TEST MODE

Press [TITLE], [CLEAR], [POWER] buttons on the remote commander in this order with the power of main unit in OFF status, and the Test Mode starts, then the menu shown below will be displayed on the TV screen. At the bottom of menu screen, the model name and revision number are displayed.

To execute each function, select the desired menu and press its number on the remote commander.

To exit from the Test Mode, press the POWER button.

```
Test Mode Menu

0. Syscon Diagnosis
1. Drive Auto Adjustment
2. Drive Manual Operation
3. Mecha Aging
4. Emergency History
5. Version Information
6. Video Level Adjustment
Exit: Power Key
-
Model      : DPX12xxxx
Revision: 1.xxxx
```

6-3. SYSCON DIAGNOSIS

The same contents as board detail check by serial interface can be checked from the remote commander.

On the Test Mode Menu screen, press [0] key on the remote commander, and the following check menu will be displayed.

```
### Syscon Diagnosis ###
Check Menu

0. Quit
1. All
2. Version
3. Peripheral
4. Servo
5. Supply
6. AV Decoder
7. Video
8. Audio
-
```

0. Quit

Quit the Syscon Diagnosis and return to the Test Mode Menu.

1. All

All items continuous check

This menu checks all diagnostic items continuously. Normally, all items are checked successively one after another automatically unless an error is found, but at a certain item that requires judgment through a visual check to the result, the following screen is displayed for the key entry.

```
### Syscon Diagnosis ###

Diag All Check
No. 2 Version

2-3. ROM Check Sum
Check Sum = xxxx

Press NEXT Key to Continue
Press PREV Key to Repeat
-
```

For the ROM Check, the check sum calculated by the Syscon is output, and therefore you must compare it with the specified value for confirmation.

Following the message, press [NEXT] key to go to the next item, or [PREV] key to repeat the same check again. To quit the diagnosis and return to the Check Menu screen, press [STOP] or [ENTER] key. If an error occurred, the diagnosis is suspended and the error code is displayed as shown below.

```
### Syscon Diagnosis ###

3-3. EEPROM Check
Error 03: EEPROM Write/Reed N
Address   : 00000001
Write Data : 2492
Read Data  : 2490
Press NEXT Key to Continue
Press PREV Key to Repeat
-
```

Press [STOP] key to quit the diagnosis, or [PREV] key to repeat the same item where an error occurred, or [NEXT] key to continue the check from the item next to faulty item.

Submenu

Selecting 2 and subsequent items calls the submenu screen of each item.

For example, if “5. Supply” is selected, the following submenu will be displayed.

```
### Syscon Diagnosis ###
Check Menu
No. 5 Supply

0. Quit
1. All
2. ARP Register Check
3. ARP to RAM Data Bus
4. ARP to RAM Address Bus
5. ARP RAM Check
-
```

0. Quit

Quit the submenu and return to the main menu.

1. All

All submenu items continuous check

This menu checks 2 and subsequent items successively. At the item where visual check is required for judgment or an error occurred, the checking is suspended and the message is output for key entry.

Normally, all items are checked successively one after another automatically unless an error is found.
 Selecting 2 and subsequent items executes respective menus and outputs the results.
 For the contents of each submenu, see “Check Items List”.

General Description of Checking Method

2. Version

- (2-2) Revision
 ROM revision number is displayed.
 Error: Not detected.
 The revision number defined in the source file of ROM (IC206) is displayed with four digits.
- (2-3) ROM Check Sum
 Check sum is calculated.
 Error: Not detected.
 The 8-bit data are added at addresses 0x000F0000 ~ 0x002EFFFF of ROM (IC206) and the result is displayed with 4-digit hexadecimal number. Error is not detected. Compare the result with the specified value.
- (2-4) Model Type
 Model code is displayed.
 Error: Not detected.
 The model code read from EEPROM (IC201) is displayed with 2-digit hexadecimal number.

	Model Type	
DVP-S525D	2	3
DVP-S725D	4	3

- (2-5) Region
 Region code is displayed.
 Error: Not detected.
 The region code determined from the model code is displayed.

3. Peripheral

- (3-2) Gate Array Check
 Data write → read, and accord check
 Error 02: Gate array write/read discord
 Data 0x00~0xFF are written to the address 0xF of GA (IC601), then read and checked if they accord.
- (3-3) EEPROM Check
 Data write → read, and accord check
 Error 03: EEPROM write/read discord
 Data 0x9249, 0x2942, 0x4294 are written to addresses 0x00~0xFF of EEPROM (IC201), then read and checked. Before writing, the data are saved, then after checking, they are written to restore the contents of EEPROM.
- (3-4) NAND Flash Check
 Data clear → write → read, and accord check
 This check is conducted to the DVP-S725D only.
 Error 04: Clear error
 05: Write error
 06: Read data discord
 21: Faulty blocks exceed 10
 The data clear, write, read, and check are executed to the block 0 of Flash memory (IC602).
 In case of a faulty block, its address is displayed.
 An error is output if faulty blocks exceed 10.

4. Servo

- (4-2) Servo DSP Check
 Data write → read, and accord check
 Error 12: Read data discord
 Data 0x9249, 0x2942, 0x4294 are written to the address 0x602 of RAM in the Servo DSP (IC701), then read and checked.
- (4-3) DSP Driver Test
 Test signal data → DSP Driver
 Error: Not detected.

Caution: Do not conduct this test with a mechanical deck connected.

The maximum voltage is applied to the Servo Driver IC (IC801, IC802). If mechanical deck is connected, the motor and optics could be damaged. Disconnect mechanical deck following the output message, then enter specified 4- or 5-digit number from the remote commander, and press the **[ENTER]**. The test is conducted only when the input data accord. Check the output level, then press the **[NEXT]** to finish the test.
 This test is skipped if “All” is selected.

Supplement: How to disconnect mechanical deck
 Disconnect flat cables connected to the CN002 and CN003 of MB-85 board. Also, disconnect harness from the CN011.

5. Supply

- Caution: Do not conduct this check with a mechanical deck connected.
 An access is made to the stream supply and servo control IC (IC303) and external RAM (IC304) using check data. If mechanical deck is connected, the motor and optics could be damaged. This check is also executed by the “All” menu item.

Supplement: How to disconnect mechanical deck
 Disconnect flat cables connected to the CN002 and CN003 of MB-85 board. Also, disconnect harness from the CN011.

- (5-2) ARP Register Check
 Data write → read, and accord check
 Error 08: ARP register write, and read data discord
 Data 0x00 to 0xFF are written to the TMAX register (address 0xC6) in ARP (IC303), then they are read and checked.
- (5-3) ARP to RAM Data Bus
 Data write → read, and accord check
 Error 09: ARP ↔ RAM data bus error
 Data 0x0001 to 0x8000 where one bit each is set to 1 are written to the address 0 of RAM (IC304) connected to the ARP (IC303) through the bus, then they are read and checked. In case of discord, written bit pattern and read data are displayed. If data where multiple bits are 1 are read, the bits concerned may touch each other. Further, if data where certain bit is always 1 or 0 regardless of written data, the line could be disconnected or shorted.

(5-4) ARP to RAM Address Bus

Data write → other address read discord check

Error 10: ARP → RAM address bus error

Caution: Address and data display in case of an error is different from the display of other diagnosis (described later).

Before starting the test, all addresses of RAM (IC304) are cleared to 0x0000.

First, 0xA55A is written to the address 0x00000, and the address data are read and checked from addresses 0x00001 to 0x80000 while shifting 1 bit each. Next, the data at that address is cleared, and it is written to the address 0x00001, and read and checked in the same manner. This check is repeated up to the address 0x80000 while shifting the address data by 1 bit each.

If data other than 0 is read at the addresses except written address, an error is given because all addresses were already cleared to 0. In this check, the error display pattern is different from that of other diagnosis; read data, written address, and read address are displayed in this order. However, the message uses same template, and accordingly exchange Address and Data when reading. The following display, for example,

```
### Syscon Diagnosis ###

5-4. ARP to RAM Address Bus
Error 10: ARP - RAM Address B
Address   : 0000A55A
Write Data: 00000000
Read Data : 00080000
Press NEXT Key to Continue
Press PREV Key to Repeat
—
```

shows the data 0xA55A was read from address 0x00080000 though it was written to the address 0x00000000. This implies that these addresses are in the form of shadow. Also, if the read data is not 0xA55A, another error will be present.

(5-5) ARP RAM Check

Data write → read, and accord check

Error 11: ARP RAM read data discord

The program code data stored in ROM are copied to all areas of RAM (IC304) connected to the ARP (IC303) through the bus, then they are read and checked if they accord. If the detail check was selected initially, the data are written to all areas and read, then the same test is conducted once again with the data where all bits are inverted between 1 and 0. If discord is detected, faulty address, written data, and read data are displayed following the error code 11, and the test is suspended.

6. AV Decoder

(6-2) 1930 RAM

Data write → read, and accord check

Error 13: AVD RAM read data discord

The program code data stored in ROM (IC206) are copied to all areas of RAM (IC402, IC403) connected to the AVD (IC401) through the bus, then they are read and checked if they accord. Further, the same test is conducted once again with the data where all bits are inverted between 1 and 0. If discord is detected, faulty address, written data, and read data are displayed following the error code 13, and the test is suspended.

(6-3) 1930 SP

ROM → AVD RAM → Video OUT

Error: Not detected.

The data including sub picture streams in ROM (IC206) are transferred to the RAM (IC402, IC403) in AVD (IC401), and output as video signals from the AVD (IC401).

They are output from all video terminals (Composite, Y/C, Component) except EURO AV terminal.

7. Video

(7-2) Color Bar

AVD color bar command write → Video OUT

Error: Not detected.

The command is transferred to the AVD, and the color bar signals are output from video terminals.

They are output from all video terminals (Composite, Y/C, Component) except EURO AV terminal.

(7-3) Composite Out

EURO-AV Composite video output check

AVD color bar command write → Video (EURO-AV Composite) OUT

Error: Not detected.

With the Component of video output turned off, the color bar signals are output from the EURO-AV terminal.

(7-4) Y/C Out

EURO-AV Y/C video output check

AVD color bar command write → Video (EURO-AV Y/C) OUT

Error: Not detected.

With the Y/C of video output turned on, the color bar signals are output from the EURO-AV terminal.

(7-5) RGB Out

EURO-AV RGB video output check

AVD color bar command write → Video (EURO-AV RGB) OUT

Error: Not detected.

With the RGB of video output turned on, the color bar signals are output from the EURO-AV terminal.

(7-6) Component Out

EURO-AV Component video output check

AVD color bar command write → Video (EURO-AV Component) OUT

Error: Not detected.

With the Component of video output turned on, the color bar signals are output from the EURO-AV terminal.

(7-7) Euro AV Through

Euro-AV2 input check.

Check video and audio signal pass through from Euro-AV2 to Euro-AV1.

Error: Not detected.

8. Audio

(8-2) ARP → 1930

Error 14 : ARP → 1930 video NG

15 : ARP → 1930 audio NG

(8-3) Test Tone

A pink noise signal is output from the AVD (IC401) through optical coaxial digital terminal and analog audio terminal.

Error: Not detected.

All channels → 2ch Left → 2ch Right → Front Left → Front Right → Rear Left → Rear Right → Center → Sub Woofer are checked in this order.

Caution: Sub Woofer is checked only for low-frequency components, and no sound will be heard unless a proper super woofer is connected.

Check Items List

2) Version

(2-2) Revision

(2-3) ROM Check Sum

(2-4) Model Type

(2-5) Region

3) Peripheral

(3-2) Gate Array Check

(3-3) EEPROM Check

(3-4) NAND Flash Check (DVP-S725D)

4) Servo

(4-2) Servo DSP Check

(4-3) DSP Driver Test

5) Supply

(5-2) ARP Register Check

(5-3) ARP to RAM Data Bus

(5-4) ARP to RAM Address Bus

(5-5) ARP RAM Check

6) AV Decoder

(6-2) 1930 RAM

(6-3) 1930 SP

7) Video

(7-2) Color Bar

(7-3) Composite Out

(7-4) Y/C Out

(7-5) RGB Out

(7-6) Component Out

8) Audio

(8-2) ARP → 1930

(8-3) Test Tone

Error Codes List

00: Error not detected

01: RAM write/read data discord

02: Gate array NG

03: EEPROM NG

04: Flash memory clear error

05: Flash memory write error

06: Flash memory read data discord

08: ARP register read data discord

09: ARP ↔ RAM data bus error

10: ARP ↔ RAM address bus error

11: ARP RAM read data discord

12: Servo DSP NG

13: 1930 SDRAM NG

14: ARP → 1930 video NG

15: ARP → 1930 audio NG

16: 1910 UCODE download NG

17: System call error (function not supported)

18: System call error (parameter error)

19: System call error (illegal ID number)

20: System call error (time out)

21: NAND Flash faulty blocks exceed 10

90: Error occurred

91: User verification NG

92: Diagnosis cancelled

6-4. DRIVE AUTO ADJUSTMENT

On the Test Mode Menu screen, press **[1]** key on the remote commander, and the drive auto adjustment menu will be displayed.

```
## Drive Auto Adjustment ##

      Adjustment Menu

0. ALL
1. DVD-SL
2. CD
3. DVD-DL
4. SACD

Exit: RETURN
```

Normally, **[0]** is selected to adjust DVD (single layer), CD, DVD (dual layer), and SACD in this order. But, individual items can be adjusted for the case where adjustment is suspended due to an error. In this mode, the adjustment can be made easily through the operation following the message displayed on the screen.

The disc used for adjustment must be the one specified for adjustment. However, for SACD disc, use the player with initial data if the disc is not available.

0. ALL

Select **[0]** and press **[ENTER]** key, and the servo set data in EEPROM will be initialized. Then, 1. DVD-SL disc, 2. CD disc, 3. DVD-DL disc, and 4. SACD disc are adjusted in this order. Each time one disc was adjusted, it is ejected. Replace it with the specified disc following the message. Though the message to confirm whether discs other than SACD disc are adjusted is not displayed, you can finish the adjustment if pressing the **[STOP]** button. During adjustment of each disc, the measurement for disc type judgment is made. As automatic adjustment does not judge the disc type unlike conventional models, take care not to insert wrong type discs. Also, do not give a shock during adjustment.

1. DVD-SL (single layer)

Select **[1]**, insert DVD single layer disc, and press **[ENTER]** key, and the adjustment will be made through the following steps, then adjusted values will be written to the EEPROM.

DVD Single Layer Disc Adjustment Steps

1. SLED TILT Reset
2. Disc Check Memory SL
3. Wait 300 msec
4. Set Disc Type SL
5. LD ON
6. Spdl Start
7. Wait 1 sec
8. Focus Servo ON 0
9. Auto Track Offset Adjust
10. CLVA ON
11. Wait 500 msec
12. Tracking ON
13. Wait 1 sec
14. Sled ON
15. Check CLV Lock
16. Auto LFO Adjust
17. Auto Focus Offset Adjust
18. Auto Tilt Position Adjust
19. Auto Focus Gain Adjust
20. Auto Focus Offset Adjust
21. EQ Boost Adjust
22. Auto LFO Adjust
23. Auto Track Gain Adjust
- Search Check
24. 32Tj Fwd
25. 32Tj Rev
26. 500Tj Fwd
27. 500Tj Rev
28. All Servo Stop
29. Eep Copy Loop Filter Offset

2. CD

Select [2], insert CD disc, and press [ENTER] key, and the adjustment will be made through the following steps, then adjusted values will be written to the EEPROM.

CD Adjustment Steps

1. Sled Tilt Rest
2. Disc Check Memory CD
3. Wait 500 msec
4. Set Disc Type CD
5. LD ON
6. Spdl Start
7. Wait 500 msec
8. Focus Servo ON 0
9. Auto Track Offset Adjust
10. CLVA ON
11. Wait 500 msec
12. Tracking ON
13. (TC Display Start)
14. Wait 1 sec
15. Jitter Display Start
16. Sled ON
17. Check CLV ON
18. Auto LFO Adjust
19. Auto Focus Offset Adjust
- 20.
21. Auto Focus Gain Adjust
22. Auto Focus Offset Adjust
23. Eq Boost Adjust
24. Auto LFO Adjust
25. Auto Track Gain Adjust
Search Check
26. 32Tj Fwd
27. 32Tj Rev
28. 500Tj Fwd
29. 500Tj Rev
30. All Servo Stop

3. DVD-DL (dual layer)

Select [3], insert DVD dual layer disc, and press [ENTER] key, and the adjustment will be made through the following steps, then adjusted values will be written to the EEPROM.

DVD Dual Layer Disc Adjustment Steps

1. Sled Tilt Reset
2. Disc Check Memory DL
3. Wait 500 msec
4. Set Disc Type DL
5. LD ON
6. Spdl Start
7. Wait 1 sec
Layer 1 Adjust
8. Focus Servo ON 1
9. Auto Track Offset Adjust
10. Clva ON
11. Wait 500 msec
12. Tracking ON
13. Wait 500 msec
14. Sled ON
15. Check CLV Lock
16. Auto Loop Filter Offset Auto Focus Adjust
- 17.
18. Auto Focus Gain Adjust
19. Auto Focus Offset Adjust
20. Eq Boost Adjust
21. Auto Loop Filter Offset
22. Auto Track Gain Adjust
Search Check
23. 32Tj Fwd
24. 32Tj Rev
25. 500Tj Fwd
26. 500Tj Rev
Layer 0 Adjust
27. Fj (L1 → L0)
28. Auto Track Offset Adjust L0
29. Clva ON
30. Wait 500 msec
31. Tracking ON
32. Wait 500 msec
33. Sled ON
34. Check CLV Lock
35. Auto Focus Filter Offset
36. Auto Focus Adjust
- 37.
38. Auto Focus Gain Adjust
39. Auto Focus Offset Adjust
40. Eq Boost Adjust
41. Auto Loop Filter Offset
42. Auto Track Gain Adjust
Search Check
43. 32Tj Fwd
44. 32Tj Rev
45. 500Tj fwd
46. 500Tj Rev
Layer Jump Check
47. Lj (L0 → L1)
48. Lj (L1 → L0)
49. All Servo Stop

4. SACD

Select [4], insert SACD disc, and press [ENTER] key, and the adjustment will be made through the following steps, then adjusted values will be written to the EEPROM. However, if SACD disc is not available, use the player with initial data, skipping the SACD adjustment. In this case, you can finish the adjustment if pressing the [STOP] button.

SACD Adjustment Steps

1. Sled Tilt Reset
2. Set Disc Type CD
3. LD ON
4. Spdl Start
5. Wait 500 msec
6. Focus Servo ON 0
7. Auto track Offset Adjust
- 8.
9. CLVA ON
10. Wait 500 msec
11. Tracking ON
12. Wait 1 sec
13. Sled ON
14. Check CLV ON
15. Auto Focus Offset Adjust
- 17.
18. Auto Focus Gain Adjust
19. Auto Focus Offset Adjust
20. Eq Boost Adjust
21. Auto LFO Adjust
22. Auto Track Gain Adjust

23. 32Tj Fwd
24. 32Tj Rev
25. 500Tj Fwd
26. 500Tj Rev

27. All Servo Stop

6-5. DRIVE MANUAL OPERATION

On the Test Mode Menu screen, select [2], and the manual operation menu will be displayed. For the manual operation, each servo on/off control and adjustment can be executed manually.

```
## Drive Manual Operation ##

          Operation Menu
1. Disc type
2. Servo Control
3. Track/Layer Jump
4. Manual Adjustment
5. Auto Adjustment
6. Memory Check

0. Disc Check Memory

          Exit: Return
```


In using the manual operation menu, take care of the following points. These commands do not provide protection, thus requiring correct operation. The sector address or time code field is displayed when a disc is loaded.

1. Set correctly the disc type to be used on the Disc Type screen.
The disc type must be set after a disc was loaded.
The set disc type is cleared when the tray is opened.
2. After power ON, if the Drive Manual Operation was selected, first perform "Reset SLED TILT" by opening 1. Disc Type screen.
3. In case of an alarm, immediately press the [STOP] button to stop the servo operation, and turn the power OFF.

Basic operation (controllable from front panel or remote commander)

[POWER]	Power OFF
[STOP]	Servo stop
[OPEN/CLOSE]	Stop+Eject/Loading
[RETURN]	Return to Operation Menu or Test Mode Menu
[NEXT], [PREV]	Transition between sub modes of menu
[1] to [9], [0]	Selection of menu items
Cursor UP/DOWN	Increase/Decrease in manually adjusted value

0. Disc Check Memory



On this screen, the mirror time is measured to judge the disc and it is written to the EEPROM. First load DVD SL disc and press [1], next load CD disc and press [2], and finally load DVD DL disc and press [3].


The adjustment must be executed more than once after default data were written. External vibration or shock to the player must not be given. Reference value for DVD is from 10 to 20, and for CD, from 28 to 4F.

Check that the value of CD is larger than that of DVD.

When those values are beyond a range perform this adjustment again.

From this screen, you can go to another mode by pressing [NEXT] or [PREV] key, but you cannot enter this mode from another mode. You can enter this mode from the Operation Menu screen only.


1. Disc Type




On this screen, select the disc type. To select the disc type, press the number of the loaded disc. The selected disc type is displayed at the bottom. Selecting [1] automatically selects and displays the disc type. In case of wrong display, retry "Disc Check Memory". Also, opening the tray causes the set disc type to be cleared. In this case, set the disc type again after loading.

In performing manual operation, the disc type must be set.

Once the disc type has been selected, the sector address or time code display field will appear as shown below. These values are displayed when PLL is locked.



Display when DVD SL 12cm disc was selected



Display when CD 12cm disc was selected


[0] Reset SLED TILT Reset the Sled and Tilt to initial position.

[1] Disk Type Check Judge automatically the loaded disc. As the judged result is displayed at the bottom of screen, make sure that it is correct.

If Disc Check Memory menu has not been executed after EEPROM default setting, the disc type cannot be judged. In this case, return to the initial menu and make a check for three types of discs (SL, DL, CD).

[2] to [9] Select the loaded disc. The adjusted value is written to the address of selected disc. No further entry is necessary if [1] was selected.

2. Servo Control



On this screen, the servo on/off control necessary for replay is executed. Normally, turn on each servo from 1 sequentially and when CLVA is turned on, the usual trace mode becomes active. In the trace mode, DVD sector address or CD time code is displayed. This is not displayed where the spindle is not locked.

The spindle could run overriding the control if the spindle system is faulty or RF is not present. In such a case, do not operate CLVA.

[0] Reset SLED TILT	Reset the Sled and Tilt to initial position.
[1] LD	Turn ON/OFF the laser.
[2] SP	Turn ON/OFF the spindle.
[3] Focus	Search the focus and turn on the focus.
[4] TRK	Turn ON/OFF the tracking servo.
[5] Sled	Turn ON/OFF the sled servo.
[6] CLVA	Turn ON/OFF normal servo of spindle servo.
[7] FCS. Srch	Apply same voltage as that of focus search to the focus drive to check the focus drive system.
→ Sled FWD	Move the sled outward. Perform this operation with the tracking servo turned off.
← Sled REV	Move the sled inward. Perform this operation with the tracking servo turned off.
↑ Tilt UP	Move the tilt upward.
↓ Tilt DOWN	Move the tilt downward.

The following menus are normally not used.

3. Track/Layer Jump

4. Manual Adjustment

5. Auto Adjustment

The persons who do not know well about these menus should not use them.

6. Memory Check

EEPROM DATA				
	CD	- DVD -		
ID No. 00	SACD	SL	L0	L1
Focus Gain	xx xx	xx	xx	xx
TRK. Gain	xx xx	xx	xx	xx
Focus Offset	xx xx	xx	xx	xx
TRK. Offset	xx xx	xx	xx	xx
L. F. Offset	xx xx	xx	xx	xx
EQ Boost	xx xx	xx	xx	xx
Jitter	xx xx	xx	xx	xx
Mirror Time	xx xx	xx	xx	xx
- CLEAR: Default Set				

This screen displays current servo adjusted data stored in the EEPROM. Though adjusted data can be initialized with the [CLEAR] key, they cannot be restored after initialization.

So, before clearing, make a note of the adjusted data.

For reference, the drive has been designed so that the gain center value is 20 and offset value is 80. Other values will be in a range of 10 to 80. If extreme value such as 00 or FF is set, adjustment will be faulty. In such a case, check for disc scratch or cable disconnection, then perform adjustment again.

6-6. MECHA AGING

### Mecha Aging ###	
Press OPEN key	
Abort: STOP key	

On the Test Mode Menu screen, selecting [3] executes the aging of mechanism. First, open the tray and load a disc. Press the [PLAY] key, and the aging will start. When the tray is closed, the disc type and size are judged and displayed. During aging, the repeat cycle is displayed. Aging can be aborted at any time by pressing the [STOP] key. After the operation has stopped, unload the disc and press again the [STOP] key or the [RETURN] key to return to the Test Mode Menu.

6-7. EMERGENCY HISTORY

### MEG. History ###	
Laser Hours	CD xxxxxxxh
	DVD xxxxxxxh
1. 00 00 00 00 00 00 00 00	
00 00 00 00 00 00 00 00	
2. 00 00 00 00 00 00 00 00	
00 00 00 00 00 00 00 00	
Select: 1 - 9	Scroll: UP/DOWN
(1: Last EMG.)	Exit: Return

On the Test Mode Menu screen, selecting [4] displays the information such as servo emergency history. The history information from last 1 up to 10 can be scrolled with [↑] key or [↓] key. Also, specific information can be displayed by directly entering that number with ten keys.

The upper two lines display the laser ON total hours. Data below minutes are omitted.

Clearing History Information

Clearing laser hours

- ◎ Press [DISPLAY] and [CLEAR] keys in this order.
Both CD and DVD data are cleared.

Clearing emergency history


- ◎ Press [TITLE] and [CLEAR] keys in this order.

Initializing set up data

- ◎ Press [DVD] and [CLEAR] keys in this order.

The data have been initialized when "Set Up Initialized" message is displayed. The EMG. History screen will be restored soon.

How to see Emergency History



①: Emergency Code

②: Don't Care

These codes are used for verification of software designing.

③: Historical order 1 to 9

Emergency Codes List

- 10: Communication to IC001 (TK-54 board) failed.
- 11: Each servo for focus, tracking, and spindle is unlocked.
- 12: Communication to EEPROM, IC201 (MB-85 board) failed.
- 13: Writing of hours meter data to EEPROM, IC201 (MB-85 board) failed.
- 14: Communication to Servo DSP IC701 (MB-85 board) failed, or Servo DSP is faulty.
- 20: Initialization of tilt servo and sled servo failed. They are not placed in the initial position.
- 21: Tilt servo operation error
- 22: Syscon made a request to move the tilt servo to wrong position.
- 23: Sled servo operation error
- 24: Syscon made a request to move the sled servo to wrong position.
- 30: Tracking balance adjustment error
- 31: Tracking gain adjustment error
- 32: Focus balance adjustment error
- 33: Focus bias adjustment error
- 34: Focus gain adjustment error
- 35: Tilt servo adjustment error
- 36: RF equalizer adjustment error
- 37: RF group delay adjustment error
- 38: Jitter value after adaptive servo operation is too large.
- 40: Focus servo does not operate.
- 41: With a dual layer (DL) disc, focus jump failed.
- 50: CLV (spindle) servo does not operate.
- 51: Spindle does not stop.
- 60: With a DVD disc, Syscon made a request to seek nonexistent address.
- 61: With a CD disc, Syscon made a request to seek nonexistent address.
- 62: With a CD disc, Syscon made a request to seek nonexistent track No. and index No.
- 63: With a DVD disc, seeking of target address failed.
- 64: With a CD disc, seeking of target address failed.
- 65: With a CD disc, seeking of target index failed.
- 70: With a DVD disc, physical information data could not be read.
- 71: With a CD disc, TOC data could not be read.
- 80: Disc type judgment failed.
- 81: As disc type judgment failed, retry was repeated.
- 82: As disc type judgment failed, a measurement error occurred.
- 83: Disc type could not be judged within the specified time.
- 84: Illegal command code was received from Syscon.
- 85: Illegal command was received from Syscon.

6-8. VERSION INFORMATION

## Version Information ##			
IF con.	Ver. x.	xxx (xxxx)	
	Group	00	
SYScon.	Ver. x.	xxx (xxxx)	
	Model	xx	
	Region	0x	
	SW1	??	
	SW2	??	
Exit: RETURN			

On the Test Mode Menu screen, selecting [5] displays the ROM version and region code.

The parenthesized hexadecimal number in version field is checksum value of ROM.

6-9. VIDEO LEVEL ADJUSTMENT


On the Test Mode Menu screen, selecting [6] displays color bars for video level adjustment. During display of color bars, OSD disappears but the menu screen will be restored if pressing any key.

Measurement point : LINE OUT VIDEO
(75 Ω terminating resistance)

Measuring instrument : Oscilloscope

Adjustment device : RV401 on MB-85 board

Specified value : 1.0 ± 0.02 Vp-p



6-10. IF CON SELF DIAGNOSTIC FUNCTION

1. FRONT BOARD TEST MODE

The front board test mode is the IF CON self diagnostic mode. The IF CON can diagnose the functions of the front panel boards that the IF CON controls. Normally, the IF CON makes a serial communication with the SYSTEM CONTROL and operates following the commands from the SYSTEM CONTROL, but in the Test mode, the IF CON operates independently from the SYSTEM CONTROL.

In the Test mode, the following functions can be checked.

1. Button function
2. Remocon receiving function
3. SYSTEM CONTROL-IF CON serial communication
4. Direct search dial function
5. Click shuttle function
6. Fluorescent display tube lighting check
Grid check
Anode check
7. LED control function

In the Test mode, the set operates same as usual, except voltage monitoring, communication monitoring, display of fluorescent display tube, and LED control.

1. The routine that monitors +3.3 V (PCONT) of MB-85 board is not provided.
2. The monitoring timer for serial communication with the SYSTEM CONTROL is not provided. The set is not placed in the Standby mode, even if the communication with SYSTEM CONTROL is normal.
3. Display of fluorescent display tube (normally, display is made following the commands from SYSTEM CONTROL)
4. LED control (normally, control is made following the commands from SYSTEM CONTROL)

2. HOW TO ENTER THE TEST MODE

The set must be placed in the Standby mode (red LED lights up). In the Standby mode, press the **[SET UP]** key on the Remocon while pressing simultaneously the **[RETRUN]** button and **[STOP]** button on the set, so that the set enters the Test mode.

When the Test mode becomes active, the automatic display sequence of the FL display tube starts.

1. LEDs and FL display tube all light up for about 5 seconds.
2. Then, the prototypical model name is displayed.
(This model name is a typical name of the series. As the button arrangement varies depending on the model, make sure the difference.)

Display	Model
DPX-1230	DVP-S525D
DPX-1226	DVP-S725D

3. Last updating date of the program is displayed.
Example: 981211
4. Following the "GRID TEST" display, odd grids and even grids are blinking alternately (3 times).
5. Following the "ANODE TEST" display, even anodes and odd anodes are blinking alternately (3 times). For the FL display tube type A, even and odd numeric parts of music calendar are blinking alternately (3 times).
6. All light-up mode restores.

Steps 1 through 6 are repeated. (Refer to "FLD Auto Test Operation" on page 6-12)


3. HOW TO EXIT FROM THE TEST MODE

Press the **[POWER]** buttons on the set and Remocon, and the FL display tube turns off and the Standby mode is restored where only the red POWER LED lights up. This is the case where the SYSTEM CONTROL and IF CON are communicating normally. To forcibly activate the Standby mode, press the **[POWER]** button together with the **[STOP]** button.


FLD Auto Test Operation

The auto test starts when the **[STOP]** and **[RETURN]** buttons on the set and the **[SET UP]** key on the Remocon are pressed at the power off.


① FLD all light up (5 sec)



② TEST START display (2 sec) This is not displayed after second and subsequent tests.




③ Model display (2 sec)




Note: Prototypical model name of the series is displayed.


④ Date display (2 sec) Program updating date is displayed.




⑤ GRID TEST start display (1 sec)




⑥ FLD odd grids light up (0.7 sec)





⑦ FLD even grids light up (0.7 sec)




Note: Displays of ⑥ and ⑦ are repeated three times.




⑧ FLD ANODE TEST display No.1 (1 sec)




⑨ FLD even anodes light up (0.7 sec)




Note: Also, even anodes of alphanumeric section light up.



⑩ FLD odd anodes light up (0.7 sec)



Note: Also, odd anodes of alphanumeric section light up.
Note: Displays of ⑨ and ⑩ are repeated three times.



Hence, the operations of ① through ⑩ are repeated.
However, ② is not displayed after the second and subsequent tests.

4. DESCRIPTION OF IF CON FUNCTION CHECK MODE

1. Button Function

In the Test mode, press any button (except **POWER** button) on the set. This operation terminates the automatic display test mode of the FL display tube. During the time that the button is pressed, the function name of the pressed button is displayed on the FL display tube, and “NOTHING” is displayed if releasing the button. For the button names displayed, refer to the following table. For the illuminated button (LED built in), it turns on and off alternately each time it is pressed. For the multi-channel LED (blue LED), it blinks when the “RETURN” button is pressed because its dedicated button is not provided.

DVP-S525D:

	Input Voltage [V]	IC201: Pin No. (Signal)		
		Pin ⑥ (AN0)	Pin ⑤ (AN1)	Pin ④ (AN2)
1	0	STOP	POWER	REPEAT
2	0.65	PAUSE	OPEN/CLOSE	CLEAR
3	1.24	←	PLAY	PROGRAM
4	1.88	↓	TITLE	SHUFFLE
5	2.41	ENTER	DVD MENU	SURROUND
6	2.92	↑	RETURN	
7	3.45	→	PREVIOUS	
8	3.94	JOG	NEXT	

DVP-S725D:

	Input Voltage [V]	IC201: Pin No. (Signal)		
		Pin ⑥ (AN0)	Pin ⑤ (AN1)	Pin ④ (AN2)
1	0	STOP	POWER	REPEAT
2	0.65	PAUSE	OPEN/CLOSE	CLEAR
3	1.24	←	PLAY	PROGRAM
4	1.88	↓	TITLE	SHUFFLE
5	2.41	ENTER	DVD MENU	SURROUND
6	2.92	↑	RETURN	
7	3.45	→	SEARCH-REV	
8	3.94	JOG	SEARCH-FWD	
9	4.52	ACS ENTER		

The direction buttons are used to enter special modes.

- ↑ : FL display tube grid check
- ↓ : LED check
- ← : Direct search dial check
- : FL display tube anode check

The buttons are all checked with the voltage at the A/D port. The reference voltage of A/D port is ever 5V. The voltage is calculated at 10bit accuracy and evaluated whether same voltage can be obtained in two-time operations to eliminate the chattering. For the button check by the IF CON, a dead zone is provided, and if voltage in the dead zone is entered, “IGNORE” is displayed.

2. Remocon Receiving Function

Upon reception of a code from the Remocon when “NOTHING” is displayed, the function name of Remocon code is displayed on the FL display tube. The codes that can be received are DVD category codes only. The “DISPLAY” on Remocon functions to change over the function name display and the code display. In the code display mode, “REM NO xx” is displayed. A xx part is the received code in Hex notation. It is FF when a Remocon code is not received.

3. SYSTEM CONTROL-IF CON Serial Communication

Normally, two-way communication at 24ms interval is made between IF CON and SYSTEM CONTROL. Whether this communication is carried out normally can be checked easily. When “NOTHING” is displayed, OFF display of “VIDEO CD”, “DVD”, and “CD” characters on the left side of FL display tube indicates that a serial communication with the SYSTEM CONTROL is carried out normally. ON display of these characters indicates that the communication with the SYSTEM CONTROL is not made. However, the communication is not made for several seconds after the Test mode became active (until MB-85 board is initialized), and these characters may turn on. This status is normal.

4. Direct Search Dial



The grid X part displays images that rotate. At the same time, the numbers on music calendar shift toward the direction in which the direct search dial was rotated.
(Though this is displayed on the models which do not have the dial, it does not function because of no dial.)

5. Click Shuttle

Whether the IF CON can judge the rotation of click shuttle is checked. In the following grid check and anode check, if the part that lights up is shifted as the click shuttle rotates, the function is normal.

6. Display of Fluorescent Display Tube

Use this mode when checking the FL display tube precisely, though the FL display tube is roughly checked in the auto display mode. Press simultaneously the **STOP** and **PLAY** buttons on the set, so that the FL display tube can all be lighted up.



(2G~12G)

ANODE CONNECTION

(Grid)

	1G	2G	3G	4G	5G	6G	7G	8G	9G	10G	11G	12G	13G
P1	ANGLE	a	a	a	a	a	a	a	a	a	a	a	1
P2	PBC	h	h	h	h	h	h	h	h	h	h	h	2
P3	1	j	j	j	j	j	j	j	j	j	j	j	3
P4	REPEAT	k	k	k	k	k	k	k	k	k	k	k	4
P5	PGM	b	b	b	b	b	b	b	b	b	b	b	5
P6	A-	f	f	f	f	f	f	f	f	f	f	f	6
P7	B	m	m	m	m	m	m	m	m	m	m	m	7
P8	SHUFFLE	s	s	s	s	s	s	s	s	s	s	s	8
P9	DTS	g	g	g	g	g	g	g	g	g	g	g	9
P10	MPEG	c	c	c	c	c	c	c	c	c	c	c	10
P11	Digital	e	e	e	e	e	e	e	e	e	e	e	11
P12	CD	n	n	n	n	n	n	n	n	n	n	n	12
P13	DVD	p	p	p	p	p	p	p	p	p	p	p	13
P14	VIDEO CD	r	r	r	r	r	r	r	r	r	r	r	14
P15	II	d	d	d	d	d	d	d	d	d	d	d	15
P16	▶	NTSC	TRACK	CHAPTER	-	-	-	Dp	-	Dp	-	-	▶
P17	-	DISC	TITLE	INDEX	-	-	-	HOUR	-	MIN	-	SEC	-

7. Grid Check (⬆ button: Grid Check Mode)

In this mode, arbitrary one grid of FL display tube lights up. (The anodes of the grid concerned all light up.) To shift the grids, use the click shuttle on the set. For the models not having the click shuttle, the DVD Remocon having the click shuttle can be used instead.

Starting from G1, rotate the click shuttle clockwise, and the grids shift such as G2, G3 G16. The grids return to G1 following G16.

During this mode, any one grid always lights up.

8. Anode Check (⬅ button: Anode Check Mode)

In this mode, arbitrary one anode of FL display tube lights up. (All grids of the anode concerned all light up.)

Starting from P1, rotate the click shuttle clockwise, and the anodes shift such as P2, P3 The anodes return to P1 following the last anode. During this mode, one anode of all grids always lights up. For the models not having the click shuttle, the DVD Remocon having the click shuttle can be used instead.

9. LED Control

In this mode, LEDs, one by one, light up by pressing the ⬇ button. Rotating the click shuttle causes the LED that lights up to be shifted. For the illuminated buttons, the built-in LEDs turn on and off each time the buttons are pressed, independently from this mode.

5. TROUBLESHOOTING

1. Test Mode is not activated

With the set assembled in the front panel, the Test mode does not become active if any button was pressed by any reason. Under this condition, the power is not turned on even in the normal status. (The set is kept in Standby status = Red LED is kept on) Not only the buttons are inactive, but also a signal from Remocon is not accepted. To check this condition, with the self check port (pin ⑥ of IF CON) kept in "Low" status, supply the AC power, so that the Test mode is forcibly activated. On the board, short the lands where SELF is printed. The IF CON checks the self check port only after the power on reset (only when AC is supplied; not in Standby status). If any button was pressed, the button name should be displayed on the FL display tube. Though no button is pressed this time, display of other than NOTHING implies that the button was pressed. However, the set will go in Standby status immediately unless the FFC (pin ⑩) connected to the MB-85 board is disconnected in advance.

2. Power is not turned on

- ① Red (STANDBY) LED does not light up when AC was supplied. The power (EVER 5V) is not supplied.
X201 is oscillating.
Loose connection of the connector between FL board and FR board.
- ② Red (STANDBY) LED is kept on though POWER button was pressed. Any button is kept pressed.
PCHECK (IF CON pin ⑦) is over 0.1V.
- ③ Green LED lights up when POWER button was pressed, but red LED lights up again after several seconds. PCHECK (IF CON pin ⑦) is abnormal. (Slow rise time from 0.1V to 1.5V. Voltage must be less than 1.5V)
SYSTEM CONTROL does not operate normally.

SECTION 7

ELECTRICAL ADJUSTMENT

In making adjustment, refer to 7-3. Adjustment Related Parts Arrangement.

Note: During diagnostic check, the characters and color bars can be seen only with the NTSC monitor. Therefore, for diagnostic check, use the monitor that supports both NTSC and PAL modes.

Use the reference disc for PAL for check, and use the reference disc for NTSC for adjustment.

This section describes procedures and instructions necessary for adjusting electrical circuits in this set.

Instruments required:

- 1) Color monitor TV
- 2) Oscilloscope 1 or 2 phenomena, band width over 100 MHz, with delay mode
- 3) Frequency counter (over 8 digits)
- 4) Digital voltmeter
- 5) Standard commander (RMT-D108P/D111P)
- 6) DVD reference disc
 - HLX-501 (J-6090-071-A) (dual layer) (NTSC)
 - HLX-503 (J-6090-069-A) (single layer) (NTSC)
 - HLX-504 (J-6090-088-A) (single layer) (NTSC)
 - HLX-505 (J-6090-089-A) (dual layer) (NTSC)
 - HLX-506 (J-6090-077-A) (single layer) (PAL)
 - HLX-507 (J-6090-078-A)(dual layer) (PAL)
- 7) SACD reference disc
 - HLXA-509 (J-6090-090-A)

7-1. POWER SUPPLY ADJUSTMENT

1. HS-030SH Board

Mode	E-E
Instrument	Digital voltmeter
+5 V Check	
Test point	CN202 pin ⑤
Specification	5.0 ± 0.2 Vdc
+3.3 V Check	
Test point	CN202 pin ⑦
Specification	3.3 ± 0.2 Vdc
EVER+5 V Check	
Test point	CN203 pin ②
Specification	5.0 ± 0.2 Vdc
P_CONT Check	
Test point	CN203 pin ①
Specification	4V – 5 Vdc
A +12 V Check	
Test point	CN202 pin ①
Specification	$9.5^{+1.5}_{-0.5}$ Vdc
–12 V Check	
Test point	CN203 pin ⑤
Specification	-12.0 ± 1.0 Vdc
M +12 V Check	
Test point	CN202 pin ②
Specification	12.0 ± 1.0 Vdc

Checking method:

- 1) Confirm that each voltage satisfies the specification.

7-2. ADJUSTMENT OF VIDEO SYSTEM

1. Video Level Adjustment (MB-85 BOARD)

<Purpose>

This adjustment is made to satisfy the NTSC standard, and if not adjusted correctly, the brightness will be too large or small.

Mode	Video level adjustment in test mode
Signal	Color bars
Test point	LINE OUT (VIDEO) connector (75 Ω terminated)
Instrument	Oscilloscope
Adjusting element	RV401
Specification	1.0 ± 0.02 Vp-p

Adjusting method:

- 1) In the test mode initial menu "6" Video Level Adjustment, set so that color bars are generated.
- 2) Adjust the RV401 to attain 1.0 ± 0.02 Vp-p.




Figure 7-1

2. S-terminal Output Check (MB-85 BOARD)

<Purpose>

Check S-terminal video output. If it is incorrect, pictures will not be displayed correctly in spite of connection to the TV with a S-terminal cable.

Mode	Video level adjustment in test mode
Signal	Color bars
Test point	S VIDEO OUT (S-Y) connector (75 Ω terminated)
Instrument	Oscilloscope
Specification	1.0 ± 0.1 Vp-p

Checking method:

- 1) In the test mode initial menu "6" Video Level Adjustment, set so that color bars are generated.
- 2) Confirm that the S-Y level is 1.0 ± 0.1 Vp-p.



Figure 7-2

3. Checking Component Video Output B-Y (MB-85 BOARD) (DVP-S725D)

<Purpose>

This checks component video output B-Y. If it is incorrect, correct colors will not be displayed when connected to, for instance, projector.

Mode	Video level adjustment in test mode
Signal	Color bars
Test point	COMPONENT VIDEO OUT (B-Y) connector (75 Ω terminated)
Instrument	Oscilloscope
Specification	700 ± 70 mVp-p

Checking method:

- 1) Confirm that the B-Y level is 700 ± 70 mVp-p.




Figure 7-3

4. Checking Component Video Output R-Y (MB-85 BOARD) (DVP-S725D)

<Purpose>

This checks component video output R-Y. If it is incorrect, correct colors will not be displayed when connected to, for instance, projector.

Mode	Video level adjustment in test mode
Signal	Color bars
Test point	COMPONENT VIDEO OUT (R-Y) connector (75 Ω terminated)
Instrument	Oscilloscope
Specification	700 ± 70 mVp-p

Checking method:

- 1) Confirm that the R-Y level is 700 ± 70 mVp-p.



Figure 7-4

5. Checking Component Video Output Y (MB-85 BOARD) (DVP-S725D)

<Purpose>

This checks component video output Y. If it is incorrect, correct brightness will not be attained when connected to, for instance, projector.

Mode	Video level adjustment in test mode
Signal	Color bars
Test point	COMPONENT VIDEO OUT (Y) connector (75 Ω terminated)
Instrument	Oscilloscope
Specification	1.0 ± 0.1 Vp-p

Checking method:

- 1) Confirm that the Y level is 1.0 ± 0.1 Vp-p.




Figure 7-5

6. Checking RGB Output R (MB-85 BOARD)

<Purpose>

This checks RGB output R. If it is incorrect, pictures will not be displayed correctly in spite of connection to the TV with an EURO AV connecting cord.

Mode	In test mode, Push [0] for Syscon Diagnosis and push [7] for Video and push [5] for RGB out
Signal	Color bars
Test point	EURO AV 1 (RGB)-TV connector pin ⑩ (75 Ω terminated)
Instrument	Oscilloscope
Specification	700 ± 70 mVp-p

Checking method:

- 1) Confirm that the R level is 700 ± 70 mVp-p.




Figure 7-6

7. Checking RGB Output G (MB-85 BOARD)

<Purpose>

This checks RGB output G. If it is incorrect, pictures will not be displayed correctly in spite of connection to the TV with an EURO AV connecting cord.

Mode	In test mode, Push [0] for Syscon Diagnosis and push [7] for Video and push [5] for RGB out
Signal	Color bars
Test point	EURO AV 1 (RGB)-TV connector pin ⑪ (75 Ω terminated)
Instrument	Oscilloscope
Specification	700 ± 70 mVp-p

Checking method:

- 1) Confirm that the G level is 700 ± 70 mVp-p.




Figure 7-7

8. Checking RGB Output B (MB-85 BOARD)

<Purpose>

This checks RGB output B. If it is incorrect, pictures will not be displayed correctly in spite of connection to the TV with an EURO AV connecting cord.

Mode	In test mode, Push [0] for Syscon Diagnosis and push [7] for Video and push [5] for RGB out
Signal	Color bars
Test point	EURO AV 1 (RGB)-TV connector pin ⑦ (75 Ω terminated)
Instrument	Oscilloscope
Specification	700 ± 70 mVp-p

Checking method:

- 1) Confirm that the B level is 700 ± 70 mVp-p.



Figure 7-8

9. Checking S Video Output S-C (MB-85 BOARD)

<Purpose>

This checks whether the S-C satisfies the NTSC Standard. If it is not correct, the colors will be too dark or light.

Mode	Video level adjustment in test mode
Signal	Color bars
Test point	S VIDEO OUT (S-C) connector (75 Ω terminated)
Instrument	Oscilloscope
Specification	286 \pm 50 mVp-p (NTSC) 300 \pm 100 mVp-p (PAL)

Checking method:


- 1) In the test mode initial menu "6" Video Level Adjustment, set so that color bars are generated.
- 2) Confirm that the S-C burst is 300 \pm 100 mVp-p.




Figure 7-9

7-3. ADJUSTMENT RELATED PARTS ARRANGEMENT

MB-85 BOARD (SIDE A)



HS-030SH BOARD (SIDE A)



SECTION 8
REPAIR PARTS LIST


8-1. EXPLODED VIEWS

NOTE:

- -XX and -X mean standardized parts, so they may have some difference from the original one.
- Items marked “*” are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- The mechanical parts with no reference number in the exploded views are not supplied.
- Hardware (# mark) list and accessories and packing materials are given in the last of the electrical parts list.


The components identified by mark Δ or dotted line with mark Δ are critical for safety. Replace only with part number specified.

8-1-1. CASE ASSEMBLY (S525D)




Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
1	3-056-508-01	EMBLEM, DVD		5	3-053-510-01	CASE, TOP	
2	3-053-498-01	COVER (BK), TRAY		6	3-973-973-01	FOOT (S)	
3	3-970-608-01	SUMITITE (B3), +BV		7	1-418-320-31	COMMANDER, STANDARD (RMT-D108P)	
4	3-710-901-41	SCREW, TAPPING		8	3-053-633-01	COVER, BATTERY (for RMT-D108P)	

8-1-2. CASE ASSEMBLY (S725D)




Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
51	3-053-493-01	ORNAMENT (M), TRAY		56	X-3949-707-1	CASE ASSY, TOP (BLACK)	
52	3-053-492-11	ORNAMENT (AL), TRAY (BLACK)		56	X-3949-708-1	CASE ASSY, TOP (SILVER)	
52	3-053-492-21	ORNAMENT (AL), TRAY (SILVER)		57	3-053-984-01	SCREW (+BV/CU)	
53	3-975-726-31	EMBLEM, DVD (SILVER)		58	X-3945-872-1	FOOT ASSY	
53	3-975-726-41	EMBLEM, DVD (BLACK)		59	1-418-321-31	COMMANDER, STANDARD (RMT-D111P)	
54	3-970-608-01	SUMITITE (B3), +BV		60	3-055-539-01	COVER, BATTERY (for RMT-D111P)	
55	3-710-901-41	SCREW, TAPPING (BLACK)		61	X-3949-298-1	COVER ASSY, TRAY (SILVER)	
55	3-710-901-51	SCREW, TAPPING (SILVER)		61	X-3949-299-1	COVER ASSY, TRAY (BLACK)	

8-1-3. FRONT PANEL ASSEMBLY



Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
101	X-3949-303-1	PANEL ASSY, FRONT (S525D)		113	3-053-482-01	KNOB (ACS) (BLACK)	
101	X-3949-308-1	PANEL ASSY, FRONT (BLACK) (S725D)		113	3-053-482-41	KNOB (ACS) (SILVER)	
101	X-3949-511-1	PANEL ASSY, FRONT (SILVER) (S725D)		114	3-988-016-01	STICK, CURSOR (BLACK)	
102	3-053-483-01	WINDOW (FL)		114	3-988-016-61	STICK, CURSOR (SILVER)	
103	3-974-997-31	WINDOW, REMOTE CONTROL (BLACK)		115	1-418-097-11	ENCODER, ROTARY	
103	3-974-997-51	WINDOW, REMOTE CONTROL (SILVER)		116	4-951-620-01	SCREW (2.6X8), +BVTP	
104	4-942-568-01	EMBLEM (NO.5), SONY (BLACK) (S725D)		119	3-945-284-51	KNOB, VOLUME (BLACK)	
104	4-942-568-61	EMBLEM (NO.5), SONY (SILVER) (S725D)		119	3-945-284-81	KNOB, VOLUME (SILVER)	
104	4-963-404-21	EMBLEM (5-A), SONY (S525D)		120	2-118-268-01	NUT (M9), HEXAGON	
105	3-988-030-51	BUTTON, POWER		* 121	3-684-436-01	PLATE, MOUNT	
106	X-3949-309-1	BUTTON (VES) ASSY (BLACK)		* 122	A-6065-229-A	HP-108 BOARD, COMPLETE (S525D)	
106	X-3949-311-1	BUTTON (VES) ASSY (SILVER)		* 122	A-6065-252-A	HP-110 BOARD, COMPLETE (S725D)	
107	3-053-479-01	BUTTON (PROG) (BLACK)		* 123	A-6065-230-A	SW-314 BOARD, COMPLETE (S525D)	
107	3-053-479-21	BUTTON (PROG) (SILVER)		* 123	A-6065-253-A	SW-316 BOARD, COMPLETE (S725D)	
108	3-053-517-01	BUTTON (OPEN) (BLACK)		* 124	A-6065-228-A	FR-147 BOARD, COMPLETE (S525D)	
108	3-053-517-21	BUTTON (OPEN) (SILVER)		* 124	A-6065-251-A	FR-149 BOARD, COMPLETE (S725D)	
109	3-053-480-01	BUTTON (PLAY) (BLACK)		125	3-054-216-01	PLATE (SL), GROUND	
109	3-053-480-21	BUTTON (PLAY) (SILVER)		126	3-053-512-01	PLATE (S), GROUND	
110	3-053-504-01	CUSHION		127	1-790-167-11	CABLE, FLEXIBLE FLAT (FMF-35)	
111	4-981-435-11	RING (DIA. 50), ORNAMENTAL		* 128	A-6065-227-A	FL-98 BOARD, COMPLETE (S525D)	
112	X-3949-294-1	RING ASSY, SHUTTLE (BLACK)		* 128	A-6065-250-A	FL-100 BOARD, COMPLETE (S725D)	
112	X-3949-313-1	RING ASSY, SHUTTLE (SILVER)					


8-1-4. CHASSIS ASSEMBLY



<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Remark</u>	<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Remark</u>
* 151	A-6065-388-A	MB-85 BOARD, COMPLETE (S525D)		△ 161	1-769-744-91	CORD, POWER	
* 151	A-6065-387-A	MB-85 BOARD, COMPLETE (S725D)		162	4-966-267-11	BUSHING (FBS001), CORD	
152	3-970-608-01	SUMITITE (B3), +BV		163	3-970-608-51	SUMITITE (B3), +BV	
153	1-790-166-11	CABLE, FLEXIBLE FLAT (FMT-25)		* 164	A-6065-255-A	RY-12 BOARD, COMPLETE (S725D)	
154	1-790-163-11	CABLE, FLEXIBLE FLAT (FMA-7)		* 165	A-6065-355-A	ER-4 BOARD, COMPLETE (S525D)	
155	1-790-164-11	CABLE, FLEXIBLE FLAT (FMA-8)		* 165	A-6065-249-A	ER-5 BOARD, COMPLETE (S725D)	
156	1-790-165-11	CABLE, FLEXIBLE FLAT (FMA-9)		166	1-790-168-11	CABLE, FLEXIBLE FLAT (FEA-4) (S725D)	
* 157	3-669-610-00	SPACER		166	1-790-408-11	CABLE, FLEXIBLE FLAT (FME-4) (S525D)	
* 158	A-6065-225-A	AU-209 BOARD, COMPLETE (S525D)		167	3-055-791-01	SUMITITE (B3), (RING), +BV	
* 158	A-6065-248-A	AU-211 BOARD, COMPLETE (S725D)		168	3-055-418-01	COVER, EJECT	
* 159	1-468-359-11	POWER BLOCK (HS-030SH)		169	3-054-650-01	SPRING, EMC	
160	3-053-507-21	PANEL, REAR (S525D)		△ T901	1-431-175-21	TRANSFORMER, POWER (S725D)	
160	X-3949-703-1	PANEL ASSY, REAR (S725D)					

The components identified by mark △ or dotted line with mark △ are critical for safety.
Replace only with part number specified.

8-1-5. MECHANISM DECK ASSEMBLY



Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
* 201	A-6065-256-A	TK-54 BOARD, COMPLETE		* 213	A-6066-012-A	MS-29 BOARD, COMPLETE	
202	A-6062-120-A	LOADING ASSY		214	3-053-845-01	CHUCK PLATE	
203	3-053-837-01	TRAY		215	3-053-844-01	YOKE	
204	3-053-841-01	PULLEY GEAR		216	3-053-848-01	CHUCK HOLDER	
205	3-053-840-01	CAM DRIVING GEAR		217	3-053-846-01	YOKE HOLDER	
206	3-053-839-01	TRAY DRIVING GEAR		218	3-053-847-01	INSULATOR	
207	4-974-711-01	SCREW (2X5) (P TYIGHT), (+) PTTWH		219	4-981-923-01	SCREW (M), STEP	
208	3-053-842-01	BELT		Δ 220	8-820-081-03	OPTICAL PICK-UP KHM-220AAA/J1RP	
209	3-053-849-01	SPRING, TENSION		221	3-053-843-01	MOTOR PULLEY	
210	3-053-838-01	CHUCK CAM		222	3-055-097-01	SEAL, DUST TRAY	
211	3-053-836-01	BASE UNIT HOLDER		M001	1-541-632-11	MOTOR, DC (LOADING)	
212	3-053-835-01	BASE, LOADING					

8-2. ELECTRICAL PARTS LIST

NOTE:

- Due to standardization, replacements in the parts list may be different from the parts specified in the diagrams or the components used on the set.
- -XX and -X mean standardized parts, so they may have some difference from the original one.
- RESISTORS
All resistors are in ohms.
METAL: Metal-film resistor.
METAL OXIDE: Metal oxide-film resistor.
F: nonflammable
- Not all of the parts for POWER BLOCK (HS-030SH) are listed.

- Items marked “*” are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- SEMICONDUCTORS
In each case, u: μ , for example:
uA. . . : μ A. . . uPA. . . : μ PA. . .
uPB. . . : μ PB. . . uPC. . . : μ PC. . .
uPD. . . : μ PD. . .
- CAPACITORS
uF: μ F
- COILS
uH: μ H

The components identified by mark Δ or dotted line with mark Δ are critical for safety. Replace only with part number specified.

When indicating parts by reference number, please include the board.

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
*	A-6065-225-A	AU-209 BOARD, COMPLETE (S525D) ***** (Ref. No. 2,000 Series)		C440	1-163-021-91	CERAMIC CHIP 0.01uF 10%	50V
		< CAPACITOR >		C442	1-163-133-00	CERAMIC CHIP 470PF 5%	50V
C302	1-126-926-11	ELECT 1000uF 20%	10V	C443	1-163-021-91	CERAMIC CHIP 0.01uF 10%	50V
C303	1-163-021-91	CERAMIC CHIP 0.01uF 10%	50V	C447	1-136-850-11	FILM 0.1uF 5%	63V
C304	1-163-021-91	CERAMIC CHIP 0.01uF 10%	50V	C448	1-104-664-11	ELECT 47uF 20%	16V
C305	1-163-239-11	CERAMIC CHIP 33PF 5%	50V	C449	1-104-664-11	ELECT 47uF 20%	16V
C306	1-163-239-11	CERAMIC CHIP 33PF 5%	50V	C450	1-136-850-11	FILM 0.1uF 5%	63V
C307	1-163-239-11	CERAMIC CHIP 33PF 5%	50V	C501	1-104-664-11	ELECT 47uF 20%	16V
C308	1-163-009-11	CERAMIC CHIP 1000PF 10%	50V	C502	1-104-664-11	ELECT 47uF 20%	16V
C310	1-163-009-11	CERAMIC CHIP 1000PF 10%	50V	C503	1-163-021-91	CERAMIC CHIP 0.01uF 10%	50V
C321	1-104-665-11	ELECT 100uF 20%	10V	C504	1-163-131-00	CERAMIC CHIP 390PF 5%	50V
C322	1-104-665-11	ELECT 100uF 20%	10V	C505	1-163-131-00	CERAMIC CHIP 390PF 5%	50V
C323	1-164-004-11	CERAMIC CHIP 0.1uF 10%	25V	C506	1-163-021-91	CERAMIC CHIP 0.01uF 10%	50V
C324	1-126-935-11	ELECT 470uF 20%	6.3V	C507	1-163-133-00	CERAMIC CHIP 470PF 5%	50V
C325	1-126-935-11	ELECT 470uF 20%	6.3V	C508	1-163-133-00	CERAMIC CHIP 470PF 5%	50V
C326	1-104-664-11	ELECT 47uF 20%	16V	C509	1-136-850-11	FILM 0.1uF 5%	63V
C327	1-163-021-91	CERAMIC CHIP 0.01uF 10%	50V	C512	1-136-850-11	FILM 0.1uF 5%	63V
C343	1-163-259-91	CERAMIC CHIP 220PF 5%	50V	C513	1-104-664-11	ELECT 47uF 20%	16V
C344	1-126-960-11	ELECT 1uF 20%	50V	C514	1-104-664-11	ELECT 47uF 20%	16V
C345	1-163-021-91	CERAMIC CHIP 0.01uF 10%	50V	C521	1-163-251-11	CERAMIC CHIP 100PF 5%	50V
C351	1-163-233-11	CERAMIC CHIP 18PF 5%	50V	C522	1-163-251-11	CERAMIC CHIP 100PF 5%	50V
C361	1-164-346-11	CERAMIC CHIP 1uF 16V		C523	1-163-251-11	CERAMIC CHIP 100PF 5%	50V
C362	1-164-346-11	CERAMIC CHIP 1uF 16V		C524	1-163-251-11	CERAMIC CHIP 100PF 5%	50V
C363	1-164-346-11	CERAMIC CHIP 1uF 16V		C525	1-163-251-11	CERAMIC CHIP 100PF 5%	50V
C364	1-164-346-11	CERAMIC CHIP 1uF 16V		C526	1-163-251-11	CERAMIC CHIP 100PF 5%	50V
C365	1-164-346-11	CERAMIC CHIP 1uF 16V		C541	1-104-664-11	ELECT 47uF 20%	16V
C366	1-164-346-11	CERAMIC CHIP 1uF 16V		C542	1-104-664-11	ELECT 47uF 20%	16V
C367	1-164-346-11	CERAMIC CHIP 1uF 16V		C543	1-163-130-00	CERAMIC CHIP 360PF 5%	50V
C368	1-164-346-11	CERAMIC CHIP 1uF 16V		C544	1-163-275-11	CERAMIC CHIP 0.001uF 5%	50V
C401	1-104-665-11	ELECT 100uF 20%	10V	C545	1-163-021-91	CERAMIC CHIP 0.01uF 10%	50V
C404	1-104-665-11	ELECT 100uF 20%	10V	C546	1-163-130-00	CERAMIC CHIP 360PF 5%	50V
C431	1-104-664-11	ELECT 47uF 20%	16V	C547	1-163-275-11	CERAMIC CHIP 0.001uF 5%	50V
C432	1-104-664-11	ELECT 47uF 20%	16V	C548	1-163-021-91	CERAMIC CHIP 0.01uF 10%	50V
C433	1-104-665-11	ELECT 100uF 20%	10V	C549	1-104-664-11	ELECT 47uF 20%	16V
C434	1-163-021-91	CERAMIC CHIP 0.01uF 10%	50V	C550	1-104-664-11	ELECT 47uF 20%	16V
C435	1-104-665-11	ELECT 100uF 20%	10V	C571	1-104-664-11	ELECT 47uF 20%	16V
C436	1-163-131-00	CERAMIC CHIP 390PF 5%	50V	C572	1-104-664-11	ELECT 47uF 20%	16V
C437	1-163-021-91	CERAMIC CHIP 0.01uF 10%	50V	C573	1-163-130-00	CERAMIC CHIP 360PF 5%	50V
C438	1-163-131-00	CERAMIC CHIP 390PF 5%	50V	C574	1-163-020-00	CERAMIC CHIP 0.0082uF 10%	50V
C439	1-163-133-00	CERAMIC CHIP 470PF 5%	50V	C575	1-163-021-91	CERAMIC CHIP 0.01uF 10%	50V
				C576	1-163-145-00	CERAMIC CHIP 0.0015uF 5%	50V
				C577	1-163-275-11	CERAMIC CHIP 0.001uF 5%	50V

Ref. No.	Part No.	Description	Remark
C578	1-163-021-91	CERAMIC CHIP 0.01uF 10% 50V	
C579	1-104-664-11	ELECT 47uF 20% 16V	
C580	1-104-664-11	ELECT 47uF 20% 16V	
C590	1-164-004-11	CERAMIC CHIP 0.1uF 10% 25V	
C591	1-163-233-11	CERAMIC CHIP 18PF 5% 50V	

< CONNECTOR >

CN301	1-785-698-11	CONNECTOR, FFC/FPC 28P
CN302	1-785-695-11	CONNECTOR, FFC/FPC 13P
CN305	1-785-697-11	CONNECTOR, FFC/FPC 18P
CN401	1-564-002-11	PIN, CONNECTOR 3P

< DIODE >

D301	8-719-988-61	DIODE 1SS355TE-17
D304	8-719-071-15	DIODE HZM6.8ZWA1TL
D306	8-719-071-15	DIODE HZM6.8ZWA1TL
D308	8-719-988-61	DIODE 1SS355TE-17
D431	8-719-988-61	DIODE 1SS355TE-17
D432	8-719-988-61	DIODE 1SS355TE-17
D525	8-719-988-61	DIODE 1SS355TE-17
D526	8-719-988-61	DIODE 1SS355TE-17
D551	8-719-988-61	DIODE 1SS355TE-17
D552	8-719-988-61	DIODE 1SS355TE-17
D591	8-719-988-61	DIODE 1SS355TE-17
D592	8-719-988-61	DIODE 1SS355TE-17

< EARTH TERMINAL >

* ET301	1-537-738-21	TERMINAL, EARTH
* ET302	1-537-738-21	TERMINAL, EARTH
* ET303	1-537-738-21	TERMINAL, EARTH

< FERRITE BEAD >

FB306	1-414-553-11	FERRITE 0uH
FB307	1-414-553-11	FERRITE 0uH
FB308	1-414-553-11	FERRITE 0uH
FB309	1-414-553-11	FERRITE 0uH
FB310	1-414-553-11	FERRITE 0uH
FB311	1-414-553-11	FERRITE 0uH
FB312	1-414-553-11	FERRITE 0uH
FB314	1-414-553-11	FERRITE 0uH
FB316	1-414-553-11	FERRITE 0uH
FB321	1-414-553-11	FERRITE 0uH
FB322	1-414-553-11	FERRITE 0uH
FB323	1-414-553-11	FERRITE 0uH
FB341	1-414-135-11	FERRITE 0uH
FB342	1-414-553-11	FERRITE 0uH
FB401	1-414-553-11	FERRITE 0uH
FB402	1-414-553-11	FERRITE 0uH
FB403	1-414-553-11	FERRITE 0uH
FB404	1-414-553-11	FERRITE 0uH
FB405	1-414-553-11	FERRITE 0uH
FB406	1-414-553-11	FERRITE 0uH
FB407	1-414-553-11	FERRITE 0uH
FB408	1-414-553-11	FERRITE 0uH
FB409	1-414-553-11	FERRITE 0uH

< IC >

IC301	8-759-701-58	IC NJM78M08FA
IC302	8-759-982-54	IC RC79M09FA
IC321	8-759-563-79	IC BA7660F-E2
IC401	8-759-909-71	IC BA4558F

Ref. No.	Part No.	Description	Remark
IC431	8-759-909-71	IC BA4558F	
IC502	8-759-909-71	IC BA4558F	
IC505	8-749-921-12	IC GP1F32T	
IC541	8-759-909-71	IC BA4558F	
IC571	8-759-909-71	IC BA4558F	

< JACK >

J502	1-779-382-11	JACK, PIN 1P (COAXIAL)
J506	1-785-537-11	JACK, PIN (3P) (LINE OUT)
J507	1-537-943-11	TERMINAL, S (S VIDEO OUT)
J508	1-785-536-11	JACK, PIN (6P) (5.1CH OUTPUT)

< JUMPER RESISTOR >

JR401	1-216-296-91	SHORT 0
JR402	1-216-296-91	SHORT 0
JR403	1-216-295-91	SHORT 0
JR404	1-216-295-91	SHORT 0
JR405	1-216-296-91	SHORT 0
JR406	1-216-296-91	SHORT 0
JR407	1-216-296-91	SHORT 0
JR408	1-216-296-91	SHORT 0
JR409	1-216-296-91	SHORT 0
JR410	1-216-296-91	SHORT 0
JR411	1-216-295-91	SHORT 0
JR412	1-216-295-91	SHORT 0
JR413	1-216-296-91	SHORT 0
JR414	1-216-296-91	SHORT 0
JR415	1-216-296-91	SHORT 0
JR418	1-216-295-91	SHORT 0
JR419	1-216-296-91	SHORT 0
JR420	1-216-296-91	SHORT 0
JR421	1-216-295-91	SHORT 0
JR422	1-216-296-91	SHORT 0
JR424	1-216-296-91	SHORT 0
JR425	1-216-295-91	SHORT 0
JR427	1-216-296-91	SHORT 0
JR428	1-216-296-91	SHORT 0
JR429	1-216-296-91	SHORT 0
JR433	1-216-295-91	SHORT 0
JR434	1-216-296-91	SHORT 0
JR435	1-216-296-91	SHORT 0
JR436	1-216-295-91	SHORT 0
JR437	1-216-295-91	SHORT 0
JR438	1-216-296-91	SHORT 0
JR439	1-216-296-91	SHORT 0
JR446	1-216-295-91	SHORT 0
JR447	1-216-295-91	SHORT 0

< COIL >

L301	1-412-953-11	INDUCTOR 15uH
L302	1-412-953-11	INDUCTOR 15uH
L303	1-412-953-11	INDUCTOR 15uH
L321	1-412-963-11	INDUCTOR 100uH

< TRANSISTOR >

Q301	8-729-424-08	TRANSISTOR UN2111
Q303	8-729-216-22	TRANSISTOR 2SA1162
Q304	8-729-421-19	TRANSISTOR UN2213
Q305	8-729-424-08	TRANSISTOR UN2111
Q306	8-729-424-08	TRANSISTOR UN2111

Ref. No.	Part No.	Description				Remark	Ref. No.	Part No.	Description				Remark
Q307	8-729-424-08	TRANSISTOR	UN2111										
Q308	8-729-424-08	TRANSISTOR	UN2111				R402	1-216-085-00	METAL CHIP	33K	5%	1/10W	
Q309	8-729-424-08	TRANSISTOR	UN2111				R403	1-216-085-00	METAL CHIP	33K	5%	1/10W	
Q310	8-729-424-08	TRANSISTOR	UN2111				R404	1-216-085-00	METAL CHIP	33K	5%	1/10W	
Q311	8-729-424-08	TRANSISTOR	UN2111				R405	1-216-085-00	METAL CHIP	33K	5%	1/10W	
							R406	1-216-077-00	METAL CHIP	15K	5%	1/10W	
Q314	8-729-424-08	TRANSISTOR	UN2111										
Q315	8-729-421-19	TRANSISTOR	UN2213				R407	1-216-077-00	METAL CHIP	15K	5%	1/10W	
Q321	8-729-421-19	TRANSISTOR	UN2213				R408	1-216-085-00	METAL CHIP	33K	5%	1/10W	
Q322	8-729-424-08	TRANSISTOR	UN2111				R409	1-216-025-91	RES, CHIP	100	5%	1/10W	
Q341	8-729-120-28	TRANSISTOR	2SC1623-L5L6				R410	1-216-025-91	RES, CHIP	100	5%	1/10W	
							R411	1-216-049-91	RES, CHIP	1K	5%	1/10W	
Q361	8-729-046-97	TRANSISTOR	2SD1938 (F)-T (TX).SO										
Q362	8-729-046-97	TRANSISTOR	2SD1938 (F)-T (TX).SO				R412	1-216-049-91	RES, CHIP	1K	5%	1/10W	
Q401	8-729-046-97	TRANSISTOR	2SD1938 (F)-T (TX).SO				R431	1-216-089-91	METAL CHIP	47K	5%	1/10W	
Q402	8-729-046-97	TRANSISTOR	2SD1938 (F)-T (TX).SO				R432	1-216-069-00	METAL CHIP	6.8K	5%	1/10W	
Q431	8-729-046-97	TRANSISTOR	2SD1938 (F)-T (TX).SO				R433	1-216-069-00	METAL CHIP	6.8K	5%	1/10W	
							R434	1-216-089-91	METAL CHIP	47K	5%	1/10W	
Q432	8-729-046-97	TRANSISTOR	2SD1938 (F)-T (TX).SO										
Q435	8-729-046-97	TRANSISTOR	2SD1938 (F)-T (TX).SO				R435	1-216-069-00	METAL CHIP	6.8K	5%	1/10W	
Q436	8-729-046-97	TRANSISTOR	2SD1938 (F)-T (TX).SO				R436	1-216-069-00	METAL CHIP	6.8K	5%	1/10W	
Q503	8-729-046-97	TRANSISTOR	2SD1938 (F)-T (TX).SO				R437	1-216-071-00	METAL CHIP	8.2K	5%	1/10W	
Q504	8-729-046-97	TRANSISTOR	2SD1938 (F)-T (TX).SO				R438	1-216-071-00	METAL CHIP	8.2K	5%	1/10W	
							R439	1-216-069-00	METAL CHIP	6.8K	5%	1/10W	
Q543	8-729-046-97	TRANSISTOR	2SD1938 (F)-T (TX).SO										
Q544	8-729-046-97	TRANSISTOR	2SD1938 (F)-T (TX).SO				R440	1-216-295-91	SHORT	0			
Q573	8-729-046-97	TRANSISTOR	2SD1938 (F)-T (TX).SO				R441	1-216-069-00	METAL CHIP	6.8K	5%	1/10W	
Q574	8-729-046-97	TRANSISTOR	2SD1938 (F)-T (TX).SO				R443	1-216-057-00	METAL CHIP	2.2K	5%	1/10W	
		< RESISTOR >				R444	1-216-057-00	METAL CHIP	2.2K	5%	1/10W		
						R445	1-216-049-91	RES, CHIP	1K	5%	1/10W		
R303	1-216-042-00	METAL CHIP	510	5%	1/10W		R446	1-216-047-91	RES, CHIP	820	5%	1/10W	
R304	1-216-042-00	METAL CHIP	510	5%	1/10W		R447	1-216-049-91	RES, CHIP	1K	5%	1/10W	
R305	1-216-042-00	METAL CHIP	510	5%	1/10W		R448	1-216-047-91	RES, CHIP	820	5%	1/10W	
R307	1-216-073-00	METAL CHIP	10K	5%	1/10W		R449	1-216-109-00	METAL CHIP	330K	5%	1/10W	
R309	1-216-073-00	METAL CHIP	10K	5%	1/10W		R450	1-216-109-00	METAL CHIP	330K	5%	1/10W	
R311	1-216-097-91	RES, CHIP	100K	5%	1/10W		R451	1-216-041-00	METAL CHIP	470	5%	1/10W	
R313	1-216-097-91	RES, CHIP	100K	5%	1/10W		R452	1-216-041-00	METAL CHIP	470	5%	1/10W	
R314	1-216-097-91	RES, CHIP	100K	5%	1/10W		R455	1-216-097-91	RES, CHIP	100K	5%	1/10W	
R315	1-216-097-91	RES, CHIP	100K	5%	1/10W		R456	1-216-049-91	RES, CHIP	1K	5%	1/10W	
R316	1-216-097-91	RES, CHIP	100K	5%	1/10W		R457	1-216-049-91	RES, CHIP	1K	5%	1/10W	
R318	1-216-097-91	RES, CHIP	100K	5%	1/10W		R458	1-216-041-00	METAL CHIP	470	5%	1/10W	
R319	1-216-097-91	RES, CHIP	100K	5%	1/10W		R459	1-216-049-91	RES, CHIP	1K	5%	1/10W	
R320	1-216-097-91	RES, CHIP	100K	5%	1/10W		R460	1-216-041-00	METAL CHIP	470	5%	1/10W	
R321	1-216-073-00	METAL CHIP	10K	5%	1/10W		R461	1-216-049-91	RES, CHIP	1K	5%	1/10W	
R322	1-216-073-00	METAL CHIP	10K	5%	1/10W		R501	1-216-089-91	METAL CHIP	47K	5%	1/10W	
R323	1-216-021-00	METAL CHIP	68	5%	1/10W		R502	1-216-069-00	METAL CHIP	6.8K	5%	1/10W	
R324	1-216-021-00	METAL CHIP	68	5%	1/10W		R503	1-216-089-91	METAL CHIP	47K	5%	1/10W	
R325	1-216-295-91	SHORT	0				R504	1-216-069-00	METAL CHIP	6.8K	5%	1/10W	
R326	1-216-021-00	METAL CHIP	68	5%	1/10W		R510	1-216-069-00	METAL CHIP	6.8K	5%	1/10W	
R327	1-216-021-00	METAL CHIP	68	5%	1/10W		R511	1-216-069-00	METAL CHIP	6.8K	5%	1/10W	
R328	1-216-021-00	METAL CHIP	68	5%	1/10W		R512	1-216-071-00	METAL CHIP	8.2K	5%	1/10W	
R330	1-216-073-00	METAL CHIP	10K	5%	1/10W		R513	1-216-069-00	METAL CHIP	6.8K	5%	1/10W	
R333	1-216-049-91	RES, CHIP	1K	5%	1/10W		R514	1-216-071-00	METAL CHIP	8.2K	5%	1/10W	
R334	1-216-097-91	RES, CHIP	100K	5%	1/10W		R517	1-216-057-00	METAL CHIP	2.2K	5%	1/10W	
R341	1-216-057-00	METAL CHIP	2.2K	5%	1/10W		R519	1-216-057-00	METAL CHIP	2.2K	5%	1/10W	
R342	1-216-063-91	RES, CHIP	3.9K	5%	1/10W		R520	1-216-069-00	METAL CHIP	6.8K	5%	1/10W	
R343	1-216-055-00	METAL CHIP	1.8K	5%	1/10W		R521	1-216-109-00	METAL CHIP	330K	5%	1/10W	
R344	1-216-033-00	METAL CHIP	220	5%	1/10W		R522	1-216-109-00	METAL CHIP	330K	5%	1/10W	
R345	1-216-021-00	METAL CHIP	68	5%	1/10W		R523	1-216-041-00	METAL CHIP	470	5%	1/10W	
R346	1-216-025-91	RES, CHIP	100	5%	1/10W		R524	1-216-041-00	METAL CHIP	470	5%	1/10W	
R347	1-216-295-91	SHORT	0				R525	1-216-049-91	RES, CHIP	1K	5%	1/10W	
R348	1-216-097-91	RES, CHIP	100K	5%	1/10W		R526	1-216-025-91	RES, CHIP	100	5%	1/10W	
R361	1-216-049-91	RES, CHIP	1K	5%	1/10W		R527	1-216-025-91	RES, CHIP	100	5%	1/10W	
R362	1-216-049-91	RES, CHIP	1K	5%	1/10W		R528	1-216-049-91	RES, CHIP	1K	5%	1/10W	
R401	1-216-085-00	METAL CHIP	33K	5%	1/10W		R541	1-216-089-91	METAL CHIP	47K	5%	1/10W	

AU-209

AU-211

Ref. No.	Part No.	Description	Remark		
R542	1-216-069-00	METAL CHIP	6.8K	5%	1/10W
R543	1-216-089-91	METAL CHIP	47K	5%	1/10W
R544	1-216-069-00	METAL CHIP	6.8K	5%	1/10W
R545	1-216-069-00	METAL CHIP	6.8K	5%	1/10W
R546	1-216-069-00	METAL CHIP	6.8K	5%	1/10W
R547	1-216-069-00	METAL CHIP	6.8K	5%	1/10W
R548	1-216-069-00	METAL CHIP	6.8K	5%	1/10W
R549	1-216-057-00	METAL CHIP	2.2K	5%	1/10W
R553	1-216-057-00	METAL CHIP	2.2K	5%	1/10W
R555	1-216-109-00	METAL CHIP	330K	5%	1/10W
R556	1-216-109-00	METAL CHIP	330K	5%	1/10W
R557	1-216-041-00	METAL CHIP	470	5%	1/10W
R558	1-216-041-00	METAL CHIP	470	5%	1/10W
R559	1-216-049-91	RES, CHIP	1K	5%	1/10W
R560	1-216-025-91	RES, CHIP	100	5%	1/10W
R561	1-216-025-91	RES, CHIP	100	5%	1/10W
R562	1-216-049-91	RES, CHIP	1K	5%	1/10W
R564	1-216-295-91	SHORT	0		
R569	1-216-295-91	SHORT	0		
R571	1-216-089-91	METAL CHIP	47K	5%	1/10W
R572	1-216-089-91	METAL CHIP	47K	5%	1/10W
R573	1-216-069-00	METAL CHIP	6.8K	5%	1/10W
R574	1-216-077-00	METAL CHIP	15K	5%	1/10W
R575	1-216-069-00	METAL CHIP	6.8K	5%	1/10W
R576	1-216-077-00	METAL CHIP	15K	5%	1/10W
R577	1-216-057-00	METAL CHIP	2.2K	5%	1/10W
R578	1-216-061-00	METAL CHIP	3.3K	5%	1/10W
R579	1-216-069-00	METAL CHIP	6.8K	5%	1/10W
R580	1-216-079-00	METAL CHIP	18K	5%	1/10W
R585	1-216-109-00	METAL CHIP	330K	5%	1/10W
R586	1-216-109-00	METAL CHIP	330K	5%	1/10W
R587	1-216-041-00	METAL CHIP	470	5%	1/10W
R588	1-216-041-00	METAL CHIP	470	5%	1/10W
R589	1-216-049-91	RES, CHIP	1K	5%	1/10W
R590	1-216-025-91	RES, CHIP	100	5%	1/10W
R591	1-216-025-91	RES, CHIP	100	5%	1/10W
R592	1-216-049-91	RES, CHIP	1K	5%	1/10W
R593	1-216-295-91	SHORT	0		
R598	1-216-295-91	SHORT	0		

* A-6065-248-A AU-211 BOARD, COMPLETE (S725D)

 (Ref. No. 3,000 Series)

< CAPACITOR >

C302	1-104-665-11	ELECT	100uF	20%	10V
C303	1-104-665-11	ELECT	100uF	20%	10V
C304	1-164-004-11	CERAMIC CHIP	0.1uF	10%	25V
C305	1-126-935-11	ELECT	470uF	20%	6.3V
C306	1-126-935-11	ELECT	470uF	20%	6.3V
C307	1-104-664-11	ELECT	47uF	20%	25V
C309	1-164-004-11	CERAMIC CHIP	0.1uF	10%	25V
C310	1-163-259-91	CERAMIC CHIP	220PF	5%	50V
C311	1-163-259-91	CERAMIC CHIP	220PF	5%	50V
C312	1-163-259-91	CERAMIC CHIP	220PF	5%	50V
C313	1-163-259-91	CERAMIC CHIP	220PF	5%	50V
C314	1-163-259-91	CERAMIC CHIP	220PF	5%	50V
C315	1-163-259-91	CERAMIC CHIP	220PF	5%	50V
C316	1-126-960-11	ELECT	1uF	20%	50V
C317	1-163-259-91	CERAMIC CHIP	220PF	5%	50V

C318	1-104-665-11	ELECT	100uF	20%	10V
C319	1-104-665-11	ELECT	100uF	20%	10V
C320	1-104-665-11	ELECT	100uF	20%	10V
C323	1-126-935-11	ELECT	470uF	20%	6.3V
C324	1-126-935-11	ELECT	470uF	20%	6.3V
C325	1-126-935-11	ELECT	470uF	20%	6.3V
C328	1-104-664-11	ELECT	47uF	20%	16V
C330	1-164-004-11	CERAMIC CHIP	0.1uF	10%	25V
C331	1-126-967-11	ELECT	47uF	20%	25V
C361	1-164-346-11	CERAMIC CHIP	1uF		16V
C362	1-164-346-11	CERAMIC CHIP	1uF		16V
C363	1-164-346-11	CERAMIC CHIP	1uF		16V
C364	1-164-346-11	CERAMIC CHIP	1uF		16V
C365	1-164-346-11	CERAMIC CHIP	1uF		16V
C366	1-164-346-11	CERAMIC CHIP	1uF		16V
C367	1-164-346-11	CERAMIC CHIP	1uF		16V
C368	1-164-346-11	CERAMIC CHIP	1uF		16V
C401	1-163-021-91	CERAMIC CHIP	0.01uF	10%	50V
C402	1-126-926-11	ELECT	1000uF	20%	10V
C403	1-128-204-11	ELECT	470uF	20%	63V
C404	1-128-204-11	ELECT	470uF	20%	63V
C405	1-163-239-11	CERAMIC CHIP	33PF	5%	50V
C406	1-163-239-11	CERAMIC CHIP	33PF	5%	50V
C407	1-163-239-11	CERAMIC CHIP	33PF	5%	50V
C408	1-163-239-11	CERAMIC CHIP	33PF	5%	50V
C409	1-163-239-11	CERAMIC CHIP	33PF	5%	50V
C410	1-163-239-11	CERAMIC CHIP	33PF	5%	50V
C411	1-119-828-31	ELECT	100uF	20%	50V
C412	1-119-828-31	ELECT	100uF	20%	50V
C413	1-126-967-11	ELECT	47uF	20%	25V
C414	1-126-967-11	ELECT	47uF	20%	25V
C415	1-126-967-11	ELECT	47uF	20%	25V
C416	1-126-967-11	ELECT	47uF	20%	25V
C417	1-126-967-11	ELECT	47uF	20%	25V
C418	1-126-967-11	ELECT	47uF	20%	25V
C419	1-136-811-11	FILM	330PF	5%	100V
C420	1-117-793-11	MYLAR	330PF	5%	50V
C421	1-117-793-11	MYLAR	330PF	5%	50V
C422	1-106-343-00	MYLAR	1000PF	5%	200V
C423	1-136-811-11	FILM	330PF	5%	100V
C424	1-117-793-11	MYLAR	330PF	5%	50V
C425	1-117-793-11	MYLAR	330PF	5%	50V
C426	1-117-793-11	MYLAR	330PF	5%	50V
C427	1-127-713-21	FILM	10000PF	5%	50V
C428	1-130-483-00	MYLAR	0.01uF	5%	50V
C429	1-130-484-00	MYLAR	0.012uF	5%	50V
C430	1-136-850-11	FILM	0.1uF	5%	63V
C431	1-127-713-21	FILM	10000PF	5%	50V
C432	1-113-577-11	ELECT	47uF	20%	16V
C433	1-113-577-11	ELECT	47uF	20%	16V
C434	1-130-483-00	MYLAR	0.01uF	5%	50V
C435	1-136-850-11	FILM	0.1uF	5%	63V
C436	1-136-850-11	FILM	0.1uF	5%	63V
C437	1-130-484-00	MYLAR	0.012uF	5%	50V
C438	1-136-850-11	FILM	0.1uF	5%	63V
C439	1-136-850-11	FILM	0.1uF	5%	63V
C440	1-130-484-00	MYLAR	0.012uF	5%	50V
C441	1-136-850-11	FILM	0.1uF	5%	63V
C442	1-136-850-11	FILM	0.1uF	5%	63V
C443	1-125-853-21	FILM	470PF	5%	50V

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
C444	1-130-467-00	MYLAR	470PF 5% 50V	D407	8-719-988-61	DIODE 1SS355TE-17	
C445	1-106-343-00	MYLAR	1000PF 5% 200V	D408	8-719-988-61	DIODE 1SS355TE-17	
C446	1-130-483-00	MYLAR	0.01uF 5% 50V	D409	8-719-988-61	DIODE 1SS355TE-17	
C447	1-125-853-21	FILM	470PF 5% 50V	D410	8-719-988-61	DIODE 1SS355TE-17	
C448	1-130-467-00	MYLAR	470PF 5% 50V	D411	8-719-115-87	DIODE RD9.1JS-T4AB2	
C449	1-106-343-00	MYLAR	1000PF 5% 200V	D421	8-719-988-61	DIODE 1SS355TE-17	
C450	1-106-343-00	MYLAR	1000PF 5% 200V	D422	8-719-988-61	DIODE 1SS355TE-17	
C451	1-119-828-31	ELECT	100uF 20% 50V	D423	8-719-988-61	DIODE 1SS355TE-17	
C452	1-136-850-11	FILM	0.1uF 5% 63V	D424	8-719-988-61	DIODE 1SS355TE-17	
C453	1-136-850-11	FILM	0.1uF 5% 63V	D425	8-719-988-61	DIODE 1SS355TE-17	
C454	1-119-828-31	ELECT	100uF 20% 50V	D426	8-719-988-61	DIODE 1SS355TE-17	
C455	1-124-673-11	ELECT	100uF 20% 10V	D427	8-719-988-61	DIODE 1SS355TE-17	
C456	1-124-673-11	ELECT	100uF 20% 10V			< EARTH TERMINAL >	
C457	1-124-673-11	ELECT	100uF 20% 10V	* ET401	1-537-738-21	TERMINAL, EARTH	
C458	1-124-673-11	ELECT	100uF 20% 10V	* ET402	1-537-738-21	TERMINAL, EARTH	
C459	1-124-673-11	ELECT	100uF 20% 10V	* ET403	1-537-738-21	TERMINAL, EARTH	
C460	1-124-673-11	ELECT	100uF 20% 10V			< FERRITE BEAD >	
C461	1-104-665-11	ELECT	100uF 20% 25V	FB301	1-414-135-11	FERRITE 0uH	
C464	1-104-665-11	ELECT	100uF 20% 25V	FB302	1-414-553-11	FERRITE 0uH	
C465	1-128-200-11	ELECT	47uF 20% 63V	FB303	1-414-553-11	FERRITE 0uH	
C466	1-163-009-11	CERAMIC CHIP	0.001uF 10% 50V	FB304	1-414-553-11	FERRITE 0uH	
C467	1-128-200-11	ELECT	47uF 20% 63V	FB305	1-414-553-11	FERRITE 0uH	
C468	1-136-850-11	FILM	0.1uF 5% 63V	FB306	1-414-553-11	FERRITE 0uH	
C469	1-126-967-11	ELECT	47uF 20% 25V	FB307	1-414-553-11	FERRITE 0uH	
C470	1-136-850-11	FILM	0.1uF 5% 63V	FB308	1-414-553-11	FERRITE 0uH	
C471	1-136-850-11	FILM	0.1uF 5% 63V	FB309	1-414-553-11	FERRITE 0uH	
C472	1-136-850-11	FILM	0.1uF 5% 63V	FB311	1-414-553-11	FERRITE 0uH	
C473	1-164-004-11	CERAMIC CHIP	0.1uF 10% 25V	FB312	1-414-553-11	FERRITE 0uH	
C474	1-136-850-11	FILM	0.1uF 5% 63V	FB313	1-414-553-11	FERRITE 0uH	
C475	1-136-850-11	FILM	0.1uF 5% 63V	FB314	1-414-553-11	FERRITE 0uH	
C478	1-104-664-11	ELECT	47uF 20% 25V	FB315	1-414-553-11	FERRITE 0uH	
C479	1-163-021-91	CERAMIC CHIP	0.01uF 10% 50V	FB316	1-414-553-11	FERRITE 0uH	
C480	1-163-021-91	CERAMIC CHIP	0.01uF 10% 50V	FB317	1-414-553-11	FERRITE 0uH	
C485	1-163-233-11	CERAMIC CHIP	18PF 5% 50V	FB319	1-414-553-11	FERRITE 0uH	
C486	1-163-233-11	CERAMIC CHIP	18PF 5% 50V	FB320	1-414-553-11	FERRITE 0uH	
C487	1-163-233-11	CERAMIC CHIP	18PF 5% 50V	FB321	1-414-553-11	FERRITE 0uH	
C488	1-163-233-11	CERAMIC CHIP	18PF 5% 50V	FB322	1-414-553-11	FERRITE 0uH	
C489	1-163-233-11	CERAMIC CHIP	18PF 5% 50V	FB323	1-414-553-11	FERRITE 0uH	
C490	1-164-004-11	CERAMIC CHIP	0.1uF 10% 25V	FB324	1-414-553-11	FERRITE 0uH	
		< CONNECTOR >		FB401	1-414-553-11	FERRITE 0uH	
CN301	1-564-002-11	PIN, CONNECTOR 3P		FB402	1-414-553-11	FERRITE 0uH	
CN302	1-785-697-11	CONNECTOR, FFC/FPC 18P				< IC >	
* CN401	1-564-241-11	PIN, CONNECTOR (B4P-VH) 4P		IC301	8-759-563-79	IC BA7660F-E2	
CN402	1-785-698-11	CONNECTOR, FFC/FPC 28P		IC302	8-759-563-79	IC BA7660F-E2	
CN403	1-785-695-11	CONNECTOR, FFC/FPC 13P		IC303	8-749-921-12	IC GP1F32T	
CN404	1-506-473-11	PIN, CONNECTOR 8P		IC401	8-759-008-67	IC MC14066BF	
CN405	1-785-694-11	CONNECTOR, FFC/FPC 7P		IC403	8-759-059-79	IC BA15532	
CN406	1-785-694-11	CONNECTOR, FFC/FPC 7P		IC404	8-759-059-79	IC BA15532	
* CN407	1-564-001-11	PIN, CONNECTOR 2P		IC405	8-759-634-51	IC M5218AP	
		< DIODE >		IC406	8-759-634-51	IC M5218AP	
D301	8-719-071-15	DIODE HZM6.8ZWA1TL		IC407	8-759-971-80	IC AD712JN	
D303	8-719-071-15	DIODE HZM6.8ZWA1TL		IC408	8-759-710-59	IC NJM4580D-D	
D401	8-719-210-21	DIODE 11EQS04		IC409	8-759-710-59	IC NJM4580D-D	
D402	8-719-210-21	DIODE 11EQS04		IC410	8-759-710-59	IC NJM4580D-D	
D403	8-719-210-21	DIODE 11EQS04		IC411	8-759-711-85	IC NJM4580E-D	
D404	8-719-210-21	DIODE 11EQS04		IC412	8-759-711-85	IC NJM4580E-D	
D405	8-719-988-61	DIODE 1SS355TE-17		IC415	8-759-604-35	IC M5F78M05	
D406	8-719-988-61	DIODE 1SS355TE-17					

AU-211

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
< JACK >				R304	1-216-063-91	RES, CHIP	3.9K 5% 1/10W
J301	1-779-382-21	JACK, PIN 1P (COAXIAL)		R305	1-216-055-00	METAL CHIP	1.8K 5% 1/10W
J302	1-784-675-11	JACK, PIN 3P (COMPONENT VIDEO OUT)		R306	1-216-021-00	METAL CHIP	68 5% 1/10W
J303	1-785-489-11	JACK, PIN 6P (5.1CH OUTPUT)		R307	1-216-021-00	METAL CHIP	68 5% 1/10W
J307	1-774-727-11	JACK, PIN 2P (AUDIO OUT)		R308	1-216-295-91	SHORT	0
J308	1-779-800-11	TERMINAL, S (S VIDEO OUT)		R309	1-216-021-00	METAL CHIP	68 5% 1/10W
J309	1-779-795-11	JACK, PIN 1P (VIDEO OUT)		R310	1-216-021-00	METAL CHIP	68 5% 1/10W
< COIL >				R311	1-216-021-00	METAL CHIP	68 5% 1/10W
L301	1-412-963-11	INDUCTOR 100uH		R312	1-216-033-00	METAL CHIP	220 5% 1/10W
L303	1-412-963-11	INDUCTOR 100uH		R313	1-216-021-00	METAL CHIP	68 5% 1/10W
L401	1-412-953-11	INDUCTOR 15uH		R314	1-216-025-91	RES, CHIP	100 5% 1/10W
L402	1-412-953-11	INDUCTOR 15uH		R315	1-216-021-00	METAL CHIP	68 5% 1/10W
L403	1-412-953-11	INDUCTOR 15uH		R316	1-216-021-00	METAL CHIP	68 5% 1/10W
L404	1-412-953-11	INDUCTOR 15uH		R317	1-216-021-00	METAL CHIP	68 5% 1/10W
L405	1-412-953-11	INDUCTOR 15uH		R320	1-216-073-00	METAL CHIP	10K 5% 1/10W
L406	1-412-953-11	INDUCTOR 15uH		R348	1-216-097-91	RES, CHIP	100K 5% 1/10W
L407	1-412-963-11	INDUCTOR 100uH		R350	1-216-295-91	SHORT	0
< TRANSISTOR >				R400	1-216-065-91	RES, CHIP	4.7K 5% 1/10W
Q301	8-729-421-19	TRANSISTOR UN2213		R401	1-216-037-00	METAL CHIP	330 5% 1/10W
Q302	8-729-424-08	TRANSISTOR UN2111		R402	1-216-047-91	RES, CHIP	820 5% 1/10W
Q303	8-729-120-28	TRANSISTOR 2SC1623-L5L6		R403	1-216-042-00	METAL CHIP	510 5% 1/10W
Q401	8-729-424-08	TRANSISTOR UN2111		R404	1-216-047-91	RES, CHIP	820 5% 1/10W
Q402	8-729-424-08	TRANSISTOR UN2111		R405	1-216-042-00	METAL CHIP	510 5% 1/10W
Q403	8-729-424-08	TRANSISTOR UN2111		R406	1-216-047-91	RES, CHIP	820 5% 1/10W
Q404	8-729-424-08	TRANSISTOR UN2111		R407	1-216-042-00	METAL CHIP	510 5% 1/10W
Q405	8-729-216-22	TRANSISTOR 2SA1162		R408	1-216-073-00	METAL CHIP	10K 5% 1/10W
Q410	8-729-046-97	TRANSISTOR 2SD1938 (F)-T (TX).SO		R409	1-216-097-91	RES, CHIP	100K 5% 1/10W
Q411	8-729-046-97	TRANSISTOR 2SD1938 (F)-T (TX).SO		R410	1-216-097-91	RES, CHIP	100K 5% 1/10W
Q412	8-729-046-97	TRANSISTOR 2SD1938 (F)-T (TX).SO		R411	1-216-097-91	RES, CHIP	100K 5% 1/10W
Q413	8-729-046-97	TRANSISTOR 2SD1938 (F)-T (TX).SO		R412	1-216-097-91	RES, CHIP	100K 5% 1/10W
Q414	8-729-046-97	TRANSISTOR 2SD1938 (F)-T (TX).SO		R413	1-216-073-00	METAL CHIP	10K 5% 1/10W
Q415	8-729-046-97	TRANSISTOR 2SD1938 (F)-T (TX).SO		R414	1-216-097-91	RES, CHIP	100K 5% 1/10W
Q416	8-729-046-97	TRANSISTOR 2SD1938 (F)-T (TX).SO		R415	1-216-061-00	METAL CHIP	3.3K 5% 1/10W
Q417	8-729-046-97	TRANSISTOR 2SD1938 (F)-T (TX).SO		R416	1-216-065-91	RES, CHIP	4.7K 5% 1/10W
Q418	8-729-046-97	TRANSISTOR 2SD1938 (F)-T (TX).SO		R417	1-216-061-00	METAL CHIP	3.3K 5% 1/10W
Q419	8-729-046-97	TRANSISTOR 2SD1938 (F)-T (TX).SO		R418	1-216-065-91	RES, CHIP	4.7K 5% 1/10W
Q420	8-729-141-10	TRANSISTOR 2SA985A		R419	1-216-061-00	METAL CHIP	3.3K 5% 1/10W
Q421	8-729-141-58	TRANSISTOR 2SC2275A-QP		R420	1-216-063-91	RES, CHIP	3.9K 5% 1/10W
Q422	8-729-224-62	TRANSISTOR 2SK246-GR		R423	1-216-109-00	METAL CHIP	330K 5% 1/10W
Q423	8-729-421-19	TRANSISTOR UN2213		R425	1-216-109-00	METAL CHIP	330K 5% 1/10W
Q424	8-729-421-19	TRANSISTOR UN2213		R426	1-216-109-00	METAL CHIP	330K 5% 1/10W
Q425	8-729-422-03	TRANSISTOR XN1B301-TX		R428	1-216-109-00	METAL CHIP	330K 5% 1/10W
Q426	8-729-422-03	TRANSISTOR XN1B301-TX		R429	1-216-109-00	METAL CHIP	330K 5% 1/10W
Q427	8-729-422-03	TRANSISTOR XN1B301-TX		R430	1-216-066-00	METAL CHIP	5.1K 5% 1/10W
Q431	8-729-424-08	TRANSISTOR UN2111		R431	1-216-109-00	METAL CHIP	330K 5% 1/10W
Q432	8-729-424-08	TRANSISTOR UN2111		R432	1-216-109-00	METAL CHIP	330K 5% 1/10W
Q433	8-729-424-08	TRANSISTOR UN2111		R433	1-216-066-00	METAL CHIP	5.1K 5% 1/10W
Q434	8-729-424-08	TRANSISTOR UN2111		R434	1-216-109-00	METAL CHIP	330K 5% 1/10W
Q435	8-729-421-19	TRANSISTOR UN2213		R435	1-216-049-91	RES, CHIP	1K 5% 1/10W
Q437	8-729-424-08	TRANSISTOR UN2111		R437	1-216-066-00	METAL CHIP	5.1K 5% 1/10W
Q438	8-729-421-19	TRANSISTOR UN2213		R438	1-216-067-00	METAL CHIP	5.6K 5% 1/10W
Q439	8-729-424-08	TRANSISTOR UN2111		R439	1-259-452-11	CARBON	10K 5% 1/6W
Q440	8-729-421-19	TRANSISTOR UN2213		R440	1-216-073-00	METAL CHIP	10K 5% 1/10W
< RESISTOR >				R441	1-216-073-00	METAL CHIP	10K 5% 1/10W
R301	1-216-057-00	METAL CHIP 2.2K	5% 1/10W	R442	1-216-075-00	METAL CHIP	12K 5% 1/10W
R302	1-216-073-00	METAL CHIP 10K	5% 1/10W	R443	1-259-452-11	CARBON	10K 5% 1/6W
R303	1-216-073-00	METAL CHIP 10K	5% 1/10W	R444	1-216-073-00	METAL CHIP	10K 5% 1/10W
				R445	1-216-073-00	METAL CHIP	10K 5% 1/10W
				R446	1-216-073-00	METAL CHIP	10K 5% 1/10W
				R447	1-259-426-11	CARBON	820 5% 1/6W

Ref. No.	Part No.	Description			Remark	Ref. No.	Part No.	Description			Remark
R448	1-216-047-91	RES, CHIP	820	5%	1/10W	R509	1-259-420-11	CARBON	470	5%	1/6W
R449	1-216-047-91	RES, CHIP	820	5%	1/10W	R510	1-216-085-00	METAL CHIP	33K	5%	1/10W
R450	1-216-063-91	RES, CHIP	3.9K	5%	1/10W	R511	1-216-077-00	METAL CHIP	15K	5%	1/10W
R451	1-259-426-11	CARBON	820	5%	1/6W	R512	1-216-077-00	METAL CHIP	15K	5%	1/10W
R452	1-216-047-91	RES, CHIP	820	5%	1/10W	R513	1-216-085-00	METAL CHIP	33K	5%	1/10W
R453	1-216-047-91	RES, CHIP	820	5%	1/10W	R514	1-216-025-91	RES, CHIP	100	5%	1/10W
R454	1-216-047-91	RES, CHIP	820	5%	1/10W	R515	1-216-025-91	RES, CHIP	100	5%	1/10W
R455	1-259-434-11	CARBON	1.8K	5%	1/6W	R516	1-216-049-91	RES, CHIP	1K	5%	1/10W
R456	1-259-424-11	CARBON	680	5%	1/6W	R517	1-216-049-91	RES, CHIP	1K	5%	1/10W
R457	1-259-424-11	CARBON	680	5%	1/6W	R519	1-259-440-11	CARBON	3.3K	5%	1/6W
R458	1-259-434-11	CARBON	1.8K	5%	1/6W	R520	1-259-404-11	CARBON	100	5%	1/6W
R459	1-216-055-00	METAL CHIP	1.8K	5%	1/10W	R521	1-259-440-11	CARBON	3.3K	5%	1/6W
R460	1-216-045-00	METAL CHIP	680	5%	1/10W	R523	1-259-404-11	CARBON	100	5%	1/6W
R461	1-216-045-00	METAL CHIP	680	5%	1/10W	R524	1-259-466-11	CARBON	39K	5%	1/6W
R462	1-216-055-00	METAL CHIP	1.8K	5%	1/10W	R525	1-259-404-11	CARBON	100	5%	1/6W
R463	1-216-055-00	METAL CHIP	1.8K	5%	1/10W	R526	1-216-081-00	METAL CHIP	22K	5%	1/10W
R464	1-216-045-00	METAL CHIP	680	5%	1/10W	R531	1-216-097-91	RES, CHIP	100K	5%	1/10W
R465	1-216-045-00	METAL CHIP	680	5%	1/10W	R532	1-216-097-91	RES, CHIP	100K	5%	1/10W
R466	1-216-055-00	METAL CHIP	1.8K	5%	1/10W	R533	1-216-097-91	RES, CHIP	100K	5%	1/10W
R467	1-216-055-00	METAL CHIP	1.8K	5%	1/10W	R534	1-216-097-91	RES, CHIP	100K	5%	1/10W
R468	1-216-045-00	METAL CHIP	680	5%	1/10W	R536	1-216-295-91	SHORT	0		
R469	1-216-061-00	METAL CHIP	3.3K	5%	1/10W	R538	1-216-295-91	SHORT	0		
R470	1-216-075-00	METAL CHIP	12K	5%	1/10W	R539	1-216-295-91	SHORT	0		
R471	1-216-109-00	METAL CHIP	330K	5%	1/10W	R540	1-216-295-91	SHORT	0		
R472	1-216-109-00	METAL CHIP	330K	5%	1/10W	R542	1-259-445-11	CARBON	5.1K	5%	1/6W
R473	1-216-109-00	METAL CHIP	330K	5%	1/10W	R543	1-259-445-11	CARBON	5.1K	5%	1/6W
R474	1-216-109-00	METAL CHIP	330K	5%	1/10W	R544	1-216-063-91	RES, CHIP	3.9K	5%	1/10W
R475	1-216-109-00	METAL CHIP	330K	5%	1/10W	R545	1-216-059-00	METAL CHIP	2.7K	5%	1/10W
R476	1-216-109-00	METAL CHIP	330K	5%	1/10W	R546	1-216-085-00	METAL CHIP	33K	5%	1/10W
R477	1-216-109-00	METAL CHIP	330K	5%	1/10W	R547	1-216-059-00	METAL CHIP	2.7K	5%	1/10W
R478	1-216-109-00	METAL CHIP	330K	5%	1/10W	R548	1-259-445-11	CARBON	5.1K	5%	1/6W
R479	1-259-412-11	CARBON	220	5%	1/6W	R549	1-259-445-11	CARBON	5.1K	5%	1/6W
R480	1-216-041-00	METAL CHIP	470	5%	1/10W	R550	1-216-081-00	METAL CHIP	22K	5%	1/10W
R481	1-216-041-00	METAL CHIP	470	5%	1/10W	R552	1-216-066-00	METAL CHIP	5.1K	5%	1/10W
R482	1-216-041-00	METAL CHIP	470	5%	1/10W	R553	1-216-066-00	METAL CHIP	5.1K	5%	1/10W
R483	1-216-085-00	METAL CHIP	33K	5%	1/10W	R556	1-216-066-00	METAL CHIP	5.1K	5%	1/10W
R484	1-216-085-00	METAL CHIP	33K	5%	1/10W	R557	1-216-066-00	METAL CHIP	5.1K	5%	1/10W
R485	1-259-412-11	CARBON	220	5%	1/6W						
R486	1-216-041-00	METAL CHIP	470	5%	1/10W	*	A-6065-355-A	ER-4 BOARD, COMPLETE (S525D)			
R487	1-216-041-00	METAL CHIP	470	5%	1/10W	*	A-6065-249-A	ER-5 BOARD, COMPLETE (S725D)			
R488	1-216-041-00	METAL CHIP	470	5%	1/10W	*****					
R489	1-216-049-91	RES, CHIP	1K	5%	1/10W	(Ref. No. 2,000 Series)					
R490	1-216-049-91	RES, CHIP	1K	5%	1/10W	< CAPACITOR >					
R491	1-216-049-91	RES, CHIP	1K	5%	1/10W	C901	1-104-664-11	ELECT	47uF	20%	16V
R492	1-216-025-91	RES, CHIP	100	5%	1/10W	C902	1-163-021-91	CERAMIC CHIP	0.01uF	10%	50V
R493	1-216-025-91	RES, CHIP	100	5%	1/10W	C903	1-104-664-11	ELECT	47uF	20%	16V
R494	1-216-049-91	RES, CHIP	1K	5%	1/10W	C904	1-163-021-91	CERAMIC CHIP	0.01uF	10%	50V
R495	1-216-049-91	RES, CHIP	1K	5%	1/10W	C905	1-104-664-11	ELECT	47uF	20%	16V
R496	1-216-025-91	RES, CHIP	100	5%	1/10W	C906	1-163-021-91	CERAMIC CHIP	0.01uF	10%	50V
R497	1-216-025-91	RES, CHIP	100	5%	1/10W	C907	1-104-664-11	ELECT	47uF	20%	16V
R498	1-216-049-91	RES, CHIP	1K	5%	1/10W	C908	1-128-551-11	ELECT	22uF	20%	25V
R499	1-216-049-91	RES, CHIP	1K	5%	1/10W	C909	1-128-551-11	ELECT	22uF	20%	25V
R500	1-216-025-91	RES, CHIP	100	5%	1/10W	C910	1-128-551-11	ELECT	22uF	20%	25V
R501	1-216-025-91	RES, CHIP	100	5%	1/10W	C911	1-163-021-91	CERAMIC CHIP	0.01uF	10%	50V
R502	1-216-049-91	RES, CHIP	1K	5%	1/10W	C912	1-128-551-11	ELECT	22uF	20%	25V
R504	1-216-085-00	METAL CHIP	33K	5%	1/10W	C913	1-163-021-91	CERAMIC CHIP	0.01uF	10%	50V
R505	1-216-085-00	METAL CHIP	33K	5%	1/10W	C914	1-126-935-11	ELECT	470uF	20%	6.3V
R506	1-259-420-11	CARBON	470	5%	1/6W	C915	1-128-551-11	ELECT	22uF	20%	25V
R507	1-259-420-11	CARBON	470	5%	1/6W	C916	1-126-935-11	ELECT	470uF	20%	6.3V
R508	1-259-420-11	CARBON	470	5%	1/6W						

Ref. No.	Part No.	Description	Remark			
C917	1-128-551-11	ELECT	22uF	20%	25V	
C918	1-126-935-11	ELECT	470uF	20%	6.3V	
C919	1-128-551-11	ELECT	22uF	20%	25V	
C920	1-163-021-91	CERAMIC CHIP	0.01uF	10%	50V	
C921	1-128-551-11	ELECT	22uF	20%	25V	
C922	1-128-551-11	ELECT	22uF	20%	25V	
C923	1-163-021-91	CERAMIC CHIP	0.01uF	10%	50V	
C924	1-126-935-11	ELECT	470uF	20%	6.3V	
C926	1-104-664-11	ELECT	47uF	20%	16V	
C927	1-163-021-91	CERAMIC CHIP	0.01uF	10%	50V	
C938	1-163-133-00	CERAMIC CHIP	470PF	5%	50V	
C939	1-163-133-00	CERAMIC CHIP	470PF	5%	50V	
C940	1-163-133-00	CERAMIC CHIP	470PF	5%	50V	
C941	1-163-133-00	CERAMIC CHIP	470PF	5%	50V	
C942	1-163-133-00	CERAMIC CHIP	470PF	5%	50V	
C943	1-163-133-00	CERAMIC CHIP	470PF	5%	50V	
C944	1-163-133-00	CERAMIC CHIP	470PF	5%	50V	
C945	1-163-133-00	CERAMIC CHIP	470PF	5%	50V	
C950	1-163-251-11	CERAMIC CHIP	100PF	5%	50V	
C951	1-163-251-11	CERAMIC CHIP	100PF	5%	50V	
C962	1-163-251-11	CERAMIC CHIP	100PF	5%	50V	
C963	1-163-251-11	CERAMIC CHIP	100PF	5%	50V	
C972	1-163-021-91	CERAMIC CHIP	0.01uF	10%	50V	
C973	1-163-239-11	CERAMIC CHIP	33PF	5%	50V	
C974	1-163-239-11	CERAMIC CHIP	33PF	5%	50V	
C975	1-163-239-11	CERAMIC CHIP	33PF	5%	50V	
C976	1-163-233-11	CERAMIC CHIP	18PF	5%	50V	
C977	1-163-233-11	CERAMIC CHIP	18PF	5%	50V	
C978	1-163-233-11	CERAMIC CHIP	18PF	5%	50V	
< CONNECTOR >						
CN901	1-785-729-21	CONNECTOR, FFC/FPC 7P				
CN902	1-785-732-21	CONNECTOR, FFC/FPC 18P				
CN903	1-251-780-11	SOCKET, PIN (21P) (EURO AV2)				
CN904	1-251-780-11	SOCKET, PIN (21P) (EURO AV1 (RGB)-TV)				
< DIODE >						
D901	8-719-988-61	DIODE 1SS355TE-17				
D902	8-719-988-61	DIODE 1SS355TE-17				
D903	8-719-988-61	DIODE 1SS355TE-17				
D904	8-719-988-61	DIODE 1SS355TE-17				
D905	8-719-988-61	DIODE 1SS355TE-17				
D906	8-719-988-61	DIODE 1SS355TE-17				
D907	8-719-988-61	DIODE 1SS355TE-17 (S725D)				
D908	8-719-071-15	DIODE HZM6.8ZWA1TL				
D910	8-719-988-61	DIODE 1SS355TE-17 (S725D)				
D915	8-719-071-15	DIODE HZM6.8ZWA1TL				
D917	8-719-071-15	DIODE HZM6.8ZWA1TL				
D918	8-719-071-15	DIODE HZM6.8ZWA1TL				
D919	8-719-071-15	DIODE HZM6.8ZWA1TL				
D920	8-719-071-15	DIODE HZM6.8ZWA1TL				
D921	8-719-071-15	DIODE HZM6.8ZWA1TL				
D922	8-719-071-15	DIODE HZM6.8ZWA1TL				
D923	8-719-071-15	DIODE HZM6.8ZWA1TL				
D924	8-719-071-15	DIODE HZM6.8ZWA1TL				
D926	8-719-056-82	DIODE Udz-TE-17-6.2B				
D927	8-719-977-40	DIODE Udz-TE-17-13B				
D929	8-719-056-82	DIODE Udz-TE-17-6.2B				
D930	8-719-977-40	DIODE Udz-TE-17-13B				

Ref. No.	Part No.	Description	Remark	
		< EARTH TERMINAL >		
* ET901	1-537-738-21	TERMINAL, EARTH		
		< FERRITE BEAD >		
FB901	1-414-553-11	FERRITE	0uH	
FB902	1-414-553-11	FERRITE	0uH	
FB903	1-414-553-11	FERRITE	0uH	
FB904	1-414-553-11	FERRITE	0uH	
FB905	1-414-553-11	FERRITE	0uH	
FB906	1-414-553-11	FERRITE	0uH	
FB907	1-414-553-11	FERRITE	0uH	
FB908	1-414-553-11	FERRITE	0uH	
FB909	1-414-553-11	FERRITE	0uH	
FB910	1-414-553-11	FERRITE	0uH	
FB911	1-414-553-11	FERRITE	0uH	
FB912	1-414-553-11	FERRITE	0uH	
FB913	1-414-553-11	FERRITE	0uH	
FB914	1-414-553-11	FERRITE	0uH	
FB915	1-414-553-11	FERRITE	0uH	
FB916	1-414-553-11	FERRITE	0uH	
FB917	1-414-553-11	FERRITE	0uH	
FB918	1-414-553-11	FERRITE	0uH	
		< IC >		
IC901	8-759-563-79	IC BA7660F-E2 (S525D)		
IC901	8-759-522-11	IC BA7660FS-E2 (S725D)		
IC902	8-759-432-78	IC MM1111XFB		
IC903	8-759-567-33	IC MM1225XFB		
		< JUMPER RESISTOR >		
JR900	1-216-296-91	SHORT	0 (S525D)	
JR901	1-216-296-91	SHORT	0 (S525D)	
JR902	1-216-295-91	SHORT	0 (S525D)	
JR903	1-216-296-91	SHORT	0 (S525D)	
JR904	1-216-296-91	SHORT	0 (S525D)	
JR905	1-216-295-91	SHORT	0 (S525D)	
JR906	1-216-295-91	SHORT	0 (S525D)	
JR907	1-216-296-91	SHORT	0 (S525D)	
JR908	1-216-296-91	SHORT	0 (S525D)	
JR909	1-216-296-91	SHORT	0 (S525D)	
JR910	1-216-295-91	SHORT	0 (S525D)	
JR911	1-216-296-91	SHORT	0 (S525D)	
JR912	1-216-296-91	SHORT	0 (S525D)	
JR913	1-216-295-91	SHORT	0 (S525D)	
JR914	1-216-296-91	SHORT	0 (S525D)	
JR915	1-216-296-91	SHORT	0 (S525D)	
JR916	1-216-296-91	SHORT	0 (S525D)	
JR917	1-216-295-91	SHORT	0 (S525D)	
JR918	1-216-296-91	SHORT	0 (S525D)	
JR919	1-216-296-91	SHORT	0 (S525D)	
JR920	1-216-296-91	SHORT	0 (S525D)	
JR921	1-216-295-91	SHORT	0 (S525D)	
JR922	1-216-295-91	SHORT	0 (S525D)	
JR923	1-216-296-91	SHORT	0 (S525D)	
JR924	1-216-295-91	SHORT	0 (S525D)	
JR925	1-216-296-91	SHORT	0 (S525D)	
JR926	1-216-296-91	SHORT	0 (S525D)	
JR927	1-216-295-91	SHORT	0 (S525D)	
JR928	1-216-296-91	SHORT	0 (S525D)	
JR929	1-216-296-91	SHORT	0 (S525D)	

ER-4

ER-5

FL-98

FL-100

Ref. No.	Part No.	Description	Remark			Ref. No.	Part No.	Description	Remark		
JR930	1-216-296-91	SHORT	0 (S525D)			R925	1-216-049-91	RES, CHIP	1K	5%	1/10W
JR932	1-216-296-91	SHORT	0 (S525D)			R926	1-216-049-91	RES, CHIP	1K	5%	1/10W
JR933	1-216-296-91	SHORT	0 (S525D)			R927	1-216-020-00	METAL CHIP	62	5%	1/10W
JR934	1-216-296-91	SHORT	0 (S525D)			R928	1-216-021-00	METAL CHIP	68	5%	1/10W
JR935	1-216-296-91	SHORT	0 (S525D)			R929	1-216-021-00	METAL CHIP	68	5%	1/10W
JR936	1-216-295-91	SHORT	0 (S525D)			R930	1-216-065-91	RES, CHIP	4.7K	5%	1/10W
JR937	1-216-295-91	SHORT	0 (S525D)			R931	1-216-065-91	RES, CHIP	4.7K	5%	1/10W
						R932	1-216-065-91	RES, CHIP	4.7K	5%	1/10W
		< COIL >				R933	1-216-065-91	RES, CHIP	4.7K	5%	1/10W
L901	1-412-064-11	INDUCTOR CHIP	100uH			R934	1-216-065-91	RES, CHIP	4.7K	5%	1/10W
L902	1-412-064-11	INDUCTOR CHIP	100uH			R938	1-216-025-91	RES, CHIP	100	5%	1/10W
L903	1-412-058-11	INDUCTOR CHIP	10uH			R939	1-216-017-91	RES, CHIP	47	5%	1/10W
L904	1-412-064-11	INDUCTOR CHIP	100uH			R940	1-216-042-00	METAL CHIP	510	5%	1/10W
L905	1-412-953-11	INDUCTOR	15uH								(S525D)
L906	1-412-953-11	INDUCTOR	15uH			R940	1-216-047-91	RES, CHIP	820	5%	1/10W
L907	1-412-953-11	INDUCTOR	15uH			R941	1-216-042-00	METAL CHIP	510	5%	1/10W
		< TRANSISTOR >				R941	1-216-047-91	RES, CHIP	820	5%	1/10W
Q901	8-729-421-19	TRANSISTOR	UN2213			R942	1-216-042-00	METAL CHIP	510	5%	1/10W
Q902	8-729-422-27	TRANSISTOR	2SD601A-Q			R942	1-216-047-91	RES, CHIP	820	5%	1/10W
Q903	8-729-424-08	TRANSISTOR	UN2111								(S725D)
Q904	8-729-421-19	TRANSISTOR	UN2213								(S525D)
Q905	8-729-422-27	TRANSISTOR	2SD601A-Q			R943	1-216-073-00	METAL CHIP	10K	5%	1/10W
Q906	8-729-421-19	TRANSISTOR	UN2213			R944	1-216-073-00	METAL CHIP	10K	5%	1/10W
Q907	8-729-424-08	TRANSISTOR	UN2111			R945	1-216-081-00	METAL CHIP	22K	5%	1/10W
Q908	8-729-421-22	TRANSISTOR	UN2211								(S725D)
Q909	8-729-421-19	TRANSISTOR	UN2213			R946	1-216-065-91	RES, CHIP	4.7K	5%	1/10W
Q910	8-729-424-08	TRANSISTOR	UN2111			R948	1-216-022-00	METAL CHIP	75	5%	1/10W
Q912	8-729-422-27	TRANSISTOR	2SD601A-Q					< RELAY >			
Q913	8-729-422-27	TRANSISTOR	2SD601A-Q			RY901	1-755-041-11	RELAY			
Q914	8-729-422-27	TRANSISTOR	2SD601A-Q			RY902	1-755-041-11	RELAY			
Q915	8-729-422-27	TRANSISTOR	2SD601A-Q			RY903	1-755-041-11	RELAY			
Q916	8-729-422-27	TRANSISTOR	2SD601A-Q			RY904	1-755-041-11	RELAY			
Q917	8-729-421-19	TRANSISTOR	UN2213 (S725D)			RY905	1-755-041-11	RELAY			
Q918	8-729-421-19	TRANSISTOR	UN2213 (S725D)								
		< RESISTOR >									
R901	1-216-113-00	METAL CHIP	470K	5%	1/10W	*	A-6065-227-A	FL-98 BOARD, COMPLETE (S525D)			
R902	1-216-095-00	METAL CHIP	82K	5%	1/10W	*	A-6065-250-A	FL-100 BOARD, COMPLETE (S725D)			
R903	1-216-113-00	METAL CHIP	470K	5%	1/10W			*****			(Ref. No. 2,000 Series)
R904	1-216-095-00	METAL CHIP	82K	5%	1/10W						
R905	1-216-113-00	METAL CHIP	470K	5%	1/10W		3-053-487-01	HOLDER, FL TUBE			
R906	1-216-095-00	METAL CHIP	82K	5%	1/10W			< CAPACITOR >			
R907	1-216-089-91	RES, CHIP	47K	5%	1/10W	C201	1-124-259-11	ELECT	4.7uF	20%	16V
R908	1-216-105-91	RES, CHIP	220K	5%	1/10W	C203	1-164-004-11	CERAMIC CHIP	0.1uF	10%	25V
R909	1-216-039-00	METAL CHIP	390	5%	1/10W	C205	1-164-004-11	CERAMIC CHIP	0.1uF	10%	25V
R910	1-216-039-00	METAL CHIP	390	5%	1/10W	C209	1-163-021-91	CERAMIC CHIP	0.01uF	10%	50V
R911	1-216-039-00	METAL CHIP	390	5%	1/10W						(S725D)
R912	1-216-039-00	METAL CHIP	390	5%	1/10W	C210	1-163-021-91	CERAMIC CHIP	0.01uF	10%	50V
R913	1-216-057-00	METAL CHIP	2.2K	5%	1/10W						(S725D)
R914	1-216-057-00	METAL CHIP	2.2K	5%	1/10W	C211	1-164-004-11	CERAMIC CHIP	0.1uF	10%	25V
R915	1-216-045-00	METAL CHIP	680	5%	1/10W	C212	1-163-021-91	CERAMIC CHIP	0.01uF	10%	50V
R916	1-216-057-00	METAL CHIP	2.2K	5%	1/10W	C213	1-163-021-91	CERAMIC CHIP	0.01uF	10%	50V
R917	1-216-057-00	METAL CHIP	2.2K	5%	1/10W	C214	1-163-021-91	CERAMIC CHIP	0.01uF	10%	50V
R918	1-216-021-00	METAL CHIP	68	5%	1/10W	C215	1-163-021-91	CERAMIC CHIP	0.01uF	10%	50V
R920	1-216-049-91	RES, CHIP	1K	5%	1/10W						
R922	1-216-021-00	METAL CHIP	68	5%	1/10W	C216	1-163-021-91	CERAMIC CHIP	0.01uF	10%	50V
						C219	1-115-339-11	CERAMIC CHIP	0.1uF	10%	50V
R923	1-216-049-91	RES, CHIP	1K	5%	1/10W	C220	1-115-339-11	CERAMIC CHIP	0.1uF	10%	50V
R924	1-216-049-91	RES, CHIP	1K	5%	1/10W	C221	1-164-004-11	CERAMIC CHIP	0.1uF	10%	25V

Ref. No.	Part No.	Description	Remark		
C222	1-164-004-11	CERAMIC CHIP 0.1uF 10%	25V		
C223	1-128-131-11	ELECT 22uF 20%	50V		
C235	1-163-259-91	CERAMIC CHIP 220PF 5%	50V		
C236	1-163-259-91	CERAMIC CHIP 220PF 5%	50V		
C237	1-163-259-91	CERAMIC CHIP 220PF 5%	50V		
C238	1-163-259-91	CERAMIC CHIP 220PF 5%	50V		
C239	1-163-259-91	CERAMIC CHIP 220PF 5%	50V		
C240	1-163-259-91	CERAMIC CHIP 220PF 5%	50V		
C241	1-163-259-91	CERAMIC CHIP 220PF 5%	50V		
C242	1-163-259-91	CERAMIC CHIP 220PF 5%	50V		
C243	1-163-259-91	CERAMIC CHIP 220PF 5%	50V		
< CONNECTOR >					
CN201	1-568-666-21	CONNECTOR, BOARD TO BOARD 12P			
CN202	1-785-731-21	CONNECTOR, FFC/FPC 17P			
CN203	1-785-730-21	CONNECTOR, FFC/FPC 9P			
< DIODE >					
D202	8-719-988-61	DIODE 1SS355TE-17			
D203	8-719-069-45	DIODE SELU5E23C-TP15 (MULTI CHANNEL)			
D204	8-719-056-06	DIODE SLR-342DCT31 (JOG)			
D206	8-719-018-12	DIODE MA8330-L-TX			
D207	8-719-422-67	DIODE MA8062-H-TX			
< EARTH TERMINAL >					
* ET201	1-537-738-21	TERMINAL, EARTH (S725D)			
< FERRITE BEAD >					
FB201	1-414-135-11	FERRITE 0uH			
< IC >					
IC201	8-759-574-86	IC M38B57MCH-E206FP			
IC202	8-759-326-78	IC PST9140NL			
< JUMPER RESISTOR >					
JR201	1-216-295-91	SHORT 0 (S525D)			
JR202	1-216-295-91	SHORT 0 (S525D)			
JR203	1-216-295-91	SHORT 0 (S525D)			
JR204	1-216-295-91	SHORT 0 (S525D)			
JR205	1-216-296-91	SHORT 0 (S525D)			
JR206	1-216-295-91	SHORT 0 (S525D)			
JR207	1-216-296-91	SHORT 0 (S525D)			
JR208	1-216-295-91	SHORT 0 (S525D)			
JR209	1-216-296-91	SHORT 0 (S525D)			
JR210	1-216-296-91	SHORT 0 (S525D)			
JR211	1-216-295-91	SHORT 0 (S525D)			
JR212	1-216-296-91	SHORT 0 (S525D)			
JR214	1-216-296-91	SHORT 0 (S525D)			
JR216	1-216-296-91	SHORT 0 (S525D)			
JR217	1-216-296-91	SHORT 0 (S525D)			
JR218	1-216-295-91	SHORT 0 (S525D)			
JR219	1-216-295-91	SHORT 0 (S525D)			
JR220	1-216-295-91	SHORT 0 (S525D)			
JR224	1-216-296-91	SHORT 0 (S525D)			
JR226	1-216-295-91	SHORT 0 (S525D)			
JR229	1-216-296-91	SHORT 0 (S525D)			
JR230	1-216-296-91	SHORT 0 (S525D)			
JR231	1-216-295-91	SHORT 0 (S525D)			
JR233	1-216-296-91	SHORT 0 (S525D)			
JR234	1-216-295-91	SHORT 0 (S525D)			

Ref. No.	Part No.	Description	Remark		
JR235	1-216-295-91	SHORT	0 (S525D)		
JR236	1-216-295-91	SHORT	0 (S525D)		
JR237	1-216-295-91	SHORT	0 (S525D)		
JR238	1-216-296-91	SHORT	0 (S525D)		
JR244	1-216-295-91	SHORT	0 (S525D)		
JR249	1-216-296-91	SHORT	0 (S525D)		
		< FLUORESCENT INDICATOR >			
ND201	1-517-836-11	INDICATOR TUBE, FLUORESCENT			
		< TRANSISTOR >			
Q201	8-729-804-41	TRANSISTOR	2SB1122-S		
		< RESISTOR >			
R201	1-208-806-11	RES, CHIP	10K	0.50%	1/10W
R202	1-216-053-00	METAL CHIP	1.5K	5%	1/10W
R203	1-216-055-00	METAL CHIP	1.8K	5%	1/10W
R204	1-216-059-00	METAL CHIP	2.7K	5%	1/10W
R205	1-216-061-00	METAL CHIP	3.3K	5%	1/10W
R206	1-216-065-91	RES, CHIP	4.7K	5%	1/10W
R207	1-216-071-00	METAL CHIP	8.2K	5%	1/10W
R208	1-216-077-00	METAL CHIP	15K	5%	1/10W
R209	1-216-091-00	METAL CHIP	56K	5%	1/10W
R211	1-208-806-11	RES, CHIP	10K	0.50%	1/10W
R212	1-216-053-00	METAL CHIP	1.5K	5%	1/10W
R213	1-216-055-00	METAL CHIP	1.8K	5%	1/10W
R214	1-216-059-00	METAL CHIP	2.7K	5%	1/10W
R215	1-216-061-00	METAL CHIP	3.3K	5%	1/10W
R216	1-216-065-91	RES, CHIP	4.7K	5%	1/10W
R217	1-216-071-00	METAL CHIP	8.2K	5%	1/10W
R218	1-216-077-00	METAL CHIP	15K	5%	1/10W
R221	1-208-806-11	RES, CHIP	10K	0.50%	1/10W
R222	1-216-053-00	METAL CHIP	1.5K	5%	1/10W
R223	1-216-055-00	METAL CHIP	1.8K	5%	1/10W
R224	1-216-059-00	METAL CHIP	2.7K	5%	1/10W
R225	1-216-061-00	METAL CHIP	3.3K	5%	1/10W
R226	1-216-025-91	RES, CHIP	100	5%	1/10W
R227	1-216-025-91	RES, CHIP	100	5%	1/10W
R229	1-216-063-91	RES, CHIP	3.9K	5%	1/10W
R230	1-216-073-00	METAL CHIP	10K	5%	1/10W
R231	1-216-025-91	RES, CHIP	100	5%	1/10W
R232	1-216-025-91	RES, CHIP	100	5%	1/10W
R241	1-216-073-00	METAL CHIP	10K	5%	1/10W
R243	1-216-073-00	METAL CHIP	10K	5%	1/10W
R244	1-216-073-00	METAL CHIP	10K	5%	1/10W
R247	1-216-073-00	METAL CHIP	10K	5%	1/10W
R248	1-216-073-00	METAL CHIP	10K	5%	1/10W
R249	1-216-073-00	METAL CHIP	10K	5%	1/10W
R250	1-216-073-00	METAL CHIP	10K	5%	1/10W
R251	1-216-049-91	RES, CHIP	1K	5%	1/10W
R252	1-216-049-91	RES, CHIP	1K	5%	1/10W
R253	1-216-073-00	METAL CHIP	10K	5%	1/10W
R254	1-216-073-00	METAL CHIP	10K	5%	1/10W
R255	1-216-073-00	METAL CHIP	10K	5%	1/10W
R256	1-216-073-00	METAL CHIP	10K	5%	1/10W
R257	1-216-025-91	RES, CHIP	100	5%	1/10W
R258	1-216-025-91	RES, CHIP	100	5%	1/10W
R259	1-216-025-91	RES, CHIP	100	5%	1/10W

FL-98

FL-100

FR-147

FR-149

HP-108

HP-110

Ref. No.	Part No.	Description	Remark		
R260	1-216-025-91	RES, CHIP	100	5%	1/10W
R261	1-216-025-91	RES, CHIP	100	5%	1/10W
R262	1-216-025-91	RES, CHIP	100	5%	1/10W
R263	1-216-073-00	METAL CHIP	10K	5%	1/10W
R264	1-216-073-00	METAL CHIP	10K	5%	1/10W
R266	1-216-057-00	METAL CHIP	2.2K	5%	1/10W (S725D)
R267	1-216-049-91	RES, CHIP	1K	5%	1/10W
R268	1-216-089-91	RES, CHIP	47K	5%	1/10W
R270	1-216-073-00	METAL CHIP	10K	5%	1/10W
R271	1-216-073-00	METAL CHIP	10K	5%	1/10W
R272	1-216-065-91	RES, CHIP	4.7K	5%	1/10W
R273	1-216-025-91	RES, CHIP	100	5%	1/10W
R274	1-216-097-91	RES, CHIP	100K	5%	1/10W
R275	1-216-073-00	METAL CHIP	10K	5%	1/10W
R276	1-216-073-00	METAL CHIP	10K	5%	1/10W
R277	1-216-073-00	METAL CHIP	10K	5%	1/10W
R278	1-216-073-00	METAL CHIP	10K	5%	1/10W
R279	1-216-073-00	METAL CHIP	10K	5%	1/10W
R284	1-216-073-00	METAL CHIP	10K	5%	1/10W
R285	1-216-045-00	METAL CHIP	680	5%	1/10W
R286	1-216-073-00	METAL CHIP	10K	5%	1/10W
R287	1-216-037-00	METAL CHIP	330	5%	1/10W
R288	1-216-073-00	METAL CHIP	10K	5%	1/10W
R289	1-216-073-00	METAL CHIP	10K	5%	1/10W
R298	1-216-025-91	RES, CHIP	100	5%	1/10W (S725D)
R299	1-216-025-91	RES, CHIP	100	5%	1/10W (S725D)
< SWITCH >					
S201	1-771-349-21	SWITCH, KEYBOARD (■)			
S202	1-771-349-21	SWITCH, KEYBOARD (■)			
S208	1-771-349-21	SWITCH, KEYBOARD (JOG)			
S212	1-771-349-21	SWITCH, KEYBOARD (OPEN/CLOSE △)			
S213	1-771-349-21	SWITCH, KEYBOARD (▶)			
S214	1-771-349-21	SWITCH, KEYBOARD (TITLE)			
S215	1-771-349-21	SWITCH, KEYBOARD (DVD MENU)			
S216	1-771-349-21	SWITCH, KEYBOARD (RETURN)			
S217	1-771-349-21	SWITCH, KEYBOARD (PREV ◀◀) (S525D)			
S217	1-771-349-21	SWITCH, KEYBOARD (◀◀ SEARCH) (S725D)			
S218	1-771-349-21	SWITCH, KEYBOARD (▶▶ NEXT) (S525D)			
S218	1-771-349-21	SWITCH, KEYBOARD (SEARCH ▶▶) (S725D)			
S221	1-771-349-21	SWITCH, KEYBOARD (REREAT)			
S222	1-771-349-21	SWITCH, KEYBOARD (CLEAR)			
S223	1-771-349-21	SWITCH, KEYBOARD (PROGRAM)			
S224	1-771-349-21	SWITCH, KEYBOARD (SHUFFLE)			
S230	1-475-235-21	ENCODER, ROTARY (PREV ◀◀ ▶▶ NEXT) (S725D)			
< VIBRATOR >					
X201	1-577-358-21	VIBRATOR, CERAMIC (4MHz)			
< CAPACITOR >					
* A-6065-228-A	FR-147 BOARD, COMPLETE (S525D)				
* A-6065-251-A	FR-149 BOARD, COMPLETE (S725D)				

(Ref. No. 4,000 Series)					
< CAPACITOR >					
C001	1-124-234-00	ELECT	22uF	20%	16V

Ref. No.	Part No.	Description	Remark		
C002	1-137-150-11	FILM	0.01uF	5%	100V
C003	1-115-339-11	CERAMIC CHIP	0.1uF	10%	50V
C004	1-115-339-11	CERAMIC CHIP	0.1uF	10%	50V
C005	1-128-131-11	ELECT	22uF	20%	50V
C051	1-164-004-11	CERAMIC CHIP	0.1uF	10%	25V
< CONNECTOR >					
CN001	1-506-485-11	PIN, CONNECTOR 6P			
CN002	1-568-672-11	CONNECTOR, BOARD TO BOARD 12P			
CN003	1-785-712-11	CONNECTOR, BOARD TO BOARD 4P			
< DIODE >					
D001	8-719-041-97	DIODE MA113-(TX)			
D002	8-719-041-97	DIODE MA113-(TX)			
D003	8-719-041-97	DIODE MA113-(TX)			
D004	8-719-041-97	DIODE MA113-(TX)			
D071	8-719-064-11	DIODE SPR-325MVW (ON/STANDBY)			
< FERRITE BEAD >					
FB001	1-414-135-11	FERRITE	0uH		
FB002	1-414-135-11	FERRITE	0uH		
FB004	1-469-324-21	FERRITE	0uH		
< IC >					
IC051	8-749-011-22	IC GP1U27X			
< COIL >					
L001	1-408-978-21	INDUCTOR	47uH		
< TRANSISTOR >					
Q001	8-729-808-41	TRANSISTOR 2SD1624-S			
Q002	8-729-808-41	TRANSISTOR 2SD1624-S			
< RESISTOR >					
R002	1-216-073-00	METAL CHIP	10K	5%	1/10W
R003	1-216-073-00	METAL CHIP	10K	5%	1/10W
R071	1-216-047-91	RES, CHIP	820	5%	1/10W
R072	1-216-037-00	METAL CHIP	330	5%	1/10W
< SWITCH >					
S071	1-771-349-21	SWITCH, KEYBOARD (I/⏻)			
< TRANSFORMER >					
T001	1-433-748-11	TRANSFORMER, DC-DC CONVERTER			

* A-6065-229-A	HP-108 BOARD, COMPLETE (S525D)				
* A-6065-252-A	HP-110 BOARD, COMPLETE (S725D)				

(Ref. No. 2,000 Series)					
< CAPACITOR >					
C701	1-163-011-11	CERAMIC CHIP	0.0015uF	10%	50V (S725D)
C701	1-164-161-11	CERAMIC CHIP	0.0022uF	10%	100V (S525D)
C702	1-163-011-11	CERAMIC CHIP	0.0015uF	10%	50V (S725D)
C702	1-164-161-11	CERAMIC CHIP	0.0022uF	10%	100V (S525D)

HP-108
HP-110
MB-85

Ref. No.	Part No.	Description	Remark
< CONNECTOR >			
* CN701	1-564-013-11	PIN, CONNECTOR 3P	
< DIODE >			
D701	8-719-071-15	DIODE HZM6.8ZWA1TL	
D702	8-719-071-15	DIODE HZM6.8ZWA1TL	
< FERRITE BEAD >			
FB701	1-414-135-11	FERRITE 0uH	
FB702	1-414-135-11	FERRITE 0uH	
FB703	1-414-135-11	FERRITE 0uH	
< JACK >			
J701	1-785-505-41	JACK, LARGE TYPE (PHONES) (S725D)	
J701	1-785-505-31	JACK, LARGE TYPE (PHONES) (S525D)	
< JUMPER RESISTOR >			
JR701	1-216-295-91	SHORT 0 (S525D)	
< VARIABLE RESISTOR >			
RV701	1-225-738-11	RES, VAR, CARBON 500/500 (LEVEL)	

*	A-6065-388-A	MB-85 BOARD, COMPLETE (S525D)	
*	A-6065-387-A	MB-85 BOARD, COMPLETE (S725D)	

(Ref. No. 1,000 Series)			
< CAPACITOR >			
C001	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C002	1-164-227-11	CERAMIC CHIP 0.022uF 10% 25V	
C003	1-126-246-11	ELECT CHIP 220uF 20% 4V	
C004	1-126-204-11	ELECT CHIP 47uF 20% 16V	
C005	1-126-206-11	ELECT CHIP 100uF 20% 6.3V	
C007	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C008	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C010	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C011	1-125-822-11	TANTAL. CHIP 10uF 20% 10V	
C012	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C013	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C015	1-126-246-11	ELECT CHIP 220uF 20% 4V	
C016	1-125-822-11	TANTAL. CHIP 10uF 20% 10V	
C017	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C018	1-125-822-11	TANTAL. CHIP 10uF 20% 10V	
C019	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C201	1-162-919-11	CERAMIC CHIP 22PF 5% 50V	
C202	1-162-919-11	CERAMIC CHIP 22PF 5% 50V	
C203	1-125-822-11	TANTAL. CHIP 10uF 20% 10V	
C204	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C206	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C209	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C210	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C211	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C212	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C213	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C304	1-110-563-11	CERAMIC CHIP 0.068uF 10% 16V	
C307	1-125-822-11	TANTAL. CHIP 10uF 20% 10V	
C309	1-107-826-91	CERAMIC CHIP 0.1uF 10% 16V	
C310	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	

Ref. No.	Part No.	Description	Remark
C312	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C313	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C314	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C315	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C316	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C317	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C318	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C319	1-125-822-11	TANTAL. CHIP 10uF 20% 10V	
C320	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C321	1-126-206-11	ELECT CHIP 100uF 20% 6.3V	
C322	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C323	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C324	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C325	1-107-826-91	CERAMIC CHIP 0.1uF 10% 16V	
C327	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C328	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C329	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C331	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C333	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C334	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C337	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C338	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C339	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C341	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C343	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C344	1-162-927-11	CERAMIC CHIP 100PF 5% 50V	
C401	1-125-822-11	TANTAL. CHIP 10uF 20% 10V	
C402	1-126-209-11	ELECT CHIP 100uF 20% 4V	
C403	1-107-826-91	CERAMIC CHIP 0.1uF 10% 16V	
C404	1-107-826-91	CERAMIC CHIP 0.1uF 10% 16V	
C405	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C406	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C408	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C410	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C411	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C413	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C414	1-125-822-11	TANTAL. CHIP 10uF 20% 10V	
C415	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C416	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C418	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C420	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C422	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C425	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C426	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C428	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C431	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C432	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C433	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C434	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C436	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C438	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C439	1-125-822-11	TANTAL. CHIP 10uF 20% 10V	
C440	1-125-822-11	TANTAL. CHIP 10uF 20% 10V	
C441	1-126-209-11	ELECT CHIP 100uF 20% 4V	
C443	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C502	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V (S725D)	
C505	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C506	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C508	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C510	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	

Ref. No.	Part No.	Description	Remark			Ref. No.	Part No.	Description	Remark		
C512	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	C831	1-107-826-91	CERAMIC CHIP	0.1uF	10%	16V
C513	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	C832	1-107-826-91	CERAMIC CHIP	0.1uF	10%	16V
					(S725D)	C833	1-164-677-11	CERAMIC CHIP	0.033uF	10%	16V
C514	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	C834	1-164-677-11	CERAMIC CHIP	0.033uF	10%	16V
					(S725D)	C835	1-107-826-91	CERAMIC CHIP	0.1uF	10%	16V
C515	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	C836	1-115-467-11	CERAMIC CHIP	0.22uF	10%	10V
					(S725D)	C837	1-115-467-11	CERAMIC CHIP	0.22uF	10%	10V
C516	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	C904	1-163-021-91	CERAMIC CHIP	0.01uF	10%	50V
					(S725D)	C905	1-163-021-91	CERAMIC CHIP	0.01uF	10%	50V
C517	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	C906	1-127-950-21	FILM CHIP	0.01uF	5%	16.5V
					(S725D)						(S725D)
C601	1-125-822-11	TANTAL. CHIP	10uF	20%	10V	C906	1-164-004-11	CERAMIC CHIP	0.1uF	10%	25V
C602	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V						(S525D)
C603	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	C907	1-125-822-11	TANTAL. CHIP	10uF	20%	10V
C604	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	C908	1-128-391-11	ELECT CHIP	330uF	20%	6.3V
											(S525D)
C605	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	C909	1-127-950-21	FILM CHIP	0.01uF	5%	16.5V
C606	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V						(S725D)
C607	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	C909	1-164-004-11	CERAMIC CHIP	0.1uF	10%	25V
C608	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V						(S525D)
C701	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V						
C702	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	C910	1-125-822-11	TANTAL. CHIP	10uF	20%	10V
C703	1-107-826-91	CERAMIC CHIP	0.1uF	10%	16V	C911	1-127-950-21	FILM CHIP	0.01uF	5%	16.5V
C704	1-107-826-91	CERAMIC CHIP	0.1uF	10%	16V						(S725D)
C705	1-165-176-11	CERAMIC CHIP	0.047uF	10%	16V	C911	1-163-021-91	CERAMIC CHIP	0.01uF	10%	50V
C706	1-165-176-11	CERAMIC CHIP	0.047uF	10%	16V						(S525D)
C707	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	C912	1-127-516-11	ELECT	220uF	20%	10V
C708	1-107-826-91	CERAMIC CHIP	0.1uF	10%	16V						(S725D)
C709	1-115-467-11	CERAMIC CHIP	0.22uF	10%	10V	C913	1-127-950-21	FILM CHIP	0.01uF	5%	16.5V
C710	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V						(S725D)
C711	1-107-826-91	CERAMIC CHIP	0.1uF	10%	16V	C913	1-164-004-11	CERAMIC CHIP	0.1uF	10%	25V
											(S525D)
C712	1-162-968-11	CERAMIC CHIP	0.0047uF	10%	50V	C914	1-125-822-11	TANTAL. CHIP	10uF	20%	10V
C713	1-162-968-11	CERAMIC CHIP	0.0047uF	10%	50V	C916	1-127-950-21	FILM CHIP	0.01uF	5%	16.5V
C714	1-162-968-11	CERAMIC CHIP	0.0047uF	10%	50V						(S725D)
C715	1-162-968-11	CERAMIC CHIP	0.0047uF	10%	50V	C916	1-163-021-91	CERAMIC CHIP	0.01uF	10%	50V
C717	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V						(S525D)
C801	1-126-204-11	ELECT CHIP	47uF	20%	16V	C922	1-127-950-21	FILM CHIP	0.01uF	5%	16.5V
C802	1-107-826-91	CERAMIC CHIP	0.1uF	10%	16V						(S725D)
C803	1-107-826-91	CERAMIC CHIP	0.1uF	10%	16V	C922	1-164-004-11	CERAMIC CHIP	0.1uF	10%	25V
C805	1-162-923-11	CERAMIC CHIP	47PF	5%	50V						(S525D)
C806	1-162-923-11	CERAMIC CHIP	47PF	5%	50V	C923	1-107-826-91	CERAMIC CHIP	0.1uF	10%	16V
C807	1-162-927-11	CERAMIC CHIP	100PF	5%	50V	C924	1-125-822-11	TANTAL. CHIP	10uF	20%	10V
C808	1-162-927-11	CERAMIC CHIP	100PF	5%	50V	C925	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C809	1-110-563-11	CERAMIC CHIP	0.068uF	10%	16V	C926	1-107-826-91	CERAMIC CHIP	0.1uF	10%	16V
C810	1-110-563-11	CERAMIC CHIP	0.068uF	10%	16V						
C811	1-165-176-11	CERAMIC CHIP	0.047uF	10%	16V	C927	1-125-822-11	TANTAL. CHIP	10uF	20%	10V
C812	1-162-967-11	CERAMIC CHIP	0.0033uF	10%	50V	C928	1-128-391-11	ELECT CHIP	330uF	20%	6.3V
C813	1-162-967-11	CERAMIC CHIP	0.0033uF	10%	50V	C929	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C814	1-165-176-11	CERAMIC CHIP	0.047uF	10%	16V	C931	1-107-826-91	CERAMIC CHIP	0.1uF	10%	16V
C815	1-110-666-11	ELECT CHIP	22uF	20%	6.3V	C932	1-125-822-11	TANTAL. CHIP	10uF	20%	10V
C816	1-104-601-11	ELECT CHIP	10uF	20%	10V						
C817	1-115-467-11	CERAMIC CHIP	0.22uF	10%	10V	C933	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C818	1-107-826-91	CERAMIC CHIP	0.1uF	10%	16V	C934	1-107-826-91	CERAMIC CHIP	0.1uF	10%	16V
C819	1-107-826-91	CERAMIC CHIP	0.1uF	10%	16V	C935	1-125-822-11	TANTAL. CHIP	10uF	20%	10V
C820	1-164-230-11	CERAMIC CHIP	220PF	5%	50V	C937	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C821	1-164-230-11	CERAMIC CHIP	220PF	5%	50V	C939	1-107-826-91	CERAMIC CHIP	0.1uF	10%	16V
C822	1-126-204-11	ELECT CHIP	47uF	20%	16V						
C823	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	C940	1-125-822-11	TANTAL. CHIP	10uF	20%	10V
C824	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V						
C825	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V						
C830	1-107-826-91	CERAMIC CHIP	0.1uF	10%	16V						
											< CONNECTOR >
						CN001	1-785-728-21	PIN (PC BOARD), CONNECTOR 7P			
						CN002	1-779-936-11	CONNECTOR, FFC/FPC 18P			
						CN003	1-779-936-11	CONNECTOR, FFC/FPC 18P			
						CN004	1-778-772-11	CONNECTOR, FFC/FPC 7P			
						CN005	1-784-327-11	CONNECTOR, FFC/FPC 28P			

MB-85

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
CN006	1-774-768-11	CONNECTOR, FFC/FPC 17P		FB063	1-216-829-11	METAL CHIP 4.7K 5%	1/16W
CN007	1-778-274-11	CONNECTOR, FFC/FPC 13P		FB065	1-469-116-21	FERRITE 0uH	
CN010	1-573-806-21	PIN, CONNECTOR (1.5mm) (SMD) 6P		FB067	1-216-829-11	METAL CHIP 4.7K 5%	1/16W
CN011	1-573-806-21	PIN, CONNECTOR (1.5mm) (SMD) 6P		FB069	1-469-116-21	FERRITE 0uH	
* CN012	1-573-768-21	PIN, CONNECTOR (1.5mm) (SMD) 5P		FB071	1-216-829-11	METAL CHIP 4.7K 5%	1/16W
< DIODE >				FB073	1-469-116-21	FERRITE 0uH	
D701	8-719-988-61	DIODE 1SS355TE-17		FB075	1-216-829-11	METAL CHIP 4.7K 5%	1/16W
D801	8-719-941-09	DIODE DAP202U		FB077	1-469-116-21	FERRITE 0uH	
D802	8-719-988-61	DIODE 1SS355TE-17		FB078	1-216-801-11	METAL CHIP 22 5%	1/16W
D803	8-719-941-09	DIODE DAP202U		FB080	1-216-801-11	METAL CHIP 22 5%	1/16W
D804	8-719-941-86	DIODE DAN202U		FB081	1-216-801-11	METAL CHIP 22 5%	1/16W
D805	8-719-941-86	DIODE DAN202U		FB083	1-216-801-11	METAL CHIP 22 5%	1/16W
D806	8-719-988-61	DIODE 1SS355TE-17		FB084	1-216-801-11	METAL CHIP 22 5%	1/16W
D807	8-719-988-61	DIODE 1SS355TE-17		FB085	1-216-801-11	METAL CHIP 22 5%	1/16W
< FERRITE BEAD >				FB086	1-216-801-11	METAL CHIP 22 5%	1/16W (S725D)
FB001	1-469-324-21	FERRITE 0uH		FB087	1-216-801-11	METAL CHIP 22 5%	1/16W
FB002	1-469-324-21	FERRITE 0uH		FB088	1-216-801-11	METAL CHIP 22 5%	1/16W
FB003	1-469-324-21	FERRITE 0uH		FB105	1-469-324-21	FERRITE 0uH	
FB004	1-469-324-21	FERRITE 0uH		FB106	1-469-324-21	FERRITE 0uH	
FB005	1-469-324-21	FERRITE 0uH		< FILTER >			
FB006	1-469-324-21	FERRITE 0uH		FL001	1-234-177-21	FILTER, CHIP EMI	
FB007	1-469-324-21	FERRITE 0uH		FL002	1-234-177-21	FILTER, CHIP EMI	
FB008	1-469-324-21	FERRITE 0uH		FL003	1-233-893-21	FILTER, CHIP EMI	
FB009	1-469-116-21	FERRITE 0uH		FL004	1-233-893-21	FILTER, CHIP EMI	
FB010	1-469-116-21	FERRITE 0uH		FL005	1-234-177-21	FILTER, CHIP EMI	
FB011	1-469-116-21	FERRITE 0uH		FL006	1-234-177-21	FILTER, CHIP EMI	
FB012	1-469-116-21	FERRITE 0uH		FL008	1-234-177-21	FILTER, CHIP EMI	
FB013	1-469-116-21	FERRITE 0uH		FL009	1-234-177-21	FILTER, CHIP EMI	
FB014	1-469-116-21	FERRITE 0uH		FL010	1-234-177-21	FILTER, CHIP EMI	
FB015	1-469-116-21	FERRITE 0uH		FL014	1-234-177-21	FILTER, CHIP EMI	
FB016	1-216-801-11	METAL CHIP 22 5%	1/16W	FL015	1-234-177-21	FILTER, CHIP EMI	
FB017	1-469-116-21	FERRITE 0uH		FL016	1-234-177-21	FILTER, CHIP EMI	
FB018	1-469-116-21	FERRITE 0uH		FL202	1-234-177-21	FILTER, CHIP EMI	
FB019	1-469-116-21	FERRITE 0uH		FL203	1-234-177-21	FILTER, CHIP EMI	
FB020	1-469-116-21	FERRITE 0uH		FL204	1-234-177-21	FILTER, CHIP EMI	
FB021	1-469-116-21	FERRITE 0uH		FL205	1-234-177-21	FILTER, CHIP EMI	
FB022	1-216-829-11	METAL CHIP 4.7K 5%	1/16W	FL301	1-234-177-21	FILTER, CHIP EMI	
FB024	1-469-116-21	FERRITE 0uH		FL302	1-234-177-21	FILTER, CHIP EMI	
FB026	1-216-829-11	METAL CHIP 4.7K 5%	1/16W	FL303	1-234-177-21	FILTER, CHIP EMI	
FB028	1-469-116-21	FERRITE 0uH		FL401	1-234-177-21	FILTER, CHIP EMI	
FB029	1-469-324-21	FERRITE 0uH		FL402	1-234-177-21	FILTER, CHIP EMI	
FB030	1-469-116-21	FERRITE 0uH		FL403	1-234-177-21	FILTER, CHIP EMI	
FB031	1-469-116-21	FERRITE 0uH		FL404	1-234-177-21	FILTER, CHIP EMI	
FB032	1-469-116-21	FERRITE 0uH		FL405	1-234-177-21	FILTER, CHIP EMI	
FB033	1-469-116-21	FERRITE 0uH		FL501	1-234-177-21	FILTER, CHIP EMI (S725D)	
FB035	1-216-829-11	METAL CHIP 4.7K 5%	1/16W	FL502	1-234-177-21	FILTER, CHIP EMI	
FB037	1-216-829-11	METAL CHIP 4.7K 5%	1/16W	FL503	1-234-177-21	FILTER, CHIP EMI (S725D)	
FB040	1-469-116-21	FERRITE 0uH		FL601	1-234-177-21	FILTER, CHIP EMI	
FB043	1-500-283-11	INDUCTOR CHIP 0uH		FL602	1-234-177-21	FILTER, CHIP EMI (S725D)	
FB047	1-469-116-21	FERRITE 0uH		FL701	1-234-177-21	FILTER, CHIP EMI	
FB049	1-469-116-21	FERRITE 0uH		FL904	1-234-177-21	FILTER, CHIP EMI	
FB051	1-469-116-21	FERRITE 0uH		< IC >			
FB053	1-500-283-11	INDUCTOR CHIP 0uH		IC001	8-759-567-31	IC PLL1700E/2K	
FB054	1-500-283-11	INDUCTOR CHIP 0uH		IC003	8-759-531-92	IC TC7WH04FU (TE12R)	
FB055	1-500-283-11	INDUCTOR CHIP 0uH		IC004	8-759-531-92	IC TC7WH04FU (TE12R)	
FB056	1-500-283-11	INDUCTOR CHIP 0uH		IC005	8-759-486-55	IC NJM2370U33-TE2	
FB058	1-500-283-11	INDUCTOR CHIP 0uH		IC201	8-759-469-25	IC AK6440AF-E2	
FB060	1-500-283-11	INDUCTOR CHIP 0uH					
FB061	1-469-116-21	FERRITE 0uH					

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
IC202	8-759-599-39	IC MB91101APFV-G-BND		R212	1-216-813-11	METAL CHIP	220 5% 1/16W
IC203	8-759-580-60	IC SN74AHCT08PWR		R213	1-216-801-11	METAL CHIP	22 5% 1/16W
IC204	8-759-573-65	IC IDT71V016S20PHAU-TL		R217	1-216-833-11	RES, CHIP	10K 5% 1/16W
IC206	8-759-652-96	IC MR27V1602D-45MAZ060 (S725D)		R222	1-216-833-11	RES, CHIP	10K 5% 1/16W
IC206	8-759-652-99	IC MR27V1602D-48MAZ060 (S525D)					
IC207	8-759-427-92	IC PST9126NL		R223	1-216-833-11	RES, CHIP	10K 5% 1/16W
IC302	8-759-486-55	IC NJM2370U33-TE2		R225	1-216-833-11	RES, CHIP	10K 5% 1/16W
IC303	8-759-567-27	IC CXD8784R		R226	1-216-833-11	RES, CHIP	10K 5% 1/16W
IC304	8-759-567-35	IC KM416V1200CT-L6T		R227	1-216-813-11	METAL CHIP	220 5% 1/16W
IC401	8-752-398-60	IC CXD1930BQ		R228	1-216-813-11	METAL CHIP	220 5% 1/16W
IC402	8-759-567-34	IC KM416S1020CT-G10T					
IC403	8-759-567-34	IC KM416S1020CT-G10T		R229	1-216-813-11	METAL CHIP	220 5% 1/16W
IC404	8-759-486-55	IC NJM2370U33-TE2		R230	1-216-813-11	METAL CHIP	220 5% 1/16W
IC501	8-752-400-43	IC CXD1901AR		R231	1-216-813-11	METAL CHIP	220 5% 1/16W
IC502	8-752-390-12	IC CXD1857Q (S725D)		R232	1-216-813-11	METAL CHIP	220 5% 1/16W
				R235	1-216-864-11	METAL CHIP	0 5% 1/16W
IC601	8-759-567-30	IC CXD8788Q					
IC602	8-759-567-55	IC KM29V16000AT-T (S725D)		R237	1-216-230-00	RES, CHIP	22K 5% 1/8W
IC701	8-759-598-87	IC CXD8791AQ		R238	1-216-224-91	RES, CHIP	12K 5% 1/8W
IC702	8-759-337-40	IC NJM2904V (TE2)					(S725D)
IC801	8-759-522-13	IC BA5981FP-E2		R238	1-216-238-91	RES, CHIP	47K 5% 1/8W
							(S525D)
IC802	8-759-567-26	IC BA5983FP-E2		R239	1-216-246-00	RES, CHIP	100K 5% 1/8W
IC803	8-759-338-78	IC BA10324AFV-E2		R240	1-216-230-00	RES, CHIP	22K 5% 1/8W
IC902	8-759-572-26	IC CXD8799N-T2					
IC904	8-759-052-52	IC L78M05T-FA		R241	1-216-224-91	RES, CHIP	12K 5% 1/8W
IC905	8-759-572-26	IC CXD8799N-T2					(S725D)
				R241	1-216-238-91	RES, CHIP	47K 5% 1/8W
IC906	8-759-572-26	IC CXD8799N-T2					(S525D)
IC907	8-759-572-26	IC CXD8799N-T2		R305	1-218-879-11	RES, CHIP	22K 0.50% 1/16W
				R306	1-218-831-11	RES, CHIP	220 0.50% 1/16W
				R307	1-218-883-11	RES, CHIP	33K 0.50% 1/16W
		< COIL >					
L001	1-414-754-11	INDUCTOR 10uH		R308	1-216-825-11	METAL CHIP	2.2K 5% 1/16W
L402	1-414-754-11	INDUCTOR 10uH		R309	1-216-838-11	METAL CHIP	27K 5% 1/16W
				R310	1-216-825-11	METAL CHIP	2.2K 5% 1/16W
				R313	1-216-833-11	RES, CHIP	10K 5% 1/16W
				R314	1-216-833-11	RES, CHIP	10K 5% 1/16W
		< TRANSISTOR >					
Q801	8-729-015-74	TRANSISTOR UN5111-TX		R315	1-216-833-11	RES, CHIP	10K 5% 1/16W
Q802	8-729-230-63	TRANSISTOR 2SC4116-YG		R316	1-218-855-11	RES, CHIP	2.2K 0.50% 1/16W
Q803	8-729-230-63	TRANSISTOR 2SC4116-YG		R317	1-218-871-11	RES, CHIP	10K 0.50% 1/16W
				R318	1-216-849-11	METAL CHIP	220K 5% 1/16W
				R319	1-216-831-11	METAL CHIP	6.8K 5% 1/16W
		< RESISTOR >					
R001	1-216-833-11	RES, CHIP 10K 5%	1/16W	R320	1-218-853-11	RES, CHIP	1.8K 0.50% 1/16W
R002	1-216-833-11	RES, CHIP 10K 5%	1/16W	R321	1-218-847-11	RES, CHIP	1K 0.50% 1/16W
R003	1-216-833-11	RES, CHIP 10K 5%	1/16W	R322	1-218-871-11	RES, CHIP	10K 0.50% 1/16W
R004	1-216-821-11	METAL CHIP 1K 5%	1/16W	R323	1-216-833-11	RES, CHIP	10K 5% 1/16W
R005	1-216-821-11	METAL CHIP 1K 5%	1/16W	R324	1-216-833-11	RES, CHIP	10K 5% 1/16W
R006	1-216-821-11	METAL CHIP 1K 5%	1/16W				
R007	1-216-864-11	METAL CHIP 0 5%	1/16W	R325	1-216-833-11	RES, CHIP	10K 5% 1/16W
R009	1-216-864-11	METAL CHIP 0 5%	1/16W	R326	1-216-833-11	RES, CHIP	10K 5% 1/16W
R010	1-216-801-11	METAL CHIP 22 5%	1/16W	R327	1-216-833-11	RES, CHIP	10K 5% 1/16W
R014	1-216-801-11	METAL CHIP 22 5%	1/16W	R328	1-216-833-11	RES, CHIP	10K 5% 1/16W
				R329	1-216-833-11	RES, CHIP	10K 5% 1/16W
R036	1-216-821-11	METAL CHIP 1K 5%	1/16W				
R037	1-216-825-11	METAL CHIP 2.2K 5%	1/16W	R330	1-216-833-11	RES, CHIP	10K 5% 1/16W
R044	1-216-829-11	METAL CHIP 4.7K 5%	1/16W	R331	1-216-833-11	RES, CHIP	10K 5% 1/16W
R045	1-216-833-11	RES, CHIP 10K 5%	1/16W	R332	1-216-833-11	RES, CHIP	10K 5% 1/16W
R053	1-216-833-11	RES, CHIP 10K 5%	1/16W	R337	1-216-809-11	METAL CHIP	100 5% 1/16W
				R338	1-216-833-11	RES, CHIP	10K 5% 1/16W
R202	1-216-801-11	METAL CHIP 22 5%	1/16W				
R203	1-216-833-11	RES, CHIP 10K 5%	1/16W	R339	1-216-833-11	RES, CHIP	10K 5% 1/16W
R204	1-216-833-11	RES, CHIP 10K 5%	1/16W	R340	1-216-833-11	RES, CHIP	10K 5% 1/16W
R205	1-216-845-11	METAL CHIP 100K 5%	1/16W	R341	1-216-809-11	METAL CHIP	100 5% 1/16W
R206	1-216-845-11	METAL CHIP 100K 5%	1/16W	R403	1-216-833-11	RES, CHIP	10K 5% 1/16W
				R404	1-216-864-11	METAL CHIP	0 5% 1/16W
R207	1-216-833-11	RES, CHIP 10K 5%	1/16W				
				R405	1-216-827-11	METAL CHIP	3.3K 5% 1/16W
				R406	1-216-822-11	METAL CHIP	1.2K 5% 1/16W
				R407	1-216-833-11	RES, CHIP	10K 5% 1/16W

MB-85

Ref. No.	Part No.	Description	Remark			Ref. No.	Part No.	Description	Remark		
R409	1-216-864-11	METAL CHIP	0	5%	1/16W	R751	1-216-821-11	METAL CHIP	1K	5%	1/16W
R410	1-216-821-11	METAL CHIP	1K	5%	1/16W	R752	1-216-821-11	METAL CHIP	1K	5%	1/16W
						R755	1-216-830-11	METAL CHIP	5.6K	5%	1/16W
R411	1-216-833-11	RES, CHIP	10K	5%	1/16W	R757	1-216-864-11	METAL CHIP	0	5%	1/16W
R412	1-216-809-11	METAL CHIP	100	5%	1/16W						
R426	1-216-813-11	METAL CHIP	220	5%	1/16W	R758	1-216-864-11	METAL CHIP	0	5%	1/16W
R427	1-216-813-11	METAL CHIP	220	5%	1/16W	R801	1-216-841-11	METAL CHIP	47K	5%	1/16W
R428	1-216-813-11	METAL CHIP	220	5%	1/16W	R802	1-216-841-11	METAL CHIP	47K	5%	1/16W
						R803	1-216-841-11	METAL CHIP	47K	5%	1/16W
R429	1-216-813-11	METAL CHIP	220	5%	1/16W	R804	1-216-841-11	METAL CHIP	47K	5%	1/16W
R430	1-216-813-11	METAL CHIP	220	5%	1/16W						
R431	1-216-813-11	METAL CHIP	220	5%	1/16W	R805	1-216-840-11	METAL CHIP	39K	5%	1/16W
R501	1-216-809-11	METAL CHIP	100	5%	1/16W	R806	1-216-840-11	METAL CHIP	39K	5%	1/16W
					(S725D)	R807	1-216-835-11	METAL CHIP	15K	5%	1/16W
R519	1-216-809-11	METAL CHIP	100	5%	1/16W	R808	1-216-835-11	METAL CHIP	15K	5%	1/16W
						R809	1-216-844-11	METAL CHIP	82K	5%	1/16W
R520	1-216-833-11	RES, CHIP	10K	5%	1/16W						
R521	1-216-833-11	RES, CHIP	10K	5%	1/16W	R810	1-216-844-11	METAL CHIP	82K	5%	1/16W
R522	1-216-833-11	RES, CHIP	10K	5%	1/16W	R811	1-218-907-11	RES, CHIP	330K	0.50%	1/16W
R527	1-216-833-11	RES, CHIP	10K	5%	1/16W	R812	1-218-895-11	RES, CHIP	100K	0.50%	1/16W
R528	1-216-833-11	RES, CHIP	10K	5%	1/16W	R813	1-218-895-11	RES, CHIP	100K	0.50%	1/16W
						R814	1-218-907-11	RES, CHIP	330K	0.50%	1/16W
R530	1-216-864-11	METAL CHIP	0	5%	1/16W						
R537	1-216-806-11	RES, CHIP	56	5%	1/16W	R815	1-216-836-11	METAL CHIP	18K	5%	1/16W
R539	1-216-864-11	METAL CHIP	0	5%	1/16W	R816	1-216-845-11	METAL CHIP	100K	5%	1/16W
R540	1-216-864-11	METAL CHIP	0	5%	1/16W	R817	1-216-852-11	METAL CHIP	390K	5%	1/16W
R541	1-216-864-11	METAL CHIP	0	5%	1/16W	R818	1-216-852-11	METAL CHIP	390K	5%	1/16W
						R819	1-216-849-11	METAL CHIP	220K	5%	1/16W
R543	1-216-864-11	METAL CHIP	0	5%	1/16W						
R544	1-216-864-11	METAL CHIP	0	5%	1/16W	R820	1-216-851-11	METAL CHIP	330K	5%	1/16W
R604	1-216-833-11	RES, CHIP	10K	5%	1/16W	R821	1-216-840-11	METAL CHIP	39K	5%	1/16W
					(S725D)	R822	1-216-845-11	METAL CHIP	100K	5%	1/16W
R605	1-216-833-11	RES, CHIP	10K	5%	1/16W	R823	1-216-833-11	RES, CHIP	10K	5%	1/16W
R606	1-216-833-11	RES, CHIP	10K	5%	1/16W	R824	1-216-833-11	RES, CHIP	10K	5%	1/16W
R630	1-216-833-11	RES, CHIP	10K	5%	1/16W	R825	1-216-830-11	METAL CHIP	5.6K	5%	1/16W
R631	1-216-833-11	RES, CHIP	10K	5%	1/16W	R826	1-216-830-11	METAL CHIP	5.6K	5%	1/16W
R632	1-216-833-11	RES, CHIP	10K	5%	1/16W	R827	1-216-851-11	METAL CHIP	330K	5%	1/16W
R633	1-216-833-11	RES, CHIP	10K	5%	1/16W	R828	1-216-837-11	METAL CHIP	22K	5%	1/16W
R634	1-216-833-11	RES, CHIP	10K	5%	1/16W	R829	1-216-837-11	METAL CHIP	22K	5%	1/16W
R635	1-216-833-11	RES, CHIP	10K	5%	1/16W	R831	1-216-833-11	RES, CHIP	10K	5%	1/16W
R636	1-216-815-11	METAL CHIP	330	5%	1/16W	R832	1-216-833-11	RES, CHIP	10K	5%	1/16W
R637	1-216-809-11	METAL CHIP	100	5%	1/16W	R834	1-216-847-11	METAL CHIP	150K	5%	1/16W
R638	1-216-809-11	METAL CHIP	100	5%	1/16W	R835	1-216-847-11	METAL CHIP	150K	5%	1/16W
R639	1-216-809-11	METAL CHIP	100	5%	1/16W	R836	1-216-847-11	METAL CHIP	150K	5%	1/16W
R640	1-216-809-11	METAL CHIP	100	5%	1/16W	R837	1-216-844-11	METAL CHIP	82K	5%	1/16W
R641	1-216-809-11	METAL CHIP	100	5%	1/16W	R838	1-216-848-11	METAL CHIP	180K	5%	1/16W
R642	1-216-809-11	METAL CHIP	100	5%	1/16W	R839	1-216-848-11	METAL CHIP	180K	5%	1/16W
R643	1-216-815-11	METAL CHIP	330	5%	1/16W	R840	1-216-848-11	METAL CHIP	180K	5%	1/16W
R647	1-216-833-11	RES, CHIP	10K	5%	1/16W	R841	1-216-843-11	METAL CHIP	68K	5%	1/16W
R701	1-216-805-11	METAL CHIP	47	5%	1/16W	R842	1-216-844-11	METAL CHIP	82K	5%	1/16W
R702	1-216-817-11	METAL CHIP	470	5%	1/16W	R843	1-216-844-11	METAL CHIP	82K	5%	1/16W
R703	1-216-817-11	METAL CHIP	470	5%	1/16W	R844	1-216-843-11	METAL CHIP	68K	5%	1/16W
R704	1-216-817-11	METAL CHIP	470	5%	1/16W	R845	1-216-843-11	METAL CHIP	68K	5%	1/16W
R705	1-216-817-11	METAL CHIP	470	5%	1/16W	R846	1-216-841-11	METAL CHIP	47K	5%	1/16W
R706	1-216-821-11	METAL CHIP	1K	5%	1/16W	R847	1-216-296-91	SHORT	0		
R707	1-216-844-11	METAL CHIP	82K	5%	1/16W	R851	1-216-833-11	RES, CHIP	10K	5%	1/16W
R708	1-216-844-11	METAL CHIP	82K	5%	1/16W	R852	1-216-833-11	RES, CHIP	10K	5%	1/16W
R709	1-216-844-11	METAL CHIP	82K	5%	1/16W	R853	1-216-833-11	RES, CHIP	10K	5%	1/16W
R710	1-216-844-11	METAL CHIP	82K	5%	1/16W	R854	1-216-833-11	RES, CHIP	10K	5%	1/16W
R711	1-216-833-11	RES, CHIP	10K	5%	1/16W	R855	1-216-834-11	METAL CHIP	12K	5%	1/16W
R712	1-216-839-11	METAL CHIP	33K	5%	1/16W	R856	1-216-836-11	METAL CHIP	18K	5%	1/16W
R720	1-216-821-11	METAL CHIP	1K	5%	1/16W	R857	1-218-899-11	RES, CHIP	150K	0.50%	1/16W
R721	1-216-821-11	METAL CHIP	1K	5%	1/16W	R858	1-218-899-11	RES, CHIP	150K	0.50%	1/16W
R722	1-216-801-11	METAL CHIP	22	5%	1/16W	R859	1-218-889-11	RES, CHIP	56K	0.50%	1/16W
R748	1-216-833-11	RES, CHIP	10K	5%	1/16W	R860	1-218-889-11	RES, CHIP	56K	0.50%	1/16W

Ref. No.	Part No.	Description	Remark		
R861	1-216-296-91	SHORT	0		
R864	1-216-138-00	METAL CHIP	3.3	5%	1/8W
R865	1-216-833-11	RES, CHIP	10K	5%	1/16W
R866	1-216-833-11	RES, CHIP	10K	5%	1/16W
R867	1-216-833-11	RES, CHIP	10K	5%	1/16W
R868	1-216-833-11	RES, CHIP	10K	5%	1/16W
R869	1-216-833-11	RES, CHIP	10K	5%	1/16W
R870	1-216-815-11	METAL CHIP	330	5%	1/16W
R871	1-216-817-11	METAL CHIP	470	5%	1/16W
R872	1-216-815-11	METAL CHIP	330	5%	1/16W
R873	1-216-821-11	METAL CHIP	1K	5%	1/16W
R909	1-216-809-11	METAL CHIP	100	5%	1/16W
R912	1-216-809-11	METAL CHIP	100	5%	1/16W
R915	1-216-809-11	METAL CHIP	100	5%	1/16W
R918	1-216-809-11	METAL CHIP	100	5%	1/16W
< COMPOSITION CIRCUIT BLOCK >					
* RB201	1-233-270-11	NETWORK, RES (8 GANG) 10K			
* RB202	1-233-270-11	NETWORK, RES (8 GANG) 10K			
* RB203	1-233-270-11	NETWORK, RES (8 GANG) 10K			
* RB204	1-233-270-11	NETWORK, RES (8 GANG) 10K			
* RB402	1-233-270-11	NETWORK, RES (8 GANG) 10K (S525D)			
* RB601	1-233-270-11	NETWORK, RES (8 GANG) 10K			
< VARIABLE RESISTOR >					
RV401	1-223-583-11	RES, ADJ, CARBON 1K			
< VIBRATOR >					
X001	1-781-188-21	OSCILLATOR, CRYSTAL (27MHz)			
X201	1-781-185-21	VIBRATOR, CERAMIC (12.5MHz)			

*	A-6066-012-A	MS-29 BOARD, COMPLETE			

(Ref. No. 3,000 Series)					
< CONNECTOR >					
CN001	1-564-722-11	PIN, CONNECTOR (SMALL TYPE) 6P			
< SWITCH >					
S001	1-771-562-11	SWITCH, LEVER (TRAY SENSOR)			
S002	1-762-386-11	SWITCH, PUSH (CHUCK SENSOR)			

*	1-468-359-11	POWER BLOCK (HS-030SH)			

(Ref.No. 6,000 Series)					
< CAPACITOR >					
C110	9-884-088-01	ELECT	56uF		400V
C131	1-126-964-11	ELECT	10uF		50V
C132	1-126-960-11	ELECT	1uF		50V
C186	1-107-967-11	ELECT	1uF		400V
C211	1-111-087-11	ELECT	330uF		35V
C213	1-126-947-11	ELECT	47uF		35V
C301	1-126-960-11	ELECT	1uF		50V
C311	1-111-087-11	ELECT	330uF		35V
C313	1-126-947-11	ELECT	47uF		35V
C401	1-126-948-11	ELECT	100uF		35V

Ref. No.	Part No.	Description	Remark	
C402	1-126-960-11	ELECT	1uF	50V
C511	1-126-942-11	ELECT	1000uF	25V
C512	1-126-947-11	ELECT	47uF	35V
C611	1-111-090-11	ELECT	560uF	35V
C613	1-126-947-11	ELECT	47uF	35V
< DIODE >				
D101	9-884-089-01	DIODE S1WBA60		
D102	8-719-160-68	DIODE RD18FB2		
D104	8-719-109-57	DIODE RD2.4ESB2		
D105	9-980-073-01	DIODE 1SS270A		
D131	9-980-073-01	DIODE 1SS270A		
D132	9-980-073-01	DIODE 1SS270A		
D133	8-719-109-60	DIODE RD2.7ESB2		
D135	9-980-073-01	DIODE 1SS270A		
D182	8-719-109-60	DIODE RD2.7ESB2		
D183	9-980-073-01	DIODE 1SS270A		
D184	9-880-435-01	DIODE D1N60		
D185	8-719-160-68	DIODE RD18FB2		
D211	8-719-027-43	DIODE S2L20U		
D212	8-719-160-78	DIODE RD24FB2		
D311	8-719-200-59	DIODE 21DQ04		
D401	8-719-210-21	DIODE 11EQS04		
D402	8-719-110-02	DIODE RD7.5ESB1		
D511	8-719-027-43	DIODE S2L20U		
D611	8-719-500-50	DIODE D3S4M		
< FUSE >				
△F101	1-532-503-31	FUSE (1.6A/250V)		
< IC >				
IC301	8-759-420-19	IC AN1431T		
IC401	8-759-420-19	IC AN1431T		
< IC LINK >				
△P211	1-533-588-11	IC LINK 500mA		
△P311	1-533-593-11	IC LINK 2A		
△P511	1-533-589-11	IC LINK 750mA		
△P611	9-884-090-01	IC LINK 1.5A		
< PHOTO COUPLER >				
△PC101	8-749-010-59	PHOTO COUPLER TLP721F		
△PC102	8-749-010-59	PHOTO COUPLER TLP721F		
△PC103	8-749-010-59	PHOTO COUPLER TLP721F		
< TRANSISTOR >				
Q101	9-880-450-01	TRANSISTOR 2SK2333		
Q102	8-729-023-98	TRANSISTOR 2SC3377		
Q103	9-880-450-01	TRANSISTOR 2SK2333		
Q131	8-729-023-98	TRANSISTOR 2SC3377		
Q181	8-729-046-40	TRANSISTOR 2SK2663		
Q182	8-729-023-98	TRANSISTOR 2SC3377		
Q183	8-729-046-40	TRANSISTOR 2SK2663		
< RESISTOR >				
R152	1-219-121-21	FUSIBLE	0.22	1/4W F

RY-12
SW-314
SW-316
TK-54

Ref. No.	Part No.	Description	Remark
*	A-6065-255-A	RY-12 BOARD, COMPLETE (S725D) ***** (Ref. No. 2,000 Series)	
		< CONNECTOR >	
* CN101	1-580-230-21	PIN, CONNECTOR (PC BOARD) 2P	
* CN201	1-691-960-11	PIN, CONNECTOR (PC BOARD) 3P	
* CN202	1-564-001-11	PIN, CONNECTOR 2P	
		< DIODE >	
D101	8-719-911-19	DIODE 1SS119	
		< RELAY >	
△ RY101	1-755-318-11	RELAY, POWER	
*	A-6065-230-A	SW-314 BOARD, COMPLETE (S525D)	
*	A-6065-253-A	SW-316 BOARD, COMPLETE (S725D) ***** (Ref. No. 4,000 Series)	
		< CONNECTOR >	
CN099	1-785-539-21	CONNECTOR, BOARD TO BOARD 4P	
		< DIODE >	
D098	8-719-056-06	DIODE SLR-342DCT31 (VES) (S525D)	
D098	8-719-056-06	DIODE SLR-342DCT31 (VIRTUAL 3D SURROUND) (S725D)	
		< TRANSISTOR >	
Q098	8-729-421-22	TRANSISTOR UN2211	
		< RESISTOR >	
R098	1-216-041-00	METAL CHIP 470 5% 1/10W	
		< SWITCH >	
S098	1-771-349-21	SWITCH, KEYBOARD (VES) (S525D)	
S098	1-771-349-21	SWITCH, KEYBOARD (VIRTUAL 3D SURROUND) (S725D)	
*	A-6065-256-A	TK-54 BOARD, COMPLETE ***** (Ref. No. 2,000 Series)	
		< CAPACITOR >	
C004	1-107-826-91	CERAMIC CHIP 0.1uF 10% 16V	
C005	1-162-966-11	CERAMIC CHIP 0.0022uF 10% 50V	
C006	1-124-779-00	ELECT CHIP 10uF 20% 16V	
C007	1-162-966-11	CERAMIC CHIP 0.0022uF 10% 50V	
C008	1-162-966-11	CERAMIC CHIP 0.0022uF 10% 50V	
C009	1-162-966-11	CERAMIC CHIP 0.0022uF 10% 50V	
C010	1-107-826-91	CERAMIC CHIP 0.1uF 10% 16V	
C011	1-162-919-11	CERAMIC CHIP 22PF 5% 50V	
C012	1-124-779-00	ELECT CHIP 10uF 20% 16V	
C013	1-162-919-11	CERAMIC CHIP 22PF 5% 50V	
C014	1-162-919-11	CERAMIC CHIP 22PF 5% 50V	
C015	1-162-919-11	CERAMIC CHIP 22PF 5% 50V	
C016	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C017	1-164-172-11	CERAMIC CHIP 0.0056uF 10% 25V	
C018	1-164-739-11	CERAMIC CHIP 560PF 5% 50V	

Ref. No.	Part No.	Description	Remark
C019	1-164-172-11	CERAMIC CHIP 0.0056uF 10% 25V	
C020	1-107-826-91	CERAMIC CHIP 0.1uF 10% 16V	
C021	1-107-826-91	CERAMIC CHIP 0.1uF 10% 16V	
C022	1-107-826-91	CERAMIC CHIP 0.1uF 10% 16V	
C023	1-165-176-11	CERAMIC CHIP 0.047uF 10% 16V	
C024	1-164-730-11	CERAMIC CHIP 0.0012uF 10% 50V	
C025	1-165-176-11	CERAMIC CHIP 0.047uF 10% 16V	
C026	1-162-964-11	CERAMIC CHIP 0.001uF 10% 50V	
C027	1-164-217-11	CERAMIC CHIP 150PF 5% 50V	
C028	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C029	1-107-826-91	CERAMIC CHIP 0.1uF 10% 16V	
C030	1-107-826-91	CERAMIC CHIP 0.1uF 10% 16V	
C031	1-124-779-00	ELECT CHIP 10uF 20% 16V	
C032	1-107-826-91	CERAMIC CHIP 0.1uF 10% 16V	
C033	1-107-826-91	CERAMIC CHIP 0.1uF 10% 16V	
C034	1-107-826-91	CERAMIC CHIP 0.1uF 10% 16V	
C035	1-107-826-91	CERAMIC CHIP 0.1uF 10% 16V	
C036	1-165-176-11	CERAMIC CHIP 0.047uF 10% 16V	
C037	1-164-739-11	CERAMIC CHIP 560PF 5% 50V	
C038	1-107-826-91	CERAMIC CHIP 0.1uF 10% 16V	
C039	1-107-826-91	CERAMIC CHIP 0.1uF 10% 16V	
C040	1-162-969-11	CERAMIC CHIP 0.0068uF 10% 25V	
C041	1-162-966-11	CERAMIC CHIP 0.0022uF 10% 50V	
		< CONNECTOR >	
CN001	1-785-700-21	CONNECTOR, FFC/FPC (ZIF) 23P	
CN002	1-566-529-11	CONNECTOR, FPC (ZIF) 13P	
CN003	1-785-699-21	CONNECTOR, FFC/FPC 18P	
CN004	1-785-699-21	CONNECTOR, FFC/FPC 18P	
		< DIODE >	
D003	8-719-988-61	DIODE 1SS355TE-17	
		< IC >	
IC001	8-759-567-24	IC SSI33P3722	
		< COIL >	
L001	1-412-031-11	INDUCTOR CHIP 47uH	
		< TRANSISTOR >	
Q001	8-729-903-46	TRANSISTOR 2SB1132-T100-QR	
Q002	8-729-015-76	TRANSISTOR UN5211-TX	
		< RESISTOR >	
R001	1-216-815-11	METAL CHIP 330 5% 1/16W	
R002	1-216-809-11	METAL CHIP 100 5% 1/16W	
R003	1-216-809-11	METAL CHIP 100 5% 1/16W	
R004	1-216-837-11	METAL CHIP 22K 5% 1/16W	
R005	1-216-013-00	METAL CHIP 33 5% 1/10W	
R006	1-216-013-00	METAL CHIP 33 5% 1/10W	
R007	1-216-841-11	METAL CHIP 47K 5% 1/16W	
R008	1-216-797-11	METAL CHIP 10 5% 1/16W	
R009	1-216-834-11	METAL CHIP 12K 5% 1/16W	
R010	1-216-833-11	RES, CHIP 10K 5% 1/16W	
R012	1-216-864-11	METAL CHIP 0 5% 1/16W	
R014	1-216-864-11	METAL CHIP 0 5% 1/16W	
R015	1-216-833-11	RES, CHIP 10K 5% 1/16W	
R016	1-216-833-11	RES, CHIP 10K 5% 1/16W	
R017	1-216-829-11	METAL CHIP 4.7K 5% 1/16W	

Ref. No.	Part No.	Description	Remark		
R018	1-216-833-11	RES, CHIP	10K	5%	1/16W
R022	1-216-811-11	METAL CHIP	150	5%	1/16W
R023	1-216-820-11	METAL CHIP	820	5%	1/16W
R025	1-216-813-11	METAL CHIP	220	5%	1/16W
R026	1-216-864-11	METAL CHIP	0	5%	1/16W
R029	1-216-861-11	METAL CHIP	2.2M	5%	1/16W

MISCELLANEOUS

115	1-418-097-11	ENCODER, ROTARY			
127	1-790-167-11	CABLE, FLEXIBLE FLAT (FMF-35)			
153	1-790-166-11	CABLE, FLEXIBLE FLAT (FMT-25)			
154	1-790-163-11	CABLE, FLEXIBLE FLAT (FMA-7)			
155	1-790-164-11	CABLE, FLEXIBLE FLAT (FMA-8)			
156	1-790-165-11	CABLE, FLEXIBLE FLAT (FMA-9)			
△ 161	1-769-744-91	CORD, POWER			
166	1-790-168-11	CABLE, FLEXIBLE FLAT (FEA-4) (S725D)			
166	1-790-408-11	CABLE, FLEXIBLE FLAT (FME-4) (S525D)			
△ 220	8-820-081-03	OPTICAL PICK-UP KHM-220AAA/J1RP			
M001	1-541-632-11	MOTOR, DC (LOADING)			
△ T901	1-431-175-21	TRANSFORMER, POWER (S725D)			

HARDWARE LIST

#1	7-685-885-09	SCREW +BVTT 4X16 (S) (S725D)
#2	7-621-775-10	SCREW +B 2.6X4
#3	7-685-136-19	SCREW +BTP 2.6X12 TYPE2 N-S

ACCESSORIES & PACKING MATERIALS

1-418-320-31	COMMANDER, STANDARD (RMT-D108P)	(S525D)
1-418-321-31	COMMANDER, STANDARD (RMT-D111P)	(S725D)
1-575-334-11	CORD, CONNECTION	(STEREO AV CABLE 1.5m) (S525D)
1-575-334-41	CORD, CONNECTION	(STEREO AV CABLE 1.5m) (S725D)
1-575-335-21	CORD, CONNECTION	(S-VIDEO CABLE 1.5m) (S525D)
1-776-078-31	CORD, CONNECTION (S-VIDEO CABLE 1.5m)	(S725D)
3-053-633-01	COVER, BATTERY (for RMT-D108P)	(S525D)
3-055-539-01	COVER, BATTERY (for RMT-D111P)	(S725D)
3-865-642-41	MANUAL, INSTRUCTION (ENGLISH)	(S525D)
3-865-642-51	MANUAL, INSTRUCTION (FRENCH, GERMAN)	(S525D)
3-865-642-61	MANUAL, INSTRUCTION (ITALIAN, DUTCH)	(S525D)
3-866-153-21	MANUAL, INSTRUCTION (ENGLISH)	(S725D)
3-866-153-31	MANUAL, INSTRUCTION (FRENCH, GERMAN)	(S725D)
3-866-153-41	MANUAL, INSTRUCTION (ITALIAN, DUTCH)	(S725D)

The components identified by mark △ or dotted line with mark △ are critical for safety.
Replace only with part number specified.